

ROBOTICS

Product manual

FlexTrack IRT501



Trace back information:
Workspace Systems version a32
Checked in 2022-10-19
Skribenta version 5.5.019

Product manual

**FlexTrack IRT501-66
FlexTrack IRT501-66R
FlexTrack IRT501-90
FlexTrack IRT501-90R
FlexTrack IRT501-90RE
FlexTrack IRT501-90RS**

IRC5

Document ID: 3HAW050008590-001

Revision: E

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2022 ABB. All rights reserved.
Specifications subject to change without notice.

Table of contents

Overview	9
Product documentation, M2004	12
How to read the product manual	14
1 Safety	15
1.1 Introduction	15
1.2 General safety information	16
1.2.1 Safety in the robot system	16
1.3 Safety risks	17
1.3.1 Safety risks during installation and service work on robot	17
1.3.2 Safety risks related to tools/workpieces	19
1.3.3 Safety risks related to pneumatic/hydraulic systems	20
1.3.4 Safety risks during operational disturbances	21
1.3.5 Risks associated with live electric parts	22
1.4 Safety actions	23
1.4.1 Safety fence dimensions	23
1.4.2 Fire extinguishing	24
1.4.3 Emergency release of the robots/manipulators axes	25
1.4.4 Brake testing	26
1.4.5 Risk of disabling function "Reduced speed 250 mm/s"	27
1.4.6 Safe use of the Teach Pendant Unit	28
1.4.7 Work inside the manipulator's working range	29
1.4.8 Translate the information on safety and information labels	30
1.5 Safety related instructions	31
1.5.1 Safety signals, general	31
1.5.2 DANGER - Moving manipulators are potentially lethal!	33
1.5.3 DANGER - First test run may cause injury or damage!	34
1.5.4 WARNING - The unit is sensitive to ESD!	35
1.5.5 WARNING - Safety risks during work with gearbox oil	36
1.5.6 Location of safety pictograms	37
2 Installation and commissioning	39
2.1 Introduction	39
2.2 Unpacking and acceptance	41
2.2.1 Unpacking	41
2.2.2 Acceptance inspection	42
2.3 Handling	43
2.3.1 Lifting FlexTrack IRT 501	43
2.3.2 Lifting weight	48
2.3.3 FlexTrack IRT 501 size and dimensions	49
2.3.4 Moving the carriage manually	54
2.4 Preparations for assembly	57
2.4.1 Foundation	57
2.4.2 Recommendation for anchors	60
2.4.3 Screw joints	63
2.5 Assembly of the track	64
2.5.1 Procedure of assembly	64
2.5.2 Recommendations for floor mounting	71
2.5.3 Geometric alignment of FlexTrack IRT 501	75
2.6 Assembly of the manipulator	80
2.7 Cables, SMB box and cable chain	81
2.7.1 Cabling of the FlexTrack	81
2.7.2 Specifications of the movement cables	82
2.7.3 Specifications of the internal cable chain	83
2.7.4 Installation of the cable chain	84
2.7.5 SMB box	87

Table of contents

2.7.6	Cables connections	88
2.7.7	Connectors on IRC5 controller	90
2.8	Software installation	95
2.8.1	Preparation for setup	95
2.8.2	Load configuration files	96
2.8.3	Modification of the Travel Direction of the track	99
2.8.4	Link robot and track	100
2.8.5	Robot orientation on the track	101
2.8.6	Set Upper and Lower Limits Software Limits for track	103
2.9	Lubrication	108
2.9.1	Activating the automatic lubrication system	108
2.9.2	Lubrication feedback (optional)	111
2.10	Zone Division	112
2.11	Setting up the FlexTrack limit switch for additional safety	113
2.12	Additional Safety Function Support	115
2.13	Anti-collision system (optional)	116
3	Maintenance	119
3.1	Introduction	119
3.2	Standard toolkit	120
3.3	Maintenance schedule and expected component life	121
3.3.1	Specification of maintenance intervals	121
3.3.2	Expected component life	122
3.3.3	Maintenance schedule	123
3.4	Activities 100 Km or one week	124
3.4.1	Racks and pinion	124
3.5	Activities 1 Month	126
3.5.1	Linear rails	126
3.5.2	Ball bearing blocks	128
3.5.3	Automatic lubrication system	130
3.5.4	Emergency stop and stroke limit system	137
3.5.5	Zone division system	138
3.5.6	Cables and connectors	140
3.6	Activity 3 and 12 months	141
3.6.1	Gearbox	141
3.7	Activities 6 Months	143
3.7.1	Anti-collision system function test	143
3.8	Activities 36 Months	144
3.8.1	Replacement, SMB Battery pack	144
4	Repair	147
4.1	Instruction	147
4.2	Replace the linear rails	148
4.3	Replace the ball bearing blocks	152
4.4	Replace the racks	156
4.5	Motor and gearbox	159
4.5.1	Overview	159
4.5.2	Disassemble the bracket from the carriage	160
4.5.3	Replace motor	164
4.5.4	Replace gearbox	165
4.5.5	Motor and gearbox assembly	168
4.6	Replace the cable chain or the cable	173
4.7	Replace the laser scanner and reflector	179
5	Calibration	183
5.1	Overview	183
5.2	Fine calibration	184
5.3	Update revolution counters	185

6	Decommissioning	187
6.1	Introduction	187
6.2	Environmental information	188
7	Reference information	191
7.1	Introduction	191
7.2	Applicable safety standards	192
7.3	Unit conversion	193
8	Spare parts	195
8.1	Carriage IRT501	195
8.2	Track	197
8.3	Limit switch and calibration	198
8.4	Automatic lubrication system	199
8.5	Cable chains	201
8.6	Electrical spare parts and cables	204
8.7	Anti collision	207
9	Appendix	209
9.1	Wiring diagrams	209
	Index	211

This page is intentionally left blank

Overview

About this manual

This manual contains instructions for:

- mechanical and electrical installation instructions for the FlexTrack
- maintenance instructions for the FlexTrack
- spare parts

Usage

This manual should be used when working during;

- installation, from lifting the robot to its work site and securing it to the foundation, to making it ready for operation
- maintenance work
- repair work

Who should read this manual?

This manual is intended for:

- installation personnel
- maintenance personnel
- repair personnel

Prerequisites

A maintenance/repair/installation craftsman working with an ABB Robot must:

- be trained by ABB and have the required knowledge of mechanical and electrical installation/repair/maintenance work.

Organization of chapters

The manual is organized in the following chapters:

Chapter	Contents
Safety	Safety information that must be read through before performing any installation or service work on the FlexTrack. Contains general safety aspects as well as more specific information about how to avoid personal injuries and damage to the product.
Installation and commissioning	Required information about lifting and installation of the FlexTrack.
Maintenance	Step-by-step procedures that describe how to perform maintenance of the FlexTrack. Based on a maintenance schedule that may be used in the work of planning periodical maintenance.
Calibration information	Procedures that does not require specific calibration equipment.

References

Document name	Document ID
Product specification - IRT 501 - 66/66R/90/90R	3HAW050008591
Product manual - IRC5 Robot Controller	3HAC021313-001

Continues on next page

Overview

Continued

Document name	Document ID
Operating manual - IRC5 with FlexPendant	3HAC16590-1
Operating manual - Calibration Pendulum	3HAC16578-1
Service Information System - IRC5	3HAC025709-001
Application manual - Additional axes and stand alone controller	3HAC021395-001
System Parameters	3HAC17076-1
Application manual - Functional safety and SafeMove	3HAC052610-001
FlexTrack Lubrication Unit Feedback	3HAW107710207

Revisions

Revision	Description
-	First edition.
A	Changes made in: <ul style="list-style-type: none">• Clarity improved and pictures added in Disassemble the bracket from the carriage on page 160. Instructions for the coupling of the motor and the gearbox updated, see Motor and gearbox assembly on page 168.• Names of spare cables updated, see Electrical spare parts and cables on page 204.
B	Changes made in: <ul style="list-style-type: none">• Standard top plate drawings are updated in Standard top plate on page 52• Robot capacities updated in Static loads on page 57• FlexTrack on site installation procedures updated in Procedure of assembly on page 64• Add more detailed information about 1, 2 and 4 position switch in Zone Division on page 112• Change the verification step of the tightening torque in Verification of the tightening torque on page 142• Procedures about how to change a cable in the cable chain is added in Replace cables on page 176• Spare parts updated in Spare parts on page 195• Electrical diagrams added in Appendix on page 209

Continues on next page

Revision	Description
C	<p>Changes made in:</p> <ul style="list-style-type: none"> • Expected life of ball bearing blocks updated in Expected life on page 122 • Different suppliers of linear rails added in Linear rail of different supplier on page 148 and different suppliers of cable chain added in Cable chain of different supplier on page 173 • Spare parts updated in Spare parts on page 195 • Robot capacities about IRB 6650/6650s/6660 removed in Robot capabilities on page 57 • Adjustment of the FlexTrack using a laser tracker updated in Instruction on page 75 • Expected life of cables updated in Expected life on page 122 • Limits for expected life of cable chains updated in Expected life on page 122 • Additional Function Support added in Additional Safety Function Support on page 115 • Added material disposing symbol and related description in Environmental information on page 188. • Re-described the method of geometric alignment, and removed the table in Geometric alignment of FlexTrack IRT 501 on page 75 • Replace the paint related reference manual to SafeMove2.
D	<p>Changes made in:</p> <ul style="list-style-type: none"> • Removed grease KLÜBER Microlube GB0 and added grease Shell Gadus S2 V220 00. • Updated the supplier information of linear rails. See Linear rail of different supplier on page 148. • Added information of six bearings 90RE variant. • Added information of six bearings 90RS variant. • Updated specification information. • Minor updates from product manual to product specification.
E	<p>Changes made in:</p> <ul style="list-style-type: none"> • Updated specification information. • Minor updates from product manual to product specification.

Product documentation, M2004

Categories for manipulator documentation

The manipulator documentation is divided into a number of categories. This listing is based on the type of information in the documents, regardless of whether the products are standard or optional.

All documents listed can be ordered from ABB on a DVD. The documents listed are valid for M2004 manipulator systems.

Product manuals

All hardware, manipulators and controllers will be delivered with a **Product manual** that contains:

- Safety information.
 - Installation and commissioning (descriptions of mechanical installation, electrical connections).
 - Maintenance (descriptions of all required preventive maintenance procedures including intervals).
 - Repair (descriptions of all recommended repair procedures including spare parts).
 - Additional procedures, if any (calibration, decommissioning).
 - Reference information (article numbers for documentation referred to in Product manual, procedures, lists of tools, safety standards).
 - Parts list.
 - Foldouts or exploded views.
 - Circuit diagrams (or references to circuit diagrams).
-

Technical reference manuals

The technical reference manuals describe the manipulator software in general and contain relevant reference information.

- **RAPID Overview:** An overview of the RAPID programming language.
 - **RAPID Instructions, Functions and Data types:** Description and syntax for all RAPID instructions, functions, and data types.
 - **RAPID Kernel:** A formal description of the RAPID programming language.
 - **System parameters:** Description of system parameters and configuration workflows.
-

Application manuals

Specific applications (for example software or hardware options) are described in **Application manuals**. An application manual can describe one or several applications.

An application manual generally contains information about:

- The purpose of the application (what it does and when it is useful).
- What is included (for example cables, I/O boards, RAPID instructions, system parameters, CD with PC software).

Continues on next page

- How to use the application.
- Examples of how to use the application.

Operating manuals

The operating manuals describe hands-on handling of the products. The manuals are aimed at those having first-hand operational contact with the product, that is production cell operators, programmers, and trouble shooters.

The group of manuals includes:

- **Emergency safety information**
- **General safety information**
- **Getting started, IRC5 and RobotStudio**
- **IRC5 with FlexPendant**
- **RobotStudio**
- **Introduction to RAPID**
- **Trouble shooting, for the controller and manipulator.**

How to read the product manual

Reading the procedures

The procedures contain references to figures, tools, material etc. The references are read as described below.

References to figures

The procedures often include references to components or attachment points located on the robot/controller. The components or attachment points are marked with italic text in the procedures and completed with a reference to the figure where the current component or attachment point is shown.

The denomination in the procedure for the component or attachment point corresponds to the denomination in the referenced figure.

The table below shows an example of a reference to a figure from a step in a procedure.

	Action	Note/Illustration
8	Remove the rear attachment screws, gearbox.	Shown in the figure <i>FlexTrack Carriage Overview on page 50</i> .

Reference to required equipment

The procedures often include references to equipment (spare parts, tools etc.) required for the different actions in the procedure. The equipment is marked with italic text in the procedures and completed with a reference to the section where the equipment is listed with further information, i.e. article number, dimension.

The denomination in the procedure for the component or attachment point corresponds to the denomination in the referenced list.

The table below shows an example of a reference to a list of required equipment, from a step in a procedure.

	Action	Note
3	Fit a new sealing, axis 2 to the gearbox.	Art. no. is specified in <i>Required equipment on page 64</i> .

Safety information

The manual includes a separate safety chapter that must be read through before proceeding with any service or installation procedures. All procedures also include specific safety information when dangerous steps are to be performed.

Read more in *Safety on page 15*.

1 Safety

1.1 Introduction

Overview

The safety information in this manual is divided in two categories:

- general safety aspects, important to attend to before performing any service work on the robot. These are applicable for all service work and are found in [General safety information on page 16](#)
- specific safety information, pointed out in the procedure at the moment of the danger. How to avoid and eliminate the danger is either detailed directly in the procedure, or further detailed in separate instructions, found in [Safety related instructions on page 31](#).

1 Safety

1.2.1 Safety in the robot system

1.2 General safety information

1.2.1 Safety in the robot system

Validity and responsibility

The information does not cover how to design, install and operate a complete system, nor does it cover all peripheral equipment, which can influence the safety of the total system. To protect personnel, the complete system must be designed and installed in accordance with the safety requirements set forth in the standards and regulations of the country where the robot is installed.

The users of ABB industrial robots are responsible for ensuring that the applicable safety laws and regulations in the country concerned are observed and that the safety devices necessary to protect people working with the robot system are designed and installed correctly. Personnel working with robots must be familiar with the operation and handling of the industrial robot, described in the applicable documents, e.g. User's Guide and Product Manual.

Connection of external safety devices

Apart from the built-in safety functions, the robot is also supplied with an interface for the connection of external safety devices. Via this interface, an external safety function can interact with other machines and peripheral equipment. This means that control signals can act on safety signals received from the peripheral equipment as well as from the robot.

Limitation of liability

Any information given in this manual regarding safety, must not be construed as a warranty by ABB that the industrial robot will not cause injury or damage even if all safety instructions are complied with.

Related information

Type of information	Detailed in document	Section
Installation of safety devices	Product manual for the robot	Installation and commissioning
Changing robot modes	Operators manual (RobotWare 5.0)	Operating modes
Restricting the working space	Product manual for the robot	Installation and commissioning

1.3 Safety risks

1.3.1 Safety risks during installation and service work on robot

Overview

This section includes information of general safety risks to be considered when performing installation and service work on the robot.

General risks during installation and service

- The instructions in the Product Manual - Installation and Commissioning must always be followed.
- Emergency stop buttons must be positioned in easily accessible places so that the robot can be stopped quickly.
- Those in charge of operations must make sure that safety instructions are available for the installation in question.
- Those who install the robot must have the appropriate training for the robot system in question and in any safety matters associated with it.

Nation/region specific regulations

To prevent injuries and damage during the installation of the robot system, the regulations applicable in the country concerned and the instructions of ABB robotics must be complied with.

Non-voltage related risks

- Safety zones, which have to be crossed before admittance, must be set up in front of the robot's working space. Light beams or sensitive mats are suitable devices.
- Turntables or the like should be used to keep the operator out of the robot's working space.
- The axes are affected by the force of gravity when the brakes are released. In addition to the risk of being hit by moving robot parts, you run the risk of being crushed by the parallel arm.
- Energy, stored in the robot for the purpose of counterbalancing certain axes, may be released if the robot, or parts thereof, are dismantled.
- When dismantling/assembling mechanical units, watch out for falling objects.
- Be aware of stored heat energy in the controller.
- Never use the robot as a ladder, i.e. do not climb on the robot motors or other part during service work. There is a serious risk of slipping because of the high temperature of the motors or oil spills that can occur on the robot.

To be observed by the supplier of the complete system

- The supplier of the complete system must ensure that all circuits used in the safety function are interlocked in accordance with the applicable standards for that function.

Continues on next page

1 Safety

1.3.1 Safety risks during installation and service work on robot

Continued

- The supplier of the complete system must ensure that all circuits used in the emergency stop function are interlocked in a safe manner, in accordance with the applicable standards for the emergency stop function.

Complete robot

Safety risk	Description
Hot components! Removed parts may result in collapse of robot!	 CAUTION Motors and gearboxes are HOT after running the robot! Touching the motors and gearboxes may result in burns!  WARNING Take any necessary measures to ensure that the robot does not collapse as parts are removed, e.g. secure the lower arm with fixtures if removing motor, axis 2.

Cabling

Safety risk	Description
Cable packs are sensitive to mechanical damage!	 CAUTION The cable packs are sensitive to mechanical damage! They must be handled with care, especially the connectors, in order to avoid damaging them!

Gearboxes and motors

Safety risk	Description
Gears may be damaged if excessive force is used!	 CAUTION Whenever parting/mating motor and gearbox, the gearboxes may be damaged if excessive force is used!

1.3.2 Safety risks related to tools/workpieces

Safe handling

It must be possible to safely turn off tools, such as milling cutters, etc. Make sure that guards remain closed until the cutters stop rotating.

It should be possible to release parts by manual operation (valves).

Safe design

Grippers/end effectors must be designed so that they retain workpieces in the event of a power failure or a disturbance of the controller.



CAUTION

Ensure that a gripper is prevented from dropping a workpiece, if such is used.

1 Safety

1.3.3 Safety risks related to pneumatic/hydraulic systems

1.3.3 Safety risks related to pneumatic/hydraulic systems

General

Special safety regulations apply to pneumatic and hydraulic systems.

Residual energy

- Residual energy may be present in these systems. After shutdown, particular care must be taken.
 - The pressure in pneumatic and hydraulic systems must be released before starting to repair them.
-

Safe design

- Gravity may cause any parts or objects held by these systems to drop.
- Dump valves should be used in case of emergency.
- Shot bolts should be used to prevent tools, etc., from falling due to gravity.

1.3.4 Safety risks during operational disturbances

General

- The industrial robot is a flexible tool which can be used in many different industrial applications.
- All work must be carried out professionally and in accordance with the applicable safety regulations.
- Care must be taken at all times.

Qualified personnel

- Corrective maintenance must only be carried out by qualified personnel who are familiar with the entire installation as well as the special risks associated with its different parts.

Extraordinary risks

If the working process is interrupted, extra care must be taken due to risks other than those associated with regular operation. Such an interruption may have to be rectified manually.

1 Safety

1.3.5 Risks associated with live electric parts

1.3.5 Risks associated with live electric parts

Voltage related risks, general

- Although troubleshooting may, on occasion, have to be carried out while the power supply is turned on, the robot must be turned off (by setting the mains switch to OFF) when repairing faults, disconnecting electric leads and disconnecting or connecting units.
- The mains supply to the robot must be connected in such a way that it can be turned off outside the robot's working space.

Voltage related risks, controller IRC5

A danger of high voltage is associated with the following parts:

- Be aware of stored electrical energy (DC link, Ultra Cap unit) in the controller.
- Units inside the controller, e.g. I/O modules, can be supplied with power from an external source.
- The mains supply/mains switch
- The transformers
- The power unit
- The control power supply (230 VAC)
- The rectifier unit (400-480 VAC and 700 VDC. Note: Capacitors!)
- The drive unit (700 VDC)
- The drive system power supply (230 VAC)
- The service outlets (115/230 VAC)
- The customer power supply (230 VAC)
- The power supply unit for tools, or special power supply units for the machining process.
- The external voltage connected to the control cabinet remains live even when the robot is disconnected from the mains.
- Additional connections.

Voltage related risks, robot

A danger of high voltage is associated with the robot in:

- The power supply for the motors (up to 800 VDC).
- The user connections for tools or other parts of the installation (max. 230 VAC, see chapter Installation and commissioning in the Product manual).

Voltage related risks, tools, material handling devices, etc.

Tools, material handling devices, etc., may be live even if the robot system is in the OFF position. Power supply cables which are in motion during the working process may be damaged.

1.4 Safety actions

1.4.1 Safety fence dimensions

General

Install a safety cell around the robot to ensure safe robot installation and operation.

Dimensioning

Dimension the fence or enclosure to enable it to withstand the force created if the load being handled by the robot is dropped or released at maximum speed.

Determine the maximum speed from the maximum velocities of the robot axes and from the position at which the robot is working in the work cell (see *Product Specification - Description, Robot Motion*).

Also consider the maximum possible impact caused by a breaking or malfunctioning rotating tool or other device fitted to the manipulator.

1 Safety

1.4.2 Fire extinguishing

1.4.2 Fire extinguishing



Note

Use a CARBON DIOXIDE (CO₂) extinguisher in the event of a fire in the robot (manipulator or controller)!

1.4.3 Emergency release of the robots/manipulators axes

Description

In an emergency situation, any of the robot's/manipulators axes may be released manually by pushing the brake release buttons on the robot.

How to release the brakes is detailed in section:

- [Moving the carriage manually on page 54](#). The robot arm may be moved manually on smaller robot models, but larger models may require using an overhead crane or similar.

Increased injury

Before releasing the brakes, make sure that the weight of the arms does not increase the pressure on the trapped person, further increasing any injury!

1 Safety

1.4.4 Brake testing

1.4.4 Brake testing

When to test

During operation the holding brakes of each axis motor wear normally. A test may be performed to determine whether the brake can still perform its function.

How to test

The function of each axis' motor holding brakes may be checked as detailed below:

	Action
1	Run each manipulator axis to a position where the combined weight of the manipulator arm and any load is maximized (max. static load).
2	Switch the motor to the MOTORS OFF position with the Operating mode selector on the controller.
3	Check that the axis maintains its position.

If the manipulator does not change position as the motors are switched off, then the brake function is adequate.

1.4.5 Risk of disabling function "Reduced speed 250 mm/s"



Note

Do not change *Transm. gearbox ratio* or other kinematic parameters from the Teach Pendant Unit or a PC. This will affect the safety function Reduced speed 250 mm/s.

1.4.6 Safe use of the Teach Pendant Unit



Note

The enabling device is a push button located on the side of the Teach Pendant Unit (TPU) which, when pressed halfway in, takes the system to MOTORS ON. When the enabling device is released or pushed all the way in, the robot is taken to the MOTORS OFF state. To ensure safe use of the Teach Pendant Unit, the following must be implemented:

- The enabling device must never be rendered inoperative in any way.
- During programming and testing, the enabling device must be released as soon as there is no need for the robot to move.
- The programmer must always bring the Teach Pendant Unit with him/her, when entering the robot's working space. This is to prevent anyone else taking control of the robot without the programmer knowing.

1.4.7 Work inside the manipulator's working range



WARNING

If work must be carried out within the robot's work envelope, the following points must be observed:

- The operating mode selector on the controller must be in the manual mode position to render the enabling device operative and to block operation from a computer link or remote control panel.
- The robot's speed is limited to max. 250 mm/s when the operating mode selector is in position < 250 mm/s. This should be the normal position when entering the working space. The position 100% "full speed" may only be used by trained personnel who are aware of the risks that this entails.
- Pay attention to the rotating axes of the manipulator! Keep a distance to the axes in order not to get entangled with hair or clothing. Also be aware of any danger that may be caused by rotating tools or other devices mounted on the manipulator or inside the cell.

1 Safety

1.4.8 Translate the information on safety and information labels

1.4.8 Translate the information on safety and information labels

Labels on the product

Both the manipulator and the controller are marked with several safety and information labels, containing important information about the product. The information is useful for all personnel handling the robot system, e.g. during installation, service or operation.

Translation possibilities


The labels fitted to the product contain space for adding a fourth language underneath the three standard languages (English, German and French).

Add a local language to the label by:

- Using a transparent sticker over the standard label with text added in a fourth language. Drawings detailing the design (text, figure, dimensions) of the standard labels can be ordered from ABB. Notice that each label is identified according to the article number located in the lower corner of the label.

Example of transparent sticker

The figure below shows the location of the free space on one of the labels on the robot, where the fourth language can be added. The figure also shows a transparent sticker, containing the text in Swedish.



xx1800002085

A	Free space for adding a fourth language
---	---

1.5 Safety related instructions

1.5.1 Safety signals, general

General

This section specifies all dangers that may arise from performing the work detailed in the manual. Each danger is detailed in its own section consisting of:

- A caption specifying the danger level (DANGER, WARNING or CAUTION) and the type of danger.
- A brief description of what will happen if the operator/service personnel do not eliminate the danger.
- An instruction of how to eliminate the danger to facilitate performing the activity at hand.

The table below defines the captions specifying the danger levels used throughout this manual.

Symbol	Designation	Significance
	DANGER	Warns that an accident <i>will</i> occur if the instructions are not followed, resulting in a serious or fatal injury and/or severe damage to the product. It applies to warnings that apply to danger with, for example, contact with high voltage electrical units, explosion or fire risk, risk of poisonous gases, risk of crushing, impact, fall from height etc.
	WARNING	Warns that an accident <i>may</i> occur if the instructions are not followed, that can lead to serious injury, possibly fatal, and/or great damage to the product. It applies to warnings that apply to danger with, for example, contact with high voltage electrical units, explosion or fire risk, risk of poisonous gases, risk of crushing, impact, fall from height etc.
	ELECTRICAL SHOCK	The electrocution or electrical shock symbol indicates electrical hazards which could result in severe personal injury or death.
	CAUTION	Warns that an accident may occur if the instructions are not followed that can result in injury and/or damage to the product. It also applies to warnings of risks that include burns, eye injury, skin injury, hearing damage, crushing or slipping, tripping, impact, fall from height, etc. Furthermore, it applies to warnings that include function requirements when fitting and removing equipment, where there is a risk of damaging the product or causing a breakdown.
	ELECTROSTATIC DISCHARGE (ESD)	The electrostatic discharge (ESD) symbol indicates electrostatic hazards which could result in severe damage to the product.

Continues on next page

1 Safety

1.5.1 Safety signals, general

Continued

Symbol	Designation	Significance
	NOTE	Note symbols alert you to important facts and conditions.
	TIP	Tip symbols direct you to specific instructions, where to find additional information or how to perform a certain operation in an easier way.

1.5.2 DANGER - Moving manipulators are potentially lethal!

1.5.2 DANGER - Moving manipulators are potentially lethal!

Description

Any moving manipulator is a potentially lethal machine.

When running the manipulator, it may perform unexpected and sometimes irrational movements. However, all movements are performed with great force and may seriously injure any personnel and/or damage any piece of equipment located within the manipulator working range.

Elimination

	Action	Note/Illustration
1	Before attempting to run the manipulator, make sure all emergency stop equipment is correctly installed and connected.	Emergency stop equipment such as gates, tread mats, light curtains, etc.
2	If possible, use the hold-to-run button whenever possible. The hold-to-run button is used in manual mode, not in automatic mode.	How to use the hold-to-run control in RobotWare 5.0 is detailed in section How to use the hold-to-run function in the <i>Operating manual - IRC5 with FlexPendant</i>
3	Make sure no personnel are present within the manipulator working range before pressing the start button.	

1 Safety

1.5.3 DANGER - First test run may cause injury or damage!

1.5.3 DANGER - First test run may cause injury or damage!

Description

Since performing a service activity often requires disassembly of the robot there are several safety risks to take into consideration before the first test run.

Elimination

Follow the procedure below when performing the first test run after a service activity (repair, installation or maintenance):

	Action
1	Remove all service tools and foreign objects from the robot and its working area!
2	Install all safety equipment properly!
3	Make sure all personnel are standing at a safe distance from the robot, i.e. out of its reach behind safety fences, etc.!
4	Pay special attention to the function of the part previously serviced!

1.5.4 WARNING - The unit is sensitive to ESD!

Description


ESD (electro static discharge) is the transfer of electrical static charge between two bodies at different potentials, either through direct contact or through an induced electrical field. When handling parts or their containers, personnel not grounded may potentially transfer high static charges. This discharge may destroy sensitive electronics.

Elimination

	Action	Note
1	Use a wrist strap	Wrist straps must be tested frequently to ensure that they are not damaged and are operating correctly.
2	Use an ESD protective floor mat.	The mat must be grounded through a current-limiting resistor.
3	Use a dissipative table mat.	The mat should provide a controlled discharge of static voltages and must be grounded.

Location of wrist strap button

The wrist strap button is located in the top right corner as shown in the illustration below.



xx1800002086

A	Wrist strap button
---	--------------------

1 Safety

1.5.5 WARNING - Safety risks during work with gearbox oil

1.5.5 WARNING - Safety risks during work with gearbox oil

Description


When handling the gearbox oil, there are several dangers to both personal injuries and product damages! Following safety information must be regarded before performing any work with the oil in the gearboxes!

Warning and elimination


Warning	Description	Elimination/Action
 Hot oil!	Changing and draining gearbox oil may require handling hot oil of up to 90 °C!	Make sure that protective gearbox like goggles and gloves are always worn during this activity.
 Possible pressure build in gearbox	When opening the oil plug, there may be pressure present in the gearbox, causing oil to spray from the opening!	Open oil plug carefully and keep away from the opening. Do not overfill the gearbox when filling.
 Don not overfill!	Overfilling of gearbox oil can lead to internal over-pressure inside the gearbox which in turn may: damage seals and gaskets completely press out seals and gaskets prevent the manipulator from moving freely.	Make sure not to overfill the gearbox when filling with oil! After filling, check the correct oil level.
 Do not mix types of oil!	Mixing types of oil may cause severe damage to the gearbox!	When filling gearbox oil, do not mix different types of oil unless specified in the instruction. Always use the type of oil specified by the manufacturer!
 Heat up the oil!	Warm oil drains quicker than cold oil.	When changing gearbox oil, first run the robot for a time to heat up the oil.
 Specified amount depends on drained volume!	The specified amount of oil is based on the total volume of the gearbox. When changing the oil, the amount of refilled oil may differ from the specified amount, depending on how much oil has previously been drained from the gearbox.	After refilling, check the oil level.

1.5.6 Location of safety pictograms

Location of safety pictograms



xx1800002087

Symbol	Description	Position
 <p>xx1800002100</p>	<p>DANGER! Risk of severe injury to hands! This pictogram must be positioned close to the timing mark.</p>	 <p>xx1800002088</p>

This page is intentionally left blank

2 Installation and commissioning

2.1 Introduction

General

The FlexTrack IRT 501-66 /66R /90 /90R includes one or more carriages moving on a modular track made of crossmembers, sidemembers, rack, and covers. This unit can be either installed on a concrete floor, or on a FlexiCell platform.

For detailed information regarding mechanical installation requirement for concrete floor and FlexiCell platform, see [Preparation for setup on page 95](#).

Protection standards

Standard FlexTrack IP54.

Explosive environments

The FlexTrack must not be located or operated in an explosive environment.

Terminology

Designation	Definition
Robotic system	The robot and the FlexTrack.
Robot	The manipulator and the controller.
Manipulator	The 6 axis mechanical unit of the robot.
Controller	The motion system used to control the manipulator & FlexTrack (i.e. ABB IRC5).
Translation unit	The complete carriage assembly including all moving parts (cable track, lubrication system, sensors, and so on).
Carriage	The moving part of the FlexTrack. The top plate receives the tooling / robot.
Track	The static part of the FlexTrack. The track is delivered as modules to be assembled by the customer, as described in Assembly of the track on page 64 .
Travel length	Maximum stroke of the carriage.
SMB Box	The Serial Measurement Board Box, a control box which includes the SMB card for the FlexTrack axis as well as the resolver position backup battery.
SMB	The Serial Measurement Board is a integrated circuit board used to measure and store the position of each robot axes.
Recirculating ball bearing linear guide system	Is the system of both the linear rail and the ball bearing blocks which achieve high precision linear motion.
Linear rail	Is the lubricated rail (steel beam) on which the ball bearing block slides.
Ball bearing block	Is the sliding block which translates on the linear rail. Also known as linear block or linear guide block. The ball bearing block contains the recirculating balls which roll on the linear rail.

Continues on next page

2 Installation and commissioning

2.1 Introduction

Continued

Description	Standard/Option	Temperature
FlexTrack during operation	Standard	+ 5 °C (41 °F) to + 50 °C (122 °F)
For the controller	Standard	+ 5 °C (41 °F) to + 45 °C (113 °F)
For the controller	Option	+5 °C (41 °F) to + 52 °C (126 °F)
For short periods (not exceeding 24 hours)	Standard	up to + 70 °C (158 °F)

Relative humidity

Description	Relative humidity
Complete track during transportation and storage	Max. 95% at constant temperature
Complete track during operation	Max. 95% at constant temperature

Preparations

The following steps should be carried out before starting the FlexTrack IRT 501.

	Action	Note
1	Unpacking and acceptance.	Compare the delivery check to the identification plate and verify for acceptance according to Acceptance inspection on page 42 .
2	Lifting.	Lifting FlexTrack IRT 501 using lifting slings, see Acceptance inspection on page 42 .
3	Preparation for assembly.	
4	Assemble the track.	
5	Assemble the manipulator.	
6	Electrical installation.	
7	Software installation.	

2.2 Unpacking and acceptance

2.2.1 Unpacking

Inspection

The FlexTrack IRT 501 is wrapped in plastic. Unpack the track and check for any visible transport damage. If the FlexTrack IRT 501 is damaged, contact ABB.

Contents

If the complete track contains more than 5 modules, it would be separated to more than 1 sections for packing's convenience. As standard the FlexTrack IRT 501 includes the following on delivery (not including options):

- One or more preassembled track sections, depending on the complete track length. The carriage is mounted on one track section no less than 2 m long.
- Cable chain. The cable chain has been preassembled on the track when delivered.
- Memolub auto lubrication system. The Memolub auto lubrication system has been installed on the carriage and preset when delivered, but it is not yet activated.

Cleaning

Before transport the FlexTrack IRT 501 has been protected against rust by a thin film of oil that has been applied before packing. This film of oil must be wiped off before installation, at the exception of the pre-lubricated parts such as the rack and the linear rails.



Note

Wipe off any surplus oil using a lint-free cloth.

2 Installation and commissioning

2.2.2 Acceptance inspection

2.2.2 Acceptance inspection



Tip

Always try to determine if the goods are as ordered, and that the package is not damaged before unpacking the complete track.

Identification plate

To identify the delivery, check the identification plate and compare it to the delivery note.

The identification plate is located on the carriage side (see figure below) and indicates the FlexTrack type, the serial number and the weight of the complete track.




ABB	
Drawing number	<input type="text"/>
Serial number	<input type="text"/>
Weight	<input type="text"/>

xx1800002093

2.3 Handling

2.3.1 Lifting FlexTrack IRT 501

Action before lifting



CAUTION

Read through the safety instructions carefully, before the FlexTrack IRT 501 is installed.



WARNING

After assembly, the FlexTrack IRT 501 must not be handled using a forklift truck or a crane.

Handling equipment for FlexTrack modules without a mounted carriage

Type	Recommended equipment
IRT 501 - 66 and 90	4 U-shackles (shackle has to fit into the bail)  xx1800002090
	4 Lifting I-bolts with a M12 thread  xx1800002091
	2 lifting straps (min. 5 m) with a load capacity of 1 tonne each
IRT 501 - 66 and 90	2 lifting straps (min. 5 m) with a load capacity of 1 tonne each

Continues on next page


2 Installation and commissioning

2.3.1 Lifting FlexTrack IRT 501

Continued

Lifting FlexTrack IRT 501 - 66 and 90 without a mounted carriage


Unmount all covers and screw the I-bolt in the outer holes located between the crossmembers and connect the shackle with the I-bolts.



xx1800002092


In the following step one end of a lifting strap should be guided through the shackle, below the sidemembers at both sides and through the second shackle. The second strap should be used for the other side.

The shackle should act as a guidance only to prevent the straps from slipping. The weight of the FlexTrack should be carried by the sidemembers.



xx1800002094


Continues on next page



xx1800002095

Lifting FlexTrack IRT 501 - 66R and 90R without a mounted carriage

The lifting strap should be guided behind the second to last crossmembers below the sidemembers at both sides and through the second shackle. The second strap should be used for the other side.




xx1800002096

Continues on next page

2 Installation and commissioning

2.3.1 Lifting FlexTrack IRT 501

Continued



xx1800002097



WARNING


Never place lifting straps wider than a combined angle of max. 60°.

Never lift a track longer than 3 m at once. If the track is longer, the track has to be disassembled into smaller sections.

Lifting FlexTrack with a lifting beam

If there is a lifting beam available, the strap should always be located at the middle of the sidemembers.

The picture shows 66 / 90 with a length of 3 m.




xx1800002098

Continues on next page

Lifting 2 m FlexTrack with carriage

The carriage comes assembled on a 2 m track section which can be handled using appropriate straps and M24 handling I-bolts.



xx2000002543

2 Installation and commissioning

2.3.2 Lifting weight

2.3.2 Lifting weight

FlexTrack IRT 501 weight

For accurate weight of the whole track, read the identification plates on the FlexTrack IRT 501. The position of the identification plates are described in [Identification plate on page 42](#).

The weight of the FlexTrack depends on its type, length, and number of carriages. The total weight can be determined with the following formulas:

Type	Weight (kg)
IRT 501-66	$W = 595 + M \times 195 + C \times 327$
IRT 501-66R	$W = 637 + M \times 237 + C \times 327$
IRT 501-90	$W = 710 + M \times 222 + C \times 393$
IRT 501-90R	$W = 752 + M \times 264 + C \times 393$
IRT 501-90RE/RS	$W = 805 + M \times 264 + C \times 446$


with:

M = Number of modules

C = Number of additional carriages (first carriage already included, C = 0 if only one carriage)

2.3.3 FlexTrack IRT 501 size and dimensions

FlexTrack overview



xx1800001861

A	Cross member
B	Levelling screw
C	Side member
D	Linear rail
E	Cover bracket
F	Rack cover
G	Cover
H	End cover
J	Cable chain
K	Carriage
L	Rack

Continues on next page


2 Installation and commissioning

2.3.3 FlexTrack IRT 501 size and dimensions

Continued

FlexTrack Carriage Overview

With four bearings



xx1800001862

A	Top plate
B	Side cover
C	3 carriage bracket 1 carriage bracket with gearbox motor support
D	Ball bearing block
E	Gearbox
F	Motor


Continues on next page

2 Installation and commissioning

2.3.3 FlexTrack IRT 501 size and dimensions

Continued

With six bearings



xx2000002590

A	Top plate
B	Side cover
C	5 carriage bracket
	1 carriage bracket with gearbox motor support
D	Ball bearing block
E	Gearbox
F	Motor

Dimensions of the FlexTrack


Data	IRT 501-66	IRT 501-66R	IRT 501-90	IRT 501-90R/90RE/90RS
A	660	660	900	900
B	500	500	680	680
C	435	435	495	495
D	1050	525	1050	525
E	1150	1150	900	900
L	738+N×1050			

Continues on next page

2 Installation and commissioning

2.3.3 FlexTrack IRT 501 size and dimensions

Continued




xx1800001863

Standard top plate

For material handling applications with FlexTrack, six M12 holes are prepared for fastening of the fixture on top, two $\text{\O}10$ d dowels for the locating.

The opening in the middle of the plate is for easy access to the motor connection box.


Dimensions for IRT501-66 / IRT501-66R



xx1800001864

Continues on next page

Dimensions for IRT501-90 / IRT501-90R / IRT501-90RE / IRT501-90RS



xx1800001865

Robot Plate

Robot plates exist for various robot models and their bolting patterns match that of the robot.

2 Installation and commissioning

2.3.4 Moving the carriage manually

2.3.4 Moving the carriage manually

Release the brake

The carriage can be pushed manually to another position on the track.

It is recommended that the carriage is manually pushed along its complete stroke after being installed and before running the track using the IRC5. This is to ensure that there is no risk of collision other equipment in the vicinity of the track.

	Action	Note/Illustration
1	Connect all cables to the controller as described in Cables connections on page 88 .	
2	Start up the controller as described in Connectors on IRC5 controller on page 90 on page.	
3	Press in the brake release button (A) shows in the figure.	 xx1800001866 Release the brake
4	Push the carriage by hand to the desired location.	

Continues on next page




Note

Care should be taken when moving the track manually. There is a risk of severe injury to hands near the calibration pin, as well as at the location where the rack and pinion mesh.

Users should remain clear of these locations when moving the track.



xx1800001868



xx1800001867

Release the brake (external 24V DC)

If there is no voltage to the motor, 24V DC can be connected direct to the SMB box.


	Action
1	Unplug the Motor power cable from the SMB box that runs to the FlexTrack motor.
2	Using pins, connect the +24VCC to the G pin (see fig).
3	Connect the 0VCC to the H pin

Continues on next page

2 Installation and commissioning

2.3.4 Moving the carriage manually

Continued



xx1800001869



Note

Painting: Half black color. Except the mounting surface.



Note

Mating connectors are not offered.

Motor Connection


PIN	FUNCTION
A	—
B	W-phase
C	—
D	—
E	Frame GND
F	U-phase
G	(brake)
H	(brake)
I	V-phase

Encoder Connection

PIN No.	FUNCTION	PIN No.	FUNCTION
A	NC	K	NC
B	NC	L	NC
C	NC	M	NC
D	NC	N	NC
E	SD	P	NC
F	SD	R	NC
G	GND	S	GND
H	VCC	T	VB
J	CASE GND		


(In case of 17/33bit abs.encoder)

MOTOR



View D-D'

ENCODER



View F-F'

xx1800001870



WARNING

The motor breaks on the FlexTrack IRT 501 are phase dependent. Fault connection can cause damage to vital parts.

2.4 Preparations for assembly

2.4.1 Foundation

Robustness

The foundation must with stand the static loads caused by the weight of the equipment and the dynamic loads generated by the movement of the carriage and the manipulator. The minimum thickness of the concrete floor is 175 mm.

The concrete quality class must be at least C20/25 (or B25) to insure a good resistance of the anchor. Class C30/37 (or B35) is advisable.

The concrete compressive strength can be tested according to the European norm EN 206-1.

When FlexTrack is mounted on the steel platform of FlexiCell, M16x40 class 12.9 screws and DIN6796 M16 washers are required, and pre-tightening torque is 280 Nm. Depth of thread must be min. 25 mm. Notice that it **MUST** do tightening for chemical screw again after tightening this M16x40 screw. For the pre-tightening torque, see [Recommendation for anchors on page 60](#).

Inclination and flatness

The levelling of the track is done by screwing / unscrewing the M60 screws. However, in order to insure a good levelling, the concrete floor inclination must not exceed 1mm / meter in the translation direction, and 0.5mm / meter cross section. The levelling screws can also compensate a poor flatness of the slab and small bumps up to 10 mm. However, the surface under the levelling screw must be flat. A concrete surfacing grinder should be used to correct the flatness locally if necessary.

Static loads

The following table shows the maximum payload of all FlexTrack carriage variants, and the corresponding load distributed to each levelling screw.

Load	IRT 501-66	IRT 501-66R	IRT 501-90	IRT 501-90R/90RE/90RS
Max. Load	900 kg	2,000 kg	2,000 kg	3,000 kg
Load on each levelling screw	320 kg	450 kg	800 kg	1,050 kg



Note

The payloads listed above are estimated for a wide range of FlexTrack applications. For ModulFlex payload, please refer to ModulFlex specifications. For higher weight of transfer application, please contact ABB.

Robot capabilities

The following table shows the robot capabilities of the FlexTrack.

Continues on next page

2 Installation and commissioning

2.4.1 Foundation

Continued

Standard risers are generally allowed between the FlexTrack carriage and the robot but their height is limited and dependent on the type of FlexTrack and the type of robot.



Note

If the riser is too high, it may vibrate.

For higher riser application, please contact ABB.

Robot	IRT 501-66	IRT 501-66R	IRT 501-90	IRT 501-90R	IRT 501-90RE	IRT 501-90RS
IRB 1410	✓ Riser 1,000 mm max	✓ Riser 1,000 mm max	X	X	X	X
IRB 1600	✓ Riser 1,000 mm max	✓ Riser 1,000 mm max	X	X	X	X
IRB 52	✓ Riser 1,000 mm max	✓ Riser 1,000 mm max	X	X	X	X
IRB 2400/2600	✓ Riser 1,000 mm max	✓ Riser 1,000 mm max	X	X	X	X
IRB 4400	X	X	✓ Riser 1,000 mm max			
IRB 4600	X	X	✓ Riser 1,000 mm max			
IRB 460	X	✓ Riser 500 mm max	✓ Riser 500 mm max	✓ Riser 1,000 mm max	✓ Riser 1,000 mm max	✓ Riser 1,000 mm max
IRB 6620/6640	X	X	✓ No riser allowed	✓ Riser 500 mm max	✓ Riser 500 mm max	✓ Riser 500 mm max
IRB 6700-200/2.6-235/2.65-205/2.8-155/2.85-175/3.05-150/3.2	X	X	✓ No riser allowed	✓ Riser 500 mm max	✓ Riser 500 mm max	✓ Riser 500 mm max
IRB 6700-300/3.7-245/3.0	X	X	X	X	✓ Riser 500 mm max	✓ Riser 500 mm max
IRB 660	X	X	X	X	✓ Riser 250 mm max	✓ Riser 250 mm max
IRB 6650	X	X	X	X	✓ No riser allowed	✓ No riser allowed
IRB 6650S	X	X	X	X	✓ No riser allowed	✓ No riser allowed


Continues on next page

2 Installation and commissioning

2.4.1 Foundation Continued

Robot	IRT 501-66	IRT 501-66R	IRT 501-90	IRT 501-90R	IRT 501-90RE	IRT 501-90RS
IRB 760	X	X	X	X	✓ No riser allowed	✓ No riser allowed
IRB 7600	X	X	X	X	✓ No riser allowed	✓ No riser allowed

For these robots application, it is better to not put track on ground straightly, put one plate as interface surface to make it more stable.



xx200002591

2 Installation and commissioning

2.4.2 Recommendation for anchors

2.4.2 Recommendation for anchors

Recommended anchor

The recommended anchor bolts are HILTI M16x125 as shown below:

Anchor size	M8	M10	M12	M16	M20	M24	M27	M30
Foil capsule HVU2	8x80	10x90	12x110	16x125	20x170	24x210	27x240	30x270
Diameter of element $d_1=d_{nom}$ [mm]	8	10	12	16	20	24	27	30
Nom. diameter of drill d_0 [mm]	10	12	14	18	22	28	30	35
Eff. Embedment depth and drill hole in the fixture $h_{ef}=h_0$ [mm]	80	90	110	125	170	210	240	270
Max. diameter of clearance hole in the fixture d_f [mm]	9	12	14	18	22	26	30	33
Min. thickness of concrete member h_{min} [mm]	110	120	140	160	220	270	300	340
Max. torque moment ^{a)} T_{max} [Nm]	10	20	40	80	150	200	270	300

xx1800001873

Curing time

Temperature of the base material	Minimum curing time t_{cure}
-10 °C to -6 °C	5 hours
-5 °C to -1 °C	3 hours
0 °C to 4 °C	40 min
5 °C to 9 °C	20 min
10 °C to 19 °C	10 min
20 °C to 40 °C	5 min

xx2200001153



Note


It is recommended to use chemical anchors with M16 threaded rods to secure the unit to the floor. See [Recommendations for floor mounting on page 71](#).

Continues on next page

2 Installation and commissioning

2.4.2 Recommendation for anchors

Continued



xx1800001874


Continues on next page

2 Installation and commissioning

2.4.2 Recommendation for anchors

Continued

Section view of the FlexTrack anchor



xx1800001875

2.4.3 Screw joints

General

This section details how to tighten the various types of screw joints on the robot and the FlexTrack.

The instructions and torque values are valid for screw joints comprised of metallic materials and do not apply to soft or brittle materials.

Screw class

Class 12.9 screw is recommended by ABB for certain screw joints. These screws are high grade quality and extremely resistant to fatigue. Whenever used, this is specified in the instructions, and in such cases, no other type of replacement screw is allowed! Using other types of screws will void any warranty and may potentially cause serious damage or injury!

Loctite 243

A thread lock should be used on all screws that have a specified torque and only where stated. This is required to prevent the risk of the screw loosening due to vibrations over the lifetime of the product. Loctite 243 is the recommended thread lock and should be applied to the screws before assembly and tightening to their recommend torque.

Tightening torque

Before tightening any screw, note the following:

- Determine whether a standard tightening torque or special torque is to be applied. The standard torques is specified in the tables below. Any special torques is specified in the [Repair on page 147](#), [Maintenance on page 119](#) or Installation procedure description. Any special torque specified overrides the standard value.
- Use the *correct tightening torque* for each type of screw joint.
- Only use *correctly calibrated torque keys*.
- *Always tighten the joint by hand*, and never use pneumatic tools.

Use the *correct tightening technique*, i.e. do not jerk. Tighten the screw in a slow, flowing motion.

- Maximum allowed total deviation from the specified value is 10%!

The table below specifies the recommended standard tightening torque for class 12.9 screws.

Dimension	Tightening torque (Nm) Class 12.9
M6	16.4
M8	40
M10	79
M12	136

2 Installation and commissioning

2.5.1 Procedure of assembly

2.5 Assembly of the track


2.5.1 Procedure of assembly

General

The FlexTrack IRT 501 should be assembled as set out in the procedure below. Detailed descriptions of each stage can be found in the following sections.

Required equipment


Qty	Tool	
1	Ring-open-end spanner 8-22 mm	
1	Socket head cap 2.5 mm, 4 mm, 5 mm, 6 mm, 8 mm and 10 mm	
1	Small flat tip screwdriver	
1	Plastic mallet	
1	Torque wrench 10 Nm -140 Nm	
1	Ratchet head for torque wrench 1/2	
2	Socket head cap 5 mm, 8 mm, 10 mm socket 1/2" bit L 20 mm	
2	Hex head cap 13 mm, 19 mm socket 1/2"bit L 20 mm	

Qty	Specific FlexTrack tools	Picture
3	Rail Pressing Tool IRT501-66 & 66R: 3HAW107700358 IRT501-90 & 90R: 3HAW107700456	 xx1800001876
3	Rack clamps (3HAW107700357)	 xx1800001877

Continues on next page

2 Installation and commissioning

2.5.1 Procedure of assembly Continued

Qty	Specific FlexTrack tools	Picture
1	Rack Mounting block (3HAWL000011)	 xx1800001878
1	Leveling Tool (3HAW107700360)	 xx1800001879
1	Calibration pin (3HAW107700354)	 xx1800001880
1	Tool for levelling screw nut tightening (3HAW107700361)	 xx1800001881

Procedure of assembly

The following table describes all necessary steps to achieve a correct assembly of the IRT501 track:



	Action	Note/Illustration
1	Markup on a clean floor the FlexTrack axis. Markup also the position of each cross member, with the following intervals: IRT 501-66/90: 1,050 mm steps IRT 501-66R/90R/90RE/90RS: 525 mm steps	
2	Position the preassembled carriage & track section on the floor at the predetermined position.	

Continues on next page



2 Installation and commissioning

2.5.1 Procedure of assembly

Continued

	Action	Note/Illustration				
3	Linearly position the other preassembled section beside the section above.					
4	Connect the preassembled sections with screws not mounted.	 <p data-bbox="1029 555 1136 573">xx1800001882</p>				
5	Level the track module with the M60 screws. See Geometric alignment of FlexTrack IRT 501 on page 75 .  Note Ensure the geometric alignment of the FlexTrack with an optical level or a laser tracker. Note that, at this stage, you can only check the horizontal alignment based on the sidemember upper surface. The final alignment will be given by the measurements done based on the linear rails position.	 <p data-bbox="1029 913 1136 931">xx1800001883</p>				
6	Adjust the leveling screws until all leveling screws touch the ground.					
7	Slightly tighten screws connecting the sidemember and the crossmember.	 <p data-bbox="1029 1491 1136 1509">xx1800001884</p> <table border="1" data-bbox="1029 1532 1410 1621"> <tr> <td data-bbox="1029 1532 1070 1576">A</td> <td data-bbox="1070 1532 1410 1576">Sidemember</td> </tr> <tr> <td data-bbox="1029 1576 1070 1621">B</td> <td data-bbox="1070 1576 1410 1621">Crossmember</td> </tr> </table>	A	Sidemember	B	Crossmember
A	Sidemember					
B	Crossmember					

Continues on next page



	Action	Note/Illustration
8	<p>Visually check if the rails are seamlessly connected. If there is seam existed, push to adjust track sections and ensure that the gap of seam is 0.2 mm.</p> <p>The distance between the two adjacent side members should be approximately 2 mm.</p>	 <p>xx1800001885</p> <p>xx1800001886</p>
9	<p>When the levelling is satisfying, tighten all the screws connecting the sidemember and the crossmember after applying Loctite 243 on their thread.</p> <p>Tightening torque: 136 Nm</p>	
10	<p>Slightly tighten the rail screws and finalize the horizontal alignment of the FlexTrack as described in Geometric alignment of FlexTrack IRT 501 on page 75.</p> <p> Tip</p> <p>All linear rails are preassembled on track sections.</p> <p> Note</p> <p>Use the rail pressing tool to make sure that the rails are pushed against the side member mounting surface.</p>	 <p>xx1800001887</p>
11	<p>Unscrew one block from the carriage and use it to check the rails alignment: if the rails are correctly aligned, you should sense no “step” while passing the rails junction. If so then push downward the rail against the side member shoulder and verify the 0.2 mm gap between rails.</p>	 <p>xx1800001888</p>

Continues on next page

2 Installation and commissioning

2.5.1 Procedure of assembly




Continued

	Action	Note/Illustration
12	<p>When the alignment is correct, tighten the rail screws one by one, after applying Loctite 243 on their thread. (Tightening torque: 132 Nm)</p> <p>If necessary, re-assemble the block in the carriage bracket and tighten its 4 pcs hexagon socket head cap M10x30 class 12.9 screws and narrow contact-lock washers M10-16. (Tightening torque: 77 Nm)</p>	
13	<p>Use a brush to lubricate the linear rails.</p>	
14	<p>Assemble the rack by slightly tighten hexagon head M8x55 screws class 12.9 with contact-lock washers M8-18 and plain washers 8x25x3.</p> <p> Note</p> <p>Clean the sidemember mounting before installing the rack.</p> <p>Check that the chamfer is located in front of the side member step (check on preassembled section if you are not sure).</p> <p> Note</p> <p>Use the clamping and mounting racks at the ends of the rack section to make sure that the racks are pushed against the side member mounting surface and perfectly aligned with each other.</p>	 <p>xx1800001889</p>  <p>xx1800001890</p>  <p>xx1800001891</p>
15	<p>When the alignment is correct, tighten the screws one by one, after applying Loctite 243 on their thread (Tightening torque: 40 Nm). Use a brush to lubricate the racks.</p>	

Continues on next page

2 Installation and commissioning

2.5.1 Procedure of assembly Continued

	Action	Note/Illustration
16	Install the cable tray.	 <p>xx1800001892</p>
17	Install the cover brackets.	 <p>xx1800001893</p>
18	<p> CAUTION</p> <p>Release the carriage brake and push the carriage manually along the length of its stroke. Check that the cable chain lies in the centre of the track and does not collide with any other fixed parts. See section Release the brake on page 54 for instructions on how to release the motor brake.</p>	
19	Fix the small covers on top of the side members. Fix the large cover's brackets on the opposite side members.	 <p>xx1800001894</p>
20	Fix the large covers on top of the cover brackets.	 <p>xx1800001895</p>

Continues on next page

2 Installation and commissioning

2.5.1 Procedure of assembly

Continued

	Action	Note/Illustration
21	 CAUTION Once again, release the carriage brake and push the carriage manually along the length of its stroke. Check that there is no interference between the covers and the carriage.	

2.5.2 Recommendations for floor mounting

Mounting bolts

Choose mounting bolts so that they:

- Are suitable for the foundation.
- Can bear the dynamic loads.
- The bolts must be able to bear the combined dynamic loads that can occur when the manipulator and carriage move.

Securing the assembled track to the floor

	Action
1	After assembly, all the levelling screws should touch the floor. Adjust if necessary and tighten the locking nut.
2	Move the carriage all along the track way, and check the levelling with a levelling device or a laser tracker. The levelness of the top plate must be satisfying in the translational direction, but also cross section. If you have moved the carriage manually, you probably need to initialize the resolver position, see Update revolution counters on page 185 .
3	Drill the holes in the floor through the levelling screws opening, see the following section.
4	Install the anchors and secure the cross members to the floor. If the recommended anchors are not used, you should check that the floor resistance and the selected anchors are compatible with the dynamic forces generated by the FlexTrack and the manipulator, see Recommendation for anchors on page 60 .

Securing a crossmember

	Action	Note/Illustration
1	Position the crossmembers on the floor.	 xx1800001896
2	Adjust the horizontality of the FlexTrack with the M60 levelling screw.	
3	Check that all the levelling screws are touching the floor.	
4	Tighten the M60 nuts.	

Continues on next page




2 Installation and commissioning

2.5.2 Recommendations for floor mounting

Continued

Installation of chemical anchors

Please respect the following procedure for chemical anchors installation. No mechanical anchors allowed. Chemical anchors used in FlexTrack IRT501-66/66R/90/90R/90RE/90RS is HILTI M16x125 anchors.






	Action	Note
1	<p>Drill the hole with rotary hammer and set the depth gauge to the correct drilling depth. Diamond coring: Mark the correct drilling depth on the height adjustment mechanism.</p>	 <p>xx1700001665</p> <p>xx1700001666</p>
2	<p>Clean the hole immediately before setting the anchor. Remove drilling dust and standing water from the base of the hole by blowing out well with at least 4 strokes of the blow-out pump, or using compressed air or an industrial vacuum cleaner. The anchor holes must be free of dust, water, ice, oil, bitumen, chemicals or any other foreign matter or contaminants. Poorly-cleaned holes leads to poor hold.</p>	 <p>xx1700001667</p>
3	<p>Ensure that the specified setting depth is marked on the anchor rod. If not, add an embedment mark, for example with tape or marker.</p>	 <p>xx1700001668</p>

Continues on next page

2 Installation and commissioning

2.5.2 Recommendations for floor mounting

Continued



	Action	Note
4	Check that the hole is drilled to the correct depth before setting the anchor, hole depth is correct when the anchor rod contacts the base of the hole and the setting depth mark coincides with the concrete surface.	 <p>xx1700001669</p>
5	Push the anchor rod into the drilled hole.	 <p>xx1700001670</p>
6	Use the setting tool at a speed of 250-1000 r.p.m to drive the anchor rod into the hole, applying moderate pressure and with the hammering action switched on.	 <p>xx1700001671</p>
7	<p>Switch off the rotary hammer drill immediately when the specified setting depth is reached (refer to mark on the anchor rod). After setting, adhesive mortar must fill the annular gap completely right up to the concrete surface.</p> <p> CAUTION</p> <p>Prolonged rotary action may cause mortar to be forced out of the hole, resulting in reduced anchor loading capacity.</p>	 <p>xx1700001672</p>
8	The working time ' t_{rel} ' which depends on base material temperature, must be observed. The screwed-on setting tool may be removed only after the time ' t_{rel} ' has elapsed.	 <p>xx1700001673</p>

Continues on next page

2 Installation and commissioning

2.5.2 Recommendations for floor mounting

Continued

	Action	Note														
9	After reaching the end of the working time ' t_{rel} ' do not manipulate or disturb the anchor rod in any way until the curing time ' t_{cure} ' has elapsed.	 <p>xx1700001674</p>														
10	A load may be applied to the anchor only after the curing time ' t_{cure} ' has elapsed. Torque: 80	 <p>xx1700001675</p>														
11	Curing time ' t_{cure} ' which depend on base material temperature must be observed!	<p>Curing time</p> <table border="1" data-bbox="1034 987 1401 1205"> <thead> <tr> <th>Temperature of the base material</th> <th>Minimum curing time t_{cure}</th> </tr> </thead> <tbody> <tr> <td>-10 °C to -6 °C</td> <td>5 hours</td> </tr> <tr> <td>-5 °C to -1 °C</td> <td>3 hours</td> </tr> <tr> <td>0 °C to 4 °C</td> <td>40 min</td> </tr> <tr> <td>5 °C to 9 °C</td> <td>20 min</td> </tr> <tr> <td>10 °C to 19 °C</td> <td>10 min</td> </tr> <tr> <td>20 °C to 40 °C</td> <td>5 min</td> </tr> </tbody> </table> <p>xx1700001676</p>	Temperature of the base material	Minimum curing time t_{cure}	-10 °C to -6 °C	5 hours	-5 °C to -1 °C	3 hours	0 °C to 4 °C	40 min	5 °C to 9 °C	20 min	10 °C to 19 °C	10 min	20 °C to 40 °C	5 min
Temperature of the base material	Minimum curing time t_{cure}															
-10 °C to -6 °C	5 hours															
-5 °C to -1 °C	3 hours															
0 °C to 4 °C	40 min															
5 °C to 9 °C	20 min															
10 °C to 19 °C	10 min															
20 °C to 40 °C	5 min															



WARNING

It is of the utmost importance that all screw joints be tightened with the correct torque. Failure to do so may result in damage to the equipment or personal.

2.5.3 Geometric alignment of FlexTrack IRT 501

Instruction

The geometric alignment of the FlexTrack should be done based on the position of the linear rails. This section details how to adjust the FlexTrack using a laser tracker.

Tool list

Tool	Illustration
<p>Absolute Tracker. Reading must allow estimating 0.1 mm. Example: Leica AT960 Absolute Tracker</p>	 <p>xx1800001905</p>
<p>Reflector Example: Leica Reflector</p>	 <p>xx1800001906</p>
<p>Magnetic block Example: Leica Magnetic block</p>	 <p>xx1800001907</p>
<p>ABB levelling tool (3HAW107700360)</p>	

Continues on next page

2 Installation and commissioning

2.5.3 Geometric alignment of FlexTrack IRT 501

Continued

Procedure



	Action	Note/Illustration
1	On the foundation where the track will be placed, use a laser line drawing instrument to draw the approximate position of the installation position. Place the track on the drawing position without installing the anchor bolts.	
2	If the FlexTrack is already assembled, remove the covers, the cover supports, and slightly loosen all the screws of the linear rails.	
3	Position the absolute tracker such as you will be able to measure the reflector position on the linear rails.	
4	Make sure that the absolute tracker is parallel to the sea level.	

Continues on next page

2 Installation and commissioning

2.5.3 Geometric alignment of FlexTrack IRT 501

Continued




	Action	Note/Illustration
5	<p>Measure the level of the FlexTrack linear rails at different locations of the FlexTrack. Measurements should be made on both sides of each crossmembers.</p> <p> Tip</p> <p>Divide the track into two parts. Make sure that the side surface of the rail at the first, middle, and end (Example points: 1, 3, 2) are on the same straight line. Then secure the track. Then make sure that the straightness of the half in one part (Example points: 1, 4, 3) is consistent. By analogy (Example points: 1, 5, 4), adjust all the side surfaces to the same straight line.</p>  <p>xx2000002601</p>	<p>The magnetic base attached to the reflector must be in contact with the rail upper surface or side surface.</p> <p>See the contact surfaces in red on the picture below:</p>  <p>xx1800001908</p> <ul style="list-style-type: none"> A Reflector & Magnetic block B Linear Rail C Levelling Screw

Continues on next page

2 Installation and commissioning

2.5.3 Geometric alignment of FlexTrack IRT 501

Continued




Action	Note/Illustration
<p> Tip</p> <p>Two special tools are used in adjusting the linear rails on linear movement direction.</p> <p>For track without base plate:</p>  <p>xx2000002602</p> <p>For track with base plate:</p>  <p>xx2000002604</p>	
<p>6 Use the ABB levelling tool 3HAW107700360 to adjust the levelling screws until all the measured points, on both sides of the FlexTrack, are at the same level.</p>	<p>It is recommended to use one of the highest points of the FlexTrack as reference: It is easier to bring the crossmember to a higher level rather than to bring it to a lower level.</p>  <p>xx2000002603</p>

Continues on next page

2 Installation and commissioning

2.5.3 Geometric alignment of FlexTrack IRT 501

Continued

	Action	Note/Illustration				
7	If the base plate is used under the track, weld the adjustment plate to the base plate.	 <p>xx2000002606</p>				
8	Do a fine adjustment of the linear rails in both lateral and transverse. The planarity tolerance is 0.1mm/m, in lateral and transverse.	 <p>xx2000002605</p> <table border="1" data-bbox="1059 1014 1437 1160"> <tr> <td data-bbox="1059 1014 1091 1111">A</td> <td data-bbox="1091 1014 1437 1111">Adjustment screw (Cannot be used after the adjustment plate is welded to the base plate.)</td> </tr> <tr> <td data-bbox="1059 1111 1091 1160">B</td> <td data-bbox="1091 1111 1437 1160">Fine adjustment screw</td> </tr> </table>	A	Adjustment screw (Cannot be used after the adjustment plate is welded to the base plate.)	B	Fine adjustment screw
A	Adjustment screw (Cannot be used after the adjustment plate is welded to the base plate.)					
B	Fine adjustment screw					
9	Check the rails alignment: Use a ball bearing block or a square ruler; if you do not have a spare block or a square ruler, disassemble one from the carriage. If the linear rails are correctly aligned, you should sense no "step" while passing the rail junction points. If you do, then push the rail against the side member step and make sure that there is 0.2 mm gap between adjacent rails. When the alignment is correct, tighten the screws one by one, after applying Loctite 243 on its thread.	 <p>xx1800001909</p>				
10	Use a brush to lubricate the linear rails.					
11	Re-assemble all the cover support brackets and covers, if necessary.					




2 Installation and commissioning

2.6 Assembly of the manipulator

2.6 Assembly of the manipulator

Overview

When the FlexTrack is carrying an IRB robot it behaves like an integrated 7th axis. The robot should be ordered with an additional drive unit (907-1) for the FlexTrack motor, and optionally a resolver connection for 7th axis on the robot base (864-1). The FlexTrack unit is designed to be controlled with ABB IRC5 controller. For compatibility with other control systems please contact ABB.

Robot position on the carriage - 4 possibilities:		
0° (right) or 180° (left)	 xx1800001910	 xx1800001911
90° (left) or 270° (right)	 xx1800001912	 xx1800001913

See [Robot orientation on the track on page 101](#) for details on how to link the robot to the track.

2.7 Cables, SMB box and cable chain


2.7.1 Cabling of the FlexTrack

Description

The FlexTrack has an internal cable chain which carries flexible movement cables. The FlexTrack motor can be controlled through an external SMB box, or through the integrated SMB card of a manipulator. Static cables connect to the IRC5 controller.

Schema

The schema below shows the typical control architecture of a FlexTrack controlled through external SMB box:



xx1800001914

The flexible movement cables exit the track at the middle of the stroke of the carriage and are selected from standard lengths based on the travel length of the carriage based on the total stroke of the carriage.

FlexTrack cables lengths

The FlexTrack flexible and static cables (power & resolver) are available in standard lengths of 5 m, 10 m and 15 m lengths.

Robot cables

If the FlexTrack is ordered prepared for a manipulator, the cable chain should contain the suitable flexible movement cables. Robot floor cables should be ordered with the robot.



Tip

It is important to indicate the robot mounting orientation in the order form in order to get the correct robot cable length.

2 Installation and commissioning

2.7.2 Specifications of the movement cables

2.7.2 Specifications of the movement cables

Movement cables diameter and weight

The internal cable chain usually contains the FlexTrack motor power and resolver cables. When additional cables are used, it is important to ensure that they can all fit in. In particular, if a number n of cables are used, you must make sure that:

- The total width of all the cables added together, as well as the width of $n-1$ separators (5 mm each), does not exceed the internal width of the cable chain (175 mm).
- The total weight of all cables does not exceed 10 kg/m.

For more detailed information, see chapter *Movement cables specifications* in *FlexTrack IRT501 product specification (3HAW050008591-001)*.

2.7.3 Specifications of the internal cable chain

Cable chain specifications

For more detailed information on , see chapter *Internal cable chain* in *FlexTrack IRT501 product specification (3HAW050008591-001)*.

2 Installation and commissioning

2.7.4 Installation of the cable chain



2.7.4 Installation of the cable chain



WARNING

The FlexTrack cable chain is delivered assembled in the FlexTrack. If the cable chain and/or its content must be modified upon installation, make sure that the following recommendations are strictly followed. Improper installation of the cable chain will result in premature wear or damages of the chain and the flexible cables.

Checklist



	Action	Note/Illustration
1	<p>An opening should be made in the internal cable tray to let all the cables exit the FlexTrack. All cables should exit the FlexTrack immediately at the end of the chain.</p> <p>An opening should be made in the external cable tray to let all the cables exit the FlexTrack. All cables should exit the FlexTrack immediately at the end of the chain.</p> <p>If necessary, the edges of the cut tray area should be covered with rubber seal strip.</p>	<p>For internal cable tray</p>  <p>Rubber Seal Strip</p> <p>xx1800001918</p> <p>For external cable tray</p>  <p>xx2000002592</p>
2	<p>The cable tray should be absolutely free of any object (cable, screw, etc.). The bottom of the cable tray must be perfectly flat, without bump.</p>	 <p>xx1800001892</p>

Continues on next page

2 Installation and commissioning

2.7.4 Installation of the cable chain

Continued


	Action	Note/Illustration
3	<p>In the cable chain, the cables should be separated by the "separators", at least every 8 links.</p> <p>That the mass of the cables and pipes inside the chain should be balanced. Having all heavy cables on the same side of the chain could cause premature wear.</p>	 <p>xx1800001920</p>
4	<p>The cables should be firmly attached on the tie-wrap plate at the end of the cable chain on the carriage side.</p>	 <p>xx1800001921</p>
5	<p>The cable chain should be perfectly aligned with the FlexTrack chain tray. In order to achieve a correct alignment, it is recommended to fix both ends of the chain when the carriage is at the end of its stroke, and the chain is entirely unrolled in the duct.</p>	 <p>xx1800001922</p>  <p>xx1800001919</p>
6	<p>For very long chains, a ramp should be used to prevent the chain from running on the cables exiting the cable chain. If the cable chain appears to be rubbing the cables and no ramp is installed, please order the following from ABB:</p> <ul style="list-style-type: none"> • The internal cable tray ramp up: 1pc 3HAW107700646 and 1pc 3HAW107700647. • The external cable tray ramp up: 1pc 3HAW107700646. 	 <p>xx1800001924</p>

Continues on next page

2 Installation and commissioning

2.7.4 Installation of the cable chain

Continued

	Action	Note/Illustration
7	<p>Verify that there is a clearance of approximately 2 mm between the rack covers and the rack (see figure).</p> <p>If not, unscrew the cover screws and push the cover away from the rack. Tighten the cover screws.</p>	 <p>xx1800001925</p>
8	<p>Move the carriage to both ends in manual mode at low speed. Verify that the cable chain is not rubbing on the covers during the carriage movement, and that no moving part shows abnormal wear. Check also that the stationary cables are not interfering with moving elements.</p>	 <p>xx1800001926</p>
9	<p>Check that the cable chain is long enough to reach the ends of the stroke without damage. At least 1 chain link should remain horizontal to avoid unnecessary pulling on the chain fixing element. Verify again that the chain is parallel with the cable tray when unwind. If not, adjust the orientation of the fixed point of the chain as described in step5.</p>	

2.7.5 SMB box

Description

The FlexTrack motor is controlled by IRC5 controller through an ABB Serial Measurement Board. For FlexTrack used to move a manipulator, it is possible to connect the motor resolver to the manipulator's integrated SMB board (robot option). If there is no robot, or if the robot is not equipped with a resolver socket for external axis on its base, it is necessary to use an external SMB box:



xx1800001927



Note

Check that there is enough space to install the SMB box during layout design.

2 Installation and commissioning


2.7.6 Cables connections

2.7.6 Cables connections

Instruction

If the FlexTrack motor is controlled through a robot integrated SMB card, the FlexTrack resolver cable should be connected to the robot base, the FlexTrack movement power cable should be connected to the FlexTrack static power cable and the FlexTrack static power cable should be connected to the XS7 socket on the IRC5 controller.

If the system is controlled through an external SMB box, the connections should be made as shown below:


Description	Note/Illustration
Connect the static resolver and power cables from the IRC5 to the SMB box.	 <p>xx1800001928</p>
Connect the movement resolver and power cables from the carriage to the SMB Box.	 <p>xx1800001929</p>
For all signal sockets on the SMB box that are unused, a PTC plug is required. This plug bridges pin 7 and 8.	 <p>xx2000002544</p>

Continues on next page

2 Installation and commissioning

2.7.6 Cables connections

Continued

Description	Note/Illustration				
Ensure that the movement cables are properly connected to the motor.	 <p>xx1800001930</p> <table border="1" data-bbox="833 721 1436 810"><tbody><tr><td data-bbox="833 721 901 766">A</td><td data-bbox="908 721 1436 766">Power cable</td></tr><tr><td data-bbox="833 775 901 810">B</td><td data-bbox="908 775 1436 810">Signal cable</td></tr></tbody></table>	A	Power cable	B	Signal cable
A	Power cable				
B	Signal cable				

2 Installation and commissioning

2.7.7 Connectors on IRC5 controller

2.7.7 Connectors on IRC5 controller

General


The following section describes the connectors on the respective front panels of the IRC5 controller. These are described below, and detailed in section, Connectors on controller IRC5 in [Product Manual IRC5](#).

Single Cabinet Controller

The following details the connection interface on the Single Cabinet Controller.

Small robots

The following details the connection interface for small robots.




xx1800001931

A	XP.0 Mains connection
B	XS.1 Robot power connection
C	XS.7 Additional axes power connection
D	XS.58 Position switches
E	XS.8 Position switches
F	XS.13/XS.5 Customer power/signals external connection
G	XS.10 Customer options
H	XS.11 Customer options
J	XS.12 Customer options
K	X3 Customer safety signals
L	XS.28 Network connection
M	XS.41 Additional axes SMB connection
N	XS.2 Robot SMB connection

Continues on next page

Large robots

The following details the connection interface for large robots.



xx1800001932

A	XP.0 Mains connection
B	XS.1 Robot power connection
C	XS.7 Additional axes power connection
D	XS.58 Position switches
E	XS.8 Position switches
F	XS.13/XS.5 Customer power/signals external connection
G	XS.10 Customer options
H	XS.11 Customer options
J	XS.12 Customer options
K	X3 Customer safety signals
L	XS.28 Network connection
M	XS.41 Additional axes SMB connection
N	XS.2 Robot SMB connection

Continues on next page

2 Installation and commissioning

2.7.7 Connectors on IRC5 controller


Continued

Dual cabinet controller

The following details the connectors on the frontpanel of the Dual Cabinet Controller, that is the Control Module and the Drive Module.

Control Module

The following details the connectors on the frontpanel of the Control Module.



xx1800001933


A	Power connection
B	A5.X8: Position switches
C	A5.X58: Position switches
D	A5.X5: Customer power/signals external connection
E	A5.X 11: Customer options
F	A5.X 12: Customer options
G	A5.X 13: Customer options
H	A5.X 14: Customer options
J	A5.X3: Customer safety signals
K	A22.X1: FlexPendant connection
L	A5.X28: Network connection

Continues on next page

Drive Module


The following details the connectors on the frontpanel of the Drive Module.

Small robots:



xx1800001934

Large robots:



xx1800001935

	Description
A	A4.X0: Mains connection to transformer
B	A4.XS25: Power to Control Module
C	A4.X1: Robot power connection
D	A4.X7: External axes power connection
E	A4.XX: Customer options
F	A4.XX: Customer options
G	A4.XX: Customer options
H	A4.XX: Customer options
J	Communication cabling between Control/Drive Module

Continues on next page

2 Installation and commissioning

2.7.7 Connectors on IRC5 controller

Continued

	Description
K	Communication cabling between Control/Drive Module
L	A4.XS41: Additional axes SMB connection
M	A4.XS2: Robot SMB connection

2.8 Software installation

2.8.1 Preparation for setup

General

How to get the system running is described in Getting started, IRC5 and in Robot Studio. This chapter contains instructions for starting up the IRC5 robot controller for the very first time after the physical installation has been completed.

Procedure

List of the required operations before starting up the FlexTrack setup:

	Action	Note/Illustration
1	Configure the controller.	Load the FlexTrack parameters and configure the controller as described in the section below.
2	Installation of the FlexTrack.	Check that the FlexTrack is installed and leveled as described in Assembly of the track on page 64 .
3	Lubrication system.	If the FlexTrack is equipped with an automatic lubrication system, it must be activated as described in Lubrication on page 108 .
4	Manual lubrication.	If the FlexTrack is not equipped with an automatic lubrication system, you need to manually lubricate the blocks and the rack, see Racks and pinion on page 124 .
5	Revolution counter update.	Like any other robot axis, the FlexTrack revolution counter must be updated using the FlexPendant, see Update revolution counters on page 185 .

Loading the FlexTrack parameters

It is necessary to load the FlexTrack parameters in the controller. These can be found on the CD supplied in the delivery package. This procedure is described in details in the robot controller operation manual. Hereunder are listed the actions related to the FlexTrack specifics:

	Action
1	Select the menu option: Add new parameters .
2	Load the file <i>MOC.cfg</i> .

2 Installation and commissioning

2.8.2 Load configuration files

2.8.2 Load configuration files

Procedure





When the track is delivered, it will be delivered with the configuration files for the track. These files include the information for the IRC5 to recognize the track, as well as required parameters for the track motor. The files are specific to the system layout and configuration.

If these files were not received, contact ABB.

To load the files, there are two methods, load the MOC files onto a USB stick and load then directly on the IRC5 or use Robot Studio Online. Below described only the USB method.

	Action	Note/Illustration
1	Make a System Backup before beginning.	
2	Start the IRC5 and tap ABB .	<p>xx1800001936</p>
3	From the ABB menu, tap Control Panel .	<p>xx1800001937</p>
4	Tap Configuration .	<p>xx1800001938</p>

Continues on next page

	Action	Note/Illustration
5	Tap File.	 <p>xx1800001939</p>
6	From the File menu, tap Load Parameters.	 <p>xx1800001940</p>
7	Tap to select the Load parameters and replace duplicates option.	 <p>xx1800001941</p>
8	Browse for the appropriate *.CFG files to add, and tap OK. Do not restart the controller yet.	 <p>xx1800001942</p>
9	Repeat the steps for all *.CFG files that need to be loaded, and then warm restart the controller.	

Continues on next page

2 Installation and commissioning

2.8.2 Load configuration files

Continued



Tip

If the IRC5 reboots without error, then the *.CFG files have been loaded correctly. If an error occurs, record the error message and error number and send the back up of the original system, system layout and error information to the *After-Sales support* to get help.

If the system enters **System failure state** it is necessary to perform a cold start. This will restore the system to a default settings with no mechanical units or programs. Then restore the original backup taken before loading the *.CFG files. Then retry loading the *.CFG files.

2.8.3 Modification of the Travel Direction of the track

Instruction

To change the travel direction, contact ABB for support.

2 Installation and commissioning

2.8.4 Link robot and track

2.8.4 Link robot and track



Note

If no robot is mounted on the track, this set can be skipped.

Instruction

If a robot is mounted in the track, it is necessary to link the robot to the track. This effectively increases the work frame of the robot, allowing the robot to reach desired targets along the length of the track, by moving the robot on the track.

The declaration is in the MOC under the theme ROBOT in `base_frame_coordinated`.

In the example below, we declare that the robot `ROB1` is mounted on the Track `TR1`.

ROBOT: -base_frame_coordinated "TR1"

2.8.5 Robot orientation on the track


Introduction

To ensure that the robot works properly in linear on its track, it is necessary to declare the robots orientation relative to the track.

The declaration of the orientation is in the MOC under the theme `ROBOT` in:

- `base_frame_orient_u0` which corresponds to the quaternion Q1
- `base_frame_orient_u1` which corresponds to the quaternion Q2
- `base_frame_orient_u2` which corresponds to the quaternion Q3
- `base_frame_orient_u3` which corresponds to the quaternion Q4


Robot with a 0° rotation around Z on the Track (Robot aligned with the Track)



xx1800001945

```
base_frame_orient_u0 = 1
base_frame_orient_u1 = 0
base_frame_orient_u2 = 0
base_frame_orient_u3 = 0
```

Robot with a 90° rotation around Z on the Track



xx1800001944

```
base_frame_orient_u0 = 0.70710678
```

Continues on next page


2 Installation and commissioning

2.8.5 Robot orientation on the track

Continued

```
base_frame_orient_u1 = 0  
base_frame_orient_u2 = 0  
base_frame_orient_u3 = 0.70710678
```


Robot with a 180° rotation around Z on the Track



xx1800001943

```
base_frame_orient_u0 = 0  
base_frame_orient_u1 = 0  
base_frame_orient_u2 = 0  
base_frame_orient_u3 = 1
```

Robot with a 270° rotation around Z on the Track



xx1800001946

```
base_frame_orient_u0 = 0.70710678  
base_frame_orient_u1 = 0  
base_frame_orient_u2 = 0  
base_frame_orient_u3 = -0.70710678
```

2.8.6 Set Upper and Lower Limits Software Limits for track

Introduction

The Upper and Lower software limit of the track are software limits that prevent the track from being jogged beyond the mechanical limit of the track.



WARNING

This is an important safety feature to prevent damage to the track. Ensure that the track direction has first been set and the track has been calibrated before performing this step.

Example

An example of the error message that is generated when the track is jogged beyond its software limit is shown below:

Event Log - Event Message

Event Message 50028 2009-04-22 10:36:56

 **Jog in wrong direction**

Description
Position for TR1 joint TR1 is out of working range.

Actions
Use the joystick to move the joint in opposite direction.

Show Log Acknowledge

Production Window Jogging 

xx1800001947

The Upper and Lower Limit of the track is the physical displacement distance from the zero position to the limit position in meters. This depends on the length of the track, and the location of the calibration pin (Also referred to as the Zero position of the track).

The limits are in `MOC.CFG`, under the theme `ARM`.

The upper limit is called `upper_joint_bound`, and the lower limit is called `lower_joint_bound`. Both are expressed in meters.

In the example below the upper limit is set to 6 m and the lower limit is set to -0.005 m.

Continues on next page





2 Installation and commissioning

2.8.6 Set Upper and Lower Limits Software Limits for track

Continued

ARM : -upper_joint_bound 6 -lower_joint_bound -0.005

To change the limits using the teach pendent, do the following:



	Action	Note/Illustration
1	From the ABB menu, tap Control Panel .	 <p>xx1800001948</p>
2	Tap Configuration .	 <p>xx1800001938</p>
3	Under Topics , tap Motion .	 <p>xx1800001949</p>
4	Select Arm .	 <p>xx1800001950</p>

Continues on next page

2 Installation and commissioning

2.8.6 Set Upper and Lower Limits Software Limits for track


Continued

	Action	Note/Illustration
5	Select the appropriate Mechanical unit.	 <p>xx1800001951</p>
6	Change the Upper joint bound and Lower Joint bound limits.	 <p>xx1800001952</p>
7	Tap OK to save the change and perform a warm start.	

Identifying the upper and lower limits by experiment

If the actual value of the limit is not know, it is possible to jog the track to the desired limit position, and then read the limit value off of the teach pendent.

Below is the process to identify the limits by experiment:



	Action	Note/Illustration
1	Before beginning, ensure that the FlexTrack's revolution counter is calibrated.	
2	<p>The Upper and Lower Limit monitoring is active when in manual mode, thus it is first necessary increase the current limit to beyond the mechanical stop. This will then allow the track to be jogging without error up to the desired limit position.</p> <p>ARM : -upper_joint_bound 11 -lower_ joint_bound -1</p>	 <p>xx1800001956</p> <p>Figure 2.1:</p>  <p>WARNING</p> <p>If the actual track length is 10 m in the positive direction of movement, and -0.060 m in the negative direction, then first set the Set the upper bound to 11 m and the lower bound to -1 m.</p>

Continues on next page

2 Installation and commissioning

2.8.6 Set Upper and Lower Limits Software Limits for track

Continued

	Action	Note/Illustration
3	Perform a warm restart.	
4	<p>Jog the mechanical unit to the limit position as shown in the figure.</p> <p>A minimum distance of 50 mm should be used between where the software limit is set and the actual mechanical stop.</p> <p>In the jogging window, read of the tracks current position. Note that the distance is shown in millimeters, and not meters. In this example it is 9,950.1 mm.</p> <p>Update the limit in the MOC file ARM: -upper_joint_bound 9.950 - lower_joint_bound -1</p>	 <p>xx1800001957</p>  <p>xx1800001958</p>  <p>WARNING</p> <p>This step should be carried out with great care. If the software limit has not been set correctly the mechanical unit may hit the mechanical hard stop.</p>
5	Perform a warm restart.	
6	<p>Set the Jogging speed to 20% and test the software limit.</p> <p>If the software limit has been set correctly, the following error should be generated, see the figure.</p>	 <p>xx1800001959</p>  <p>WARNING</p> <p>This step should be carried out with great care. If the software limit has not been set correctly the mechanical unit may hit the mechanical hard stop.</p>
7	Repeat the previous steps for the other limit.	

Continues on next page

Offset parameters

The offset parameters for the FlexTrack IRT 501 are manufacturer parameters, and must not be modified on site.

Travel length

The travel length of each carriage are defined starting from the zero indicator (see figure).

In the parameter file, the travel length value is set to the maximum stroke.



xx1800001960

Use a $\varnothing 8$ mm pin or the calibration tool to accurately setup the FlexTrack zero position, then follow the instruction in [Fine calibration on page 184](#).

2 Installation and commissioning

2.9.1 Activating the automatic lubrication system

2.9 Lubrication

2.9.1 Activating the automatic lubrication system

There are two types of automatic lubrication system can be used in FlexTrack. One is HPS, and the other is EPS.

	HPS	EPS
Power supply	4.5 battery	External 24 power
Control method	After setting the use period, install the time loop oil pump to work once, and then work independently according to the set use period until the oil bag is used up.	<p>A The same as the HPS time setting, except that the battery power supply is changed to an external power supply; but the oil pump works once when it is powered on, and then works according to the previously set time period under the condition of uninterrupted power, so it can be synchronized with the equipment (in shutdown Or the oil pump does not work during maintenance)</p> <p>B The working frequency of the oil pump is controlled by the equipment PLC. Because the oil pump works once when it is powered on, the customer can control the working frequency of the oil pump by controlling the power on and off frequency of the oil pump with the PLC.</p>

Continues on next page

2 Installation and commissioning


2.9.1 Activating the automatic lubrication system

Continued

HPS

The automatic lubrication system needs to be activated before using the FlexTrack. Once the system has been activated, it delivers the exact quantity of grease to each port at required time interval, during one year.

Follow the instructions below to activate the cartridge:

	Action	Note/Illustration
1	<p>Introduce the battery and the cartridge LONGTIME PD 0 in the port. The timer is activated once the battery is inserted.</p> <p>See Memolub manual on page 134 for instructions about MEMOLUB.</p>	 <p>xx1800001961</p>
2	<p>The grease is pushed in the piping by the pump; a valve is sequencing the distribution to each port.</p>	 <p>xx1800001962</p>

Continues on next page

2 Installation and commissioning


2.9.1 Activating the automatic lubrication system

Continued

EPS

The automatic lubrication system needs to be activated before using the FlexTrack. Once the system has been activated, it delivers the exact quantity of grease to each port at required time interval, during one year.

Follow the instructions below to activate the cartridge:

	Action	Note/Illustration
1	<p>Introduce the external 24 power and the cartridge LONGTIME PD 0 in the port. The timer is activated once the 24 power is on.</p> <p>See Memolub manual on page 134 for instructions about MEMOLUB.</p>	 <p>xx2000002593</p>
2	<p>The grease is pushed in the piping by the pump; a valve is sequencing the distribution to each port.</p>	 <p>xx1800001962</p>

2.9.2 Lubrication feedback (optional)


Overview

To check if the lubrication system works well, it is viable to take use of lubrication feedback system with FlexTrack.

Content

The principle of Switch detection of lubrication:

If it ends in a complete working cycle (Normal working cycle: 1 in 4 out distributor cycle for 4 days, 1 in 6 out cycle for 6 days, 1 in 8 out cycle for 8 days. If other working cycle is used, please contact ABB for the cycle), the switch will show a 0-1-0 or 1-0-1 signal as feedback, which indicates that the lubrication is normal, if not, it indicates that the lubrication is abnormal. Lubrication abnormal alarm can be set according to this signal difference.



xx2000002594

A	M12 Cable
B	M12 Connector
C	Switch

Reference

For more detail, see *FlexTrack Lubrication Unit Feedback, 3HAW107710207*.

2 Installation and commissioning

2.10 Zone Division

2.10 Zone Division

Overview

For more detailed information, see chapter *Position switch/ zone division* in *FlexTrack IRT501 product specification (3HAW050008591-001)*.

2.11 Setting up the FlexTrack limit switch for additional safety

Option 1 - Wiring the limit switch into the safety link of the IRC5





Note

This option should be used in simple systems where there is no safety PLC however additional safety is required to guarantee that the carriage does not go beyond the software limits set in the controller.

Operating principle

When the limit switch is triggered, it will open a circuit that is constantly monitored by the robot controller. As soon as this open circuit is detected, the IRC safety chain is opened and the drive module turns off the motors immediately stopping all motion. At the same time **Error 20209 - External Contactor Open** is generated on the FlexPendant.

	Action	Note/Illustration
1	<p>Connect the signal cable from the limit switch to the IRC5 cabinets "Contactor Board" to A43:X22. This connection is described below. The board is located as shown:</p>	 <p>A43 Contactor unit</p> <p>xx1800001970</p>  <p>xx1800001969</p>
2	<p>Remove the terminal connector A43:X22. There should normally be a jumper between Pins 1 & 2 (Jumper between Pins 3 & 4 or Pin 5 & 6 can be used for each limit switch)</p>	 <p>xx1800001971</p>

Continues on next page

2 Installation and commissioning

2.11 Setting up the FlexTrack limit switch for additional safety

Continued

	Action	Note/Illustration
3	Remove the jumper between Pin 1 & 2 and place one cable from the limit switch into pin 1 and the other into pin 2.	
4	Start the IRC5 controller. If the "Error 20209 - External Contactor Open" is generated, check the cable connection between A43:X22 and the limit switch. Ensure that the limit switch is normally closed.	
5	Repeat the above step for the limit switch at the other end of the FlexTrack.	If all the pairs of Pins in A43:X22 are used, then place the limit switch 1 and limit switch 2 in series to an existing chain.



Note

The limit switch has 1 normally open contact and 1 normally closed contact. The normally closed circuit should be connected to the A43:X24 terminal.



Tip

- If the limit switch is triggered by the carriage, it will not be possible to jog the carriage away from the limit switch. In this case, release the brake and manually push the carriage away from the sensor. Then update the revolution counters before attempting to run the track when necessary.
- For more information, please see *Product manual - IRC5*.

Option 2 - Wiring the limit switch into the safety PLC



Note

This option should be used for more complex systems where a safety PLC is controlling the complete station and additional safety to guarantee that the carriage does not go beyond the software limits set in the controller.

Operating Principle

When the limit switch is triggered, it will open a circuit that is constantly monitored by the safety PLC. Additional logic should be programmed in the PLC react appropriately, such as shutting off the power to the motors.



Tip

For details on how to connect to the safety PLC, please review the *Product specification - PLC robot controller*.

2.12 Additional Safety Function Support

Overview

To implement advanced safety control, it is viable to take use of SafeMove2 with FlexTrack.

Regarding software and hardware options, installation and commissioning, safety etc., please follow the instructions in *Application manual - Functional safety and SafeMove2 (3HAC052610-001)*.

For more detailed information, see chapter *Safety* in *FlexTrack IRT501 product specification (3HAW050008591-001)*.


2 Installation and commissioning

2.13 Anti-collision system (optional)

2.13 Anti-collision system (optional)

Overview

To prevent carriages from colliding during the movement (especially when multiple carriages are on one track), anti-collision system (optional) can be installed on carriages with FlexTrack.




xx2000002595

	ABB part reference no.	Description
A	3HAW107710201	Laser scanner
B	3HAWC116985	Laser reflector

Content

The stopping distance is specifically set by the customer according to the specific situation (the minimum distance is 200mm).



xx2000002596

A	Laser scanner
---	---------------

Continues on next page

2 Installation and commissioning




2.13 Anti-collision system (optional)

Continued

B	Laser reflector
---	-----------------

Installation

The following table describes all necessary steps to achieve a correct installation of the anti-collision system to a carriage:


	Action	Note/Illustration
1	Install the laser scanner with the bracket to the carriage.	Screws: 2 pcs x M6x20 Washers: 2 pcs x ϕ 6 Tightening torque: 10 Nm
2	Secure with washers and screws.	
3	Connect the movement cable to the scanner connection point.	 xx2000002597
4	Route the movement cable from the drawer on the carriage to the track.	 xx2000002599
5	Connect the other end of the movement cable to the static cable.	 xx2000002600
6	Connect the other end of the static cable to the IRC5 controller.	

Continues on next page

2 Installation and commissioning

2.13 Anti-collision system (optional)

Continued

	Action	Note/Illustration
7	<p>Install the laser reflector with the bracket to the nearby carriage.</p> <p> WARNING</p> <p>The reflector should be installed aligned with the scanner. Or the reflector cannot reflect the laser signal from the scanner.</p>	<p>Screws: 2 pcs x M6x20 Washers: 2 pcs x $\phi 6$ Tightening torque: 10 Nm</p> 
8	<p>Secure with washers and screws.</p>	<p>xx2000002598</p>

3 Maintenance

3.1 Introduction

Structure of this chapter

This chapter details all maintenance activities recommended for the FlexTrack IRT 501-66/66R/90/90R/90RE/90RS.

It is based on the maintenance schedule, located in the beginning of the chapter. The schedule contains information about required maintenance activities including intervals and refers to procedures for the activities. Each procedure contains all information required to perform the activity, e.g. required tools and materials. The procedures are gathered in different sections, divided according to the maintenance activity.

Safety information

Before any service work is commenced, it is extremely important that all safety information is observed! There are general safety aspects that must be read through, as well as more specific safety information that describe danger and safety risks when performing the procedures. Read [Safety on page 15](#) before performing any service work.

3 Maintenance

3.2 Standard toolkit

3.2 Standard toolkit

General

All service (repairs, maintenance and installation) procedures contain lists of tools required to perform the specified activity. All special tools required are listed directly in the procedures while all the tools that are considered standard are gathered in the standard toolkit and defined in the table below. This way, the tools required are the sum of the standard toolkit and any tools listed in the instruction.

Contents, standard toolkit

Qty	Tool
1	Ring-open-end spanner 8--22 mm
1	Socket head cap 2.5 mm, 4 mm, 5 mm, 6 mm, 8 mm and 10 mm
1	Small flat tip screwdriver
1	Plastic mallet
1	Torque wrench 10 Nm-140 Nm
1	Ratchet head for torque wrench 1/2
2	Socket head cap 5 mm, 8 mm, 10 mm socket 1/2" bit L 20 mm
2	Hex head cap 13 mm, 19 mm socket 1/2" bit L 20 mm

3.3 Maintenance schedule and expected component life

3.3.1 Specification of maintenance intervals

Description

The intervals may be specified in different ways depending on the type of maintenance activity to be carried out and the working conditions of the FlexTrack IRT 501-66/66R/90/90R//90RE/90RS:

- Calendar time: specified in months regardless of whether the FlexTrack system is run or not.
- Operating time: specified in operating hours/meters/cycles. More frequent running of the FlexTrack means more frequent maintenance activities.

3 Maintenance

3.3.2 Expected component life

3.3.2 Expected component life

General

The expected life of a component can vary greatly depending on how intensively the FlexTrack IRT 501 is run.

Regarding the life of the product, under typical application condition, most use cases or typical use cases can achieve the 1M cycle mark. Under certain extreme application conditions, the life of bearing block and rails may be reduced by more than 50%.

Expected life

Component	Expected life	Note
Cables	1,000,000 cycles	The expected life can also be affected by assemblage of cabling other than standard options.
Cable chain	10.000.000 m	1) Different working environment 2) the weight of the internal cables and tubes 3) the actual travel length 4) the speed and acceleration, will have a great impact on the actual life.
Ball bearing blocks	1,000,000 cycles	The expected life is given for the ball bearings of a six-meter-longstroke FlexTrack (12 meters per cycle) operating 1,000 maximum load cycles a day.
Gearbox	Over 20000 hours	
Rack and pinion	Over 10 years	
Rail	12 meters per cycle x 1,000,000 cycles	

3.3.3 Maintenance schedule

General

The FlexTrack IRT 501-66/66R/90/90R/90RE/90RS must be maintained regularly to ensure proper function. The maintenance activities and intervals are specified in the table below.

Unexpected situation may arise during the inspections of the FlexTrack. Any damage must be attended immediately!

The inspection intervals do not specify the life of each component.

Values for these are specified in the previous chapter.

Activities and interval, standard equipment

The table below specifies the required maintenance activities and intervals:

Maintenance activity	Equipment	Interval	Further information
Inspection and cleaning if necessary	Racks and pinion	Every 100 km or every week	See Racks and pinion on page 124
Lubricate (If no automatic lubrication)	Racks and pinion	Every 100 km or every week	See Racks and pinion on page 124
Inspection and cleaning if necessary	linear rails	1 month	See Racks and pinion on page 124 for cleaning linear guides.
Lubricate (If no automatic lubrication)	Ball bearing blocks	1 month	See Ball bearing blocks on page 128
Inspect and re-fill if necessary (If automatic lubrication)	Automatic lubrication system	1 month	See Automatic lubrication system on page 130
Inspection	Emergency stop and stroke limit system	1 month	See Emergency stop and stroke limit system on page 137
Inspection	Zone division system	1 month	See Zone division system on page 138
Inspection	Cables, connectors and electrical cabinets	1 month	See Cables and connectors on page 140
Inspection	Cable chain	1 month	See Cables and connectors on page 140
Inspection (visual)	Gearbox	3 months	See Gearbox on page 141
Inspection (tightening)	Gearbox	1 year	See Gearbox on page 141
Replacement	SMB Battery pack	Battery low alert ⁱ	See Replacement, SMB Battery pack on page 144
Function test	Anti-collision system	6 months	See Anti-collision system function test on page 143

ⁱ SMB Battery low alert (38213 Battery charge low) is displayed when remaining backup capacity (robot powered off) is less than two months. Typical lifetime of a new battery is 36 months if the robot is powered off 2 days/week or 18 months if the robot is powered off 16 h/day. The lifetime can be extended (approx. 3 times) for longer production breaks by a battery shutdown service routine. See Operating manual - IRC5 with FlexPendant for instructions.

3 Maintenance

3.4.1 Racks and pinion

3.4 Activities 100 Km or one week


3.4.1 Racks and pinion

General

It is recommended to inspect and, if necessary, clean the racks and the pinion every 100 km or every week. If the FlexTrack IRT 501-66/66R/90/90R/90RE/90RS is not equipped with an automatic lubrication system, it is necessary to lubricate the racks and the pinion manually every 100 km or every week.

Location

The figure below shows the location of the gearbox racks and pinion:



xx1800001972

A	Pinion
B	Rack

Continues on next page

Required equipment

When you clean the racks and the pinion, or if the FlexTrack IRT 501-66/66R/90/90R/90RE/90RS is not equipped with an automatic lubrication system, it is necessary to lubricate the racks and pinion manually. Use one of the recommended lubricants:

Equipment	Note
Lubricant	CASTROL Longtime PD0
Lubricant	Shell Gadus S2 V220 00
Lubricant	TOTAL Multis EP 0
Lint free cloth	
Lubrication gun (if no automatic lubrication system).	


Lubrication of the racks and pinion

The procedure below details how to perform manual cleaning and lubrication of the racks and pinion of FlexTracks that are not equipped with an automatic lubrication system.



Note

Use lint free cloth.

	Action	Note/Illustration
1	Remove the FlexTrack upper covers and rack covers.	
2	Inspect the racks and the pinion, clean them if necessary.	
3	If you have cleaned them, use a brush to lubricate the racks and the pinion.	
4	Move the carriage back and forth and repeat step3 .	
5	Re-attach the covers.	
6	Every week or 100 km, if the FlexTrack is not equipped with an automatic lubrication system, connect the pump to the rack & pinion grease port on the manifold. Check that no pipe has been damaged.	 <p>xx1800001973</p>
7	Pump to inject the grease in the piping. Inject 3 grams of lubricant for rack & pinion per week or 100 km.	

3 Maintenance

3.5.1 Linear rails

3.5 Activities 1 Month


3.5.1 Linear rails

General

It is recommended to inspect and, if necessary, clean the linear rails every month.

Location

The figure below shows the location of the linear rails:



xx1800001974

A	Linear rails
---	--------------

Required equipment

When you clean the linear rails, it is necessary to lubricate them manually. Use one of the recommended lubricants:

Equipment	Note
Lubricant	CASTROL Longtime PD0
Lubricant	Shell Gadus S2 V220 00
Lubricant	TOTAL Multis EP 0
Lint free cloth	

Continues on next page

Lubrication of the linear rails

The procedure below details how to perform cleaning and, if necessary, lubrication of the linear rails.



Note

Use lint free cloth.

	Action	Note/Illustration
1	Remove the FlexTrack upper covers and rack covers.	
2	Inspect the linear rails, clean them if necessary.	
3	If you have cleaned them, use a brush to lubricate the linear rails.	
4	Move the carriage back and forth and repeat step 3 .	
5	Re-attach the covers.	

3 Maintenance

3.5.2 Ball bearing blocks


3.5.2 Ball bearing blocks

General

If the FlexTrack IRT 501-66/66R/90/90R/90RE/90RS is not equipped with an automatic lubrication system, it is necessary to lubricate the ball bearing blocks manually every month.

Location

The figure below shows the location of the ball bearing blocks:



xx1800001975

A	Ball bearing blocks
B	Grease manifold

Required equipment

Use one of the recommended lubricants:

Equipment	Note
Lubricant	CASTROL Longtime PD0
Lubricant	Shell Gadus S2 V220 00
Lubricant	TOTAL Multis EP 0
Lint free cloth	

Lubricate the ball bearing blocks

The procedure below details how to lubricate the ball bearing blocks.



Note


Use lint free cloth.

Continues on next page

3 Maintenance

3.5.2 Ball bearing blocks

Continued

	Action	Note
1	Connect the pump to a block grease port on the manifold. Check that no pipe has been damaged.	 xx1800001973
2	Pump to inject the grease in the piping. During the operation, watch the seals at the ball bearing block: when you see the grease pouring out, you have applied enough grease. In average, one should inject 1 gram of lubricant per block and per month.	
3	Repeat the <i>step1</i> and <i>step2</i> for each block port on the manifold.	

3 Maintenance

3.5.3 Automatic lubrication system

3.5.3 Automatic lubrication system


General

If the FlexTrack is equipped with an automatic lubrication system, an electric pump will deliver the correct quantity of grease from a cartridge to the ball bearing blocks and to the pinion at required time intervals (one cycle per day). The grease is pushed in the piping by the pump; a valve is sequencing the distribution to each port.

The level of the lubricant should be checked once a month, even though the system should apply the lubricant equally over a longer period.

Location

The figure below shows the location of the lubrication system.



xx1800001977

A	Grease cartridge
B	Control unit grease pump
C	Oil dispatcher

Continues on next page

Required equipment



WARNING

Use lithium soap flowable grease, class NLGI 0, with a mineral oil base, doped with EP (extreme pressure) additives. The base oil viscosity must be ISO VG68 to ISO VG 100.

Grease doped with EP additives is absolutely necessary, due to high loads on blocks.

Customers must use the following lubrication suggested by ABB or malfunction of the lubrication system may occur.

Equipment	Note
Lubricant	CASTROL Longtime PD0
Lubricant	Shell Gadus S2 V220 00
Lubricant	TOTAL Multis EP 0



WARNING

Battery packs should be changed every time the lubricant cartridge is replaced to assure proper voltage to the system, and each battery pack should only be used once only. A new battery pack should be supplied with each replacement cartridge purchased.

Checking grease level and inspect the pipes without lubrication feedback system

The procedure below details how to check the grease level and inspect the pipes when the FlexTrack is installed without lubrication feedback system.


	Action	Note/Illustration
1	Locate the cartridge.	

Continues on next page

3 Maintenance

3.5.3 Automatic lubrication system

Continued

	Action	Note/Illustration
2	Check the level of lubricant. If the lubricant is used up, change with a new one.	 <p>xx1800001978</p> <p>For cartridge replacement, see the memolub manual on the next page.</p>
3	<p>Check if the lubrication pump is working normally. If not, check:</p> <ul style="list-style-type: none"> • The battery is low or not. If yes, replace the battery. (Although the replacement battery should be delivered with the replacement cartridge, note that it is possible to use a set of 3 pcs standard AA batteries). • The EPS system is working normally or not. If no, replace the cartridge. 	
4	Check that no pipe has been damaged, and that the grease is distributed to each block and on the pinion.	 <p>xx1800001979</p>


Checking grease level and inspect the pipes with lubrication feedback system

When lubrication feedback system is used, there will be an abnormal alarm on the FlexPendant if anything is not ok in the lubrication system.

The procedure below details how to troubleshoot the lubrication system when the lubrication feedback system .

	Action	Note/Illustration
1	Locate the cartridge.	

Continues on next page

	Action	Note/Illustration
2	<p>Check the level of lubricant. If the lubricant is used up, change with a new one.</p>	 <p>xx1800001978</p> <p>For cartridge replacement, see the memolub manual on the next page.</p>
3	<p>Check if the lubrication pump is working normally. If not, check:</p> <ul style="list-style-type: none"> • The battery is low or not. If yes, replace the battery. (Although the replacement battery should be delivered with the replacement cartridge, note that it is possible to use a set of 3 pcs standard AA batteries). • The EPS system is working normally or not. If no, replace the cartridge. 	
4	<p>Check that no pipe has been damaged, and that the grease is distributed to each block and on the pinion.</p>	 <p>xx1800001979</p>
5	<p>After installing the lubrication feedback system, check the lubrication status regularly (at least for three months) to avoid incorrect feedback.</p>	

Continues on next page

3 Maintenance

3.5.3 Automatic lubrication system

Continued

Memolub manual

The procedure below is based on the Memolub HPS user manual. It details how to replace the grease cartridge.

Opening and closing the Memolub

	Action	Note
1	<p>Opening the Memolub.</p> <p>First place the Memolub on a flat and clean surface. Push firmly with one hand on top of the Memolub. With the other hand, hold the black base and turn counterclockwise. Pull the transparent bell to open.</p>	 <p>xx1800001980</p>
2	<p>Closing the Memolub.</p> <p>Use the same technique: hold the cranked black base, put the transparent bell and turn it clockwise. When the closed position is reached you should hear a "click".</p>	 <p>xx1800001981</p>

Installing a new grease cartridge

Respect the following instructions to replace the grease cartridge:

	Action	Note
1	<p>Open the Memolub® as described before.</p>	
2	<p>Pull-up the black rubber seal. Fill-in the Memolub® with a manual grease pump. This manual operation is required only if the Memolub has been used without a cartridge, if the previous cartridge has run out of grease. Place the pump nipple at the entry of the Memolub, and pump until you see grease coming out at the outlet. Two strokes of the manual pump are usually enough.</p>	 <p>xx1800001982</p>

Continues on next page

	Action	Note
3	<p>Pull-up the black strap to reveal the battery case. Insert a new Memolub battery: hold it by the black plastic strap & insert it in the Memolub respecting the instructions on the label. If the battery is correctly inserted the motor is activated during 1 sec. to check that the motor is working properly. Put the black rubber seal back in place.</p>	 <p>xx1800001983</p>
4	<p>Remove the paper disc from the replacement cartridge. Fill-in the required dates: "Started" and "Replace before". The "replace before" date is depending on the Memolub program. Put the paper disc back in place in order to see the instructions when the Memolub is closed.</p>	 <p>xx1800001984</p>
5	<p>Press softly on the cartridge until the grease comes out, to avoid injecting air into the pump.</p>	 <p>xx1800001985</p>
6	<p>Place the cartridge at the inlet of the pump. Check that the cartridge is correctly inserted in the inlet of the pump.</p>	 <p>xx1800001986</p>
7	<p>Place the spring and the compression disc inside the transparent bell. Put the bell back in place and check that the compression disc is correctly lying on the top of the cartridge surface.</p>	 <p>xx1800001987</p>
8	<p>Close the Memolub as described before.</p>	

Continues on next page

3 Maintenance

3.5.3 Automatic lubrication system

Continued

Test the Memolub® (Check Function)

	Action	Note
1	<p>To check that the Memolub is working well after a maintenance operation, press one of the 3 connectors located on the base during a few seconds. The Memolub is starting a dispensing cycle. The completion of the cycle means that the battery & control board of the Memolub are working well.</p> <p><i>It is important that you run this test cycle only if a cartridge is in place, otherwise you'll fill-in the pump with air.</i></p>	 <p>xx1800001988</p>

3.5.4 Emergency stop and stroke limit system

General

It is recommended to ensure the emergency stop and stroke limit system effectiveness every month.

Motor brake

The procedure below details how to ensure the effectiveness of the motor brake in case of emergency stop.

	Action	Note/Illustration
1	The FlexTrack is powered, but not moving.	
2	Press the emergency stop button.	
3	The brake is applied; you should hear the noise in the motor area.	
4	Try to push the carriage manually.	
5	If the brake is correctly applied, it is not possible to move the carriage manually.	
6	Proceed with the required validations in the control system to switch back to auto mode.	

Verification of the effectiveness of the stroke limit system

A software limit prevents the carriage from moving beyond its acceptable upper and lower stroke limits.

The procedure below details how to ensure the software stroke limit is working correctly:

	Action	Note/Illustration
1	Switch the IRC5 to manual mode.	
2	With the teach pendant, try to jog the carriage to both ends.	
3	If the software limits are functional, it should not be possible to go beyond the defined upper or lower end position, and it should not be possible to reach the hard stops.	

3 Maintenance

3.5.5 Zone division system


3.5.5 Zone division system

General

It is recommended to ensure the zone division is working properly every month.

Zone division system

The figure below shows the location of the position switch:



xx1800001989

Inspect monthly the following parts:

A	Limit switch
B	Cam guide (on both ends of the FlexTrack)
C	Cam (on both ends of the FlexTrack)
D	Hard stop (bumper) (on both ends of the FlexTrack)

Verification of the effectiveness of the zone division sensor

If a 1 position, 2 position or 4 position limit switch is used to divide the track into zones, then the following procedure should be followed to ensure it is functioning correctly:

	Action	Note/Illustration
1	Power off the IRC5 and activate the E-Stop.	
2	Activate the limit switch sensor using an adhesive tape.	
3	Reset the E-Stop button and power on the IRC5 in manual mode.	

Continues on next page

	Action	Note/Illustration
4	Check if the reaction / error from the IRC5 or PLC are as expected while the limit switch is triggered.	This depends on how the limits switch has been wired and the function it is being used for. For example, if the limit switch is wired to a lamp, then the lamp should be illuminated.
5	Power off the IRC5 and activate the E-Stop.	
	Remove the adhesive tape and reset the E-Stop button and power on the IRC5.	

3 Maintenance

3.5.6 Cables and connectors

3.5.6 Cables and connectors

Inspection of electrical operations



WARNING

Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and for the FlexTrack IRT 501-66/66R/90/90R/90RE/90RS.

Check the cabling

Check monthly:

If any cables ...	then ...
have been damaged trough wear or pinching	replace the cable
run against sharp edges	Replace the cable, remove the cause of the wear, or route the cable in a different way.


Check the connector

Check monthly:

- All the connectors on the controller, the SMB box and the motor are firmly tighten, and that there's no damage to the cable outlet.

Inspection of the cable chain

Once a month check that the cable track shows no trace of excessive wear due to rub on a fixed part. If one element is damaged, it is possible to replace it without removing the whole chain from the FlexTrack.




xx1800001990

3.6 Activity 3 and 12 months

3.6.1 Gearbox

Location

The figure below shows the location of the gearbox:



xx1800001991

A	Bracket
B	Gearbox
C	Motor

Oil

The FlexTrack IRT 501 gearbox is filled with synthetic oil for the internal lubrication. The quantity of oil in the gearbox is planned for the gearbox's lifetime. However, if you need to refill the gearbox with oil for any reason, you must use one of the recommended oil below (ISO VG 220):

Supplier	Reference
MOBIL	SHC 630
SHELL	Omala HD 220
TOTAL	Carter SH 220



Note

The oil in the gearbox does not need to be changed during life of the gearbox.

Continues on next page

3 Maintenance

3.6.1 Gearbox

Continued

Maintenance schedule


Interval	Maintenance activity
First use	Visual inspection Verification of the tightening torque
After the first 500 hours / 3 months	Visual inspection Verification of the tightening torque
Every 3 months	Visual inspection
Every year	Verification of the tightening torque

Visual Inspection

Every 3 months, remove the necessary FlexTrack and carriage side covers and inspect the gearbox. Make sure that there is no mark of wear or damages to the gearbox, and that there is no oil leak.

Verification of the tightening torque

Every year, make sure that the tightening torque of the hexagon socket head cap M6x25 class 12.9 screws that secure the gearbox to the bracket is 16.5 Nm:

	Action	Note/Illustration
1	Separate the carriage bracket holding the gearbox and motor from the carriage, and move the carriage away. For the procedure about how to move the carriage away, see Disassemble the bracket from the carriage on page 160 .	
2	The tightening torque of the hexagon socket head cap M6x25 class 12.9 screws that secure the gearbox to the bracket is 16.5 Nm.	Section view:  xx1800001992

3.7 Activities 6 Months


3.7.1 Anti-collision system function test

General

It is recommended to do the function test on the anti-collision system every six months.

Location

The figure below shows the location of the anti-collision system on the carriage:



xx2000002596

A	Laser scanner
B	Laser reflector

Function test on anti-collision system

The procedure below details how to perform cleaning and, if necessary, lubrication of the linear rails.



Note

Use lint free cloth.

	Action	Note/Illustration
1	Jog and move the carriage to get close to the other carriage.	
2	Inspect if the moved carriage have a collision with the other carriage or not.	
3	If there is a collision, check that: <ul style="list-style-type: none"> Is there any damage on the laser scanner. If yes, replace it. Are the laser scanner and reflector installed on the correct location. If not, reinstall them to make sure that the laser scanner and reflector are in a line. 	

3 Maintenance

3.8.1 Replacement, SMB Battery pack

3.8 Activities 36 Months

3.8.1 Replacement, SMB Battery pack

General

The SMB box contains a main board and a battery for the memory backup in order to maintain position data.

SMB boxes manufactured before 2015 are equipped with a SMB board DSQC633 (Ref. 3HAC031851-001) and a SMB battery (Ref. 3HAC16831-1).


SMB boxes manufactured after 2015 are equipped with a SMB board RMU101 (Ref. 3HAC044168-001) and a Battery pack RMU (Ref. 3HAC044075-001).

The battery should be replaced every three years or when the battery is going flat. This is generally shown by an error code on the FlexPendant screen (38213). Information about error codes can be found in the FlexPendant documentation.



Note

In a new system the batteries are charged to full capacity after a few hours in STANDBY mode.




xx1800001993

Continues on next page

Instructions

Replace the SMB battery as follows:

	Action	Note
1	Position first the carriage in the calibration position (align the synchronization gauges).	 <p>xx1800001994</p>
2	Switch off the power on the SMB box.	 <p>WARNING</p> <p>Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and for the FlexTrack IRT 501.</p>
3	Open the SMB box and locate the battery.	
4	Cut the plastic straps.	
5	Unplug the 2 wires cable from the board and remove the battery pack.	
6	Place the new battery pack, plug the connector on the board, and secure the pack with straps.	
7	Close the SMB box, switch on the power.	
8	Update the revolution counters of the axis.	

This page is intentionally left blank

4 Repair

4.1 Instruction

Structure of the this chapter

This chapter details all repair activities recommended for the FlexTrack IRT 501-66/66R/90/90R/90RE/90RS and any external unit. Each procedure contains all information required to perform the activity, e.g. required tools and materials.

Safety information

Before any service work is commenced, it is extremely important that all safety information is observed! There are general safety aspects that must be read through, as well as more specific safety information that describe danger and safety risks when performing the procedures. Read [Safety on page 15](#) before performing any service work.

**WARNING**

Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.

4 Repair


4.2 Replace the linear rails

4.2 Replace the linear rails

Location

There are 3 different lengths of linear rail sections, depending on its position on the FlexTrack. If you need to replace one or more sections of linear rail, make sure that you order the right parts. See [Spare parts on page 195](#) at the end of this manual to find the correct part number.

The figure below shows the location of the linear rails:




xx1800001995

A	Linear rails
---	--------------

Linear rail of different supplier

Linear rail of ABB FlexTrack has two suppliers, Rexroth and INA, and these two types are not compatible with each other.

The figure below shows the differences of two different suppliers:



xx1800001996

Continues on next page

Linear rails

Bearing blocks

Contrast points	INA	Rexroth
Marking of the brand on the linear rails	No	Yes
Chamfers at the ends of each piece of linear rail	No	Yes
Chamfers at the ends of the FlexTrack	Yes	Yes
Color of the side casing of the ball block	Green	Black

Required equipment

Equipment	Note
Standard toolkit	The content is defined in Standard toolkit on page 120 .
Rail pressing tool IRT501-66/66R: 3HAW107700358 IRT501-90/90R: 3HAW107700456	The rail pressing tool is part of the kit of tools necessary to assemble the FlexTrack. See Procedure of assembly on page 64 .
Ball bearings block	It is recommended to use one spare ball bearing block to verify the alignment of the rails.
Loctite 243	Apply Loctite 243 on the screws that hold the linear rails.

When you install new linear rails, it is necessary to lubricate them manually.

Use one of the recommended lubricants:

Equipment	Note
Lubricant	CASTROL Longtime PD0
Lubricant	Shell Gadus S2 V220 00
Lubricant	TOTAL Multis EP 0
Lint free cloth	

Disassemble

Follow the directions below to disassemble the linear rail:


	Action	Note
1	 WARNING Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.	
2	Remove all necessary FlexTrack covers and disassemble all hexagon head M12x35 class 12.9 screws with contactlock washers M12-27 and plain washers 12x32x4 which hold the linear rail to the sidemember.	As the linear rail screws should have been tightened with Loctite 243, you may have to apply high force on the wrench.

Continues on next page


4 Repair

4.2 Replace the linear rails


Continued

	Action	Note
3	Remove the linear rail.	 xx1800001997

Assemble

	Action	Note/Illustration
1	 WARNING Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.	
2	Assemble linear rails using the all the hexagon head M12x35 class 12.9 screws with contact-lock washers M12-27 and plain washers 12x32x4. Use the rail pressing tool to make sure that the rails are pushed against the sidemember mounting surface. Use standard tools to slightly tighten the screws.	 xx1800001998

Continues on next page

	Action	Note/Illustration
3	<p>Check the rails alignment:</p> <p>Use a ball bearing block or a square ruler; if you do not have a spare block or a square ruler, disassemble one from the carriage (remove the 4 pcs hexagon head M10X30 class 12.9 screws).</p> <p>If the linear rails are correctly aligned, you should sense no "step" while passing the rail junction points. If you do, then push the rail against the side member step, using the rail pressing tool, and make sure that there is 0.2 mm gap between adjacent rails. When the alignment is correct, tighten the screws one by one, after applying Loctite 243 on its thread.</p> <p>(Tightening torque: 132 Nm)</p> <p>If necessary, re-assemble the block in the carriage bracket and tighten its 4 pcs screws (Tightening torque: 77 Nm.)</p>	 <p>xx1800001999</p>  <p>xx1800002000</p> <p> WARNING</p> <p>If you need to remove the block out of the rails, make sure you use the bearing protection to prevent the balls from falling out.</p>
4	<p>Once you have tightened a screw, mark the screw head with a white marker.</p>	 <p>xx1800002021</p>
5	<p>Use a brush to lubricate the linear rails.</p>	
6	<p>Re-assemble the FlexTrack covers.</p>	


4 Repair

4.3 Replace the ball bearing blocks

4.3 Replace the ball bearing blocks

Location

The figure below shows the location of the ball bearing blocks and other key parts:



xx1800002022

A	Ball bearing blocks
B	Carriage bracket
C	4 pcs hexagon head M10x30 class 12.9 screws and 4x M10-16 narrow contact-lock washers
D	Linear rail
E	Mechanical stop (supports + rubber hard stop)
F	End cover

Required equipment

Equipment	Note
Standard toolkit	The content is defined in Standard toolkit .
Lubrication gun	
Jack >2t	



Use one of the recommended lubricants:

Equipment	Note
Lubricant	CASTROL Longtime PD0
Lubricant	Shell Gadus S2 V220 00
Lubricant	TOTAL Multis EP 0
Lint free cloth	

Continues on next page

Disassemble

Follow the instructions below to disassemble the bearing block:


	Action	Note/Illustration
1	<p> WARNING</p> <p>When doing manual jogging with power and pneumatic on inside the cell (Max at 10%), the maintenance personnel should stay away from motion unit in safe area.</p>	
2	<p>If there is a robot on the track, move the robot in the opposite direction from the bracket in order to unload it.</p>	 <p>xx1800002023</p>
3	<p> WARNING</p> <p>Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.</p>	
4	<p>Disassemble the necessary carriage side cover, the FlexTrack end cover (if present) and the mechanical stop.</p>	
5	<p>If there is no robot on the track, loose the screws connecting the bearing support and mounting plate more than 1 mm.</p> <p>Use a jack to secure the height of the carriage plate (don't rise it more than 1 mm).</p> <p> WARNING</p> <p>Rising the carriage more then 1 mm can seriously damage the remaining three ball bearing blocks.</p>	 <p>xx2000002609</p>
6	<p>Unplug the lubrication pipe from the bearing block.</p>	
7	<p>Remove the 4 pcs hexagon head M10X30 class 12.9 screws and 4 pcs M10-16 narrow contact-lock washers.</p>	

Continues on next page


4 Repair

4.3 Replace the ball bearing blocks

Continued


	Action	Note/Illustration
8	<p>Let the block slide out of the bracket and linear rail.</p> <p> Note</p> <p>If the block can be slid out from the end of the track, slide it out from the end of the track. Otherwise, disassemble a nearby rail and slide out the block.</p> <p>For detail procedures, see Disassemble on page 149.</p>	 <p>xx1800002024</p>

Assemble

	Action	Note/Illustration
1	<p> WARNING</p> <p>Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.</p>	
2	Remove one standard screw on the new block for the grease pipe.	
3	Insert the grease pipe fitting to the screw hole.	
4	<p>The fitting must be on the inside of the carriage, and the reference surface (with no marking) on the upper face of the block.</p> <p> Tip</p> <p>For the middle block on six bearing track, both sides can be used for the fitting.</p>	 <p>xx2000002610</p>

Continues on next page

4.3 Replace the ball bearing blocks
Continued

	Action	Note/Illustration				
5	Insert it onto the rail. Pay attention to the position of the fittings which must be on the inside of the carriage.	 <p>xx1800002026</p> <p>ATTENTION: Do not remove the black plastic protection of the bearings until you slide the block onto the rail. They will come out automatically.</p>  <p>xx1800002027</p> <table border="1" data-bbox="1059 1003 1436 1093"> <tr> <td>A</td> <td>Ball bearing block</td> </tr> <tr> <td>B</td> <td>Plastic bearing protection</td> </tr> </table>	A	Ball bearing block	B	Plastic bearing protection
A	Ball bearing block					
B	Plastic bearing protection					
6	Inject grease in the block. During the operation, watch the seals at the ball bearing block: when you see the grease pouring out, you have applied enough grease.					
7	Let the bearings block slide into the bracket and tighten the 4 pcs hexagon head M10X30 class 12.9 screws and 4 pcs M10-16 narrow contact-lock washers, applying Loctite 243 on their thread. (Tightening torque: 77 Nm)					
8	Remove the jack.					
9	Re-connect the lubrication pipe.					
10	Re-assemble the mechanical stop and the covers.					


4 Repair

4.4 Replace the racks

4.4 Replace the racks

Location

The figure below shows the location of the gearbox racks and pinion:



xx1800002028

A	Pinion
B	Rack

Required equipment

Equipment	Note
Standard toolkit	The content is defined in Standard toolkit on page 120 .
Rack clamps 3HAW107700357	The rack clamps are part of the kit of tools necessary to assemble the FlexTrack. See Procedure of assembly on page 64 .
Mounting rack 3HAWL000011	The mounting rack is part of the kit of tools necessary to assemble the FlexTrack. See Procedure of assembly on page 64 .
Loctite 243	Apply Loctite 243 on the screws that hold the racks.


Continues on next page

When you install new racks, it is necessary to lubricate them manually. Use one of the recommended lubricants:

Equipment	Note
Lubricant	CASTROL Longtime PD0
Lubricant	Shell Gadus S2 V220 00
Lubricant	TOTAL Multis EP 0
Lint free cloth	

Disassemble

Follow the directions below to disassemble the racks:

	Action	Note/Illustration
1	 WARNING Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.	
2	Remove all necessary FlexTrack covers and disassemble all hexagon head M8x55 screws class 12.9 with contact-lock washers M8-18 and flat washers 8x25x3 that hold the rack to the sidemember.	As the rack screws should have been tightened with Loctite 243, you may have to apply high force on the wrench.
3	Remove the rack.	 xx1800002029

Assemble

Follow the directions below to assemble the racks:


	Action	Note
1	 WARNING Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.	

Continues on next page

4 Repair

4.4 Replace the racks

Continued

	Action	Note
2	<p>Assemble the racks using the hexagon head M8x55 screws class 12.9 with contact-lock washers M8-18 and flat washers 8x25x3.</p> <p>Use the clamping and mounting racks at the ends of the rack section to make sure that the racks are pushed against the sidemember mounting surface and perfectly aligned with each other.</p> <p>Use standard tools, slightly tighten.</p>	 <p>xx1800002030</p>  <p>xx1800002031</p>
3	<p>When you are confident that the alignment is correct, tighten the screws one by one, after applying Loctite 243 on their thread.</p> <p>(Tightening torque: 40 Nm)</p>	
4	<p>Once you have tightened a screw, mark it with a white marker.</p>	 <p>xx1800002032</p>
5	<p>Use a brush to lubricate the racks.</p>	
6	<p>Re-assemble the FlexTrack covers.</p>	


4.5 Motor and gearbox

4.5.1 Overview

It is possible to remove the motor and /or the gearbox what ever the position of the carriage or the tooling/robot on top. It is recommended to have 2 technicians to work together.

Location

The figure below shows the location of the motor and the gearbox:



xx1800002033

A	Bracket
B	Gear
C	Motor

4 Repair


4.5.2 Disassemble the bracket from the carriage

4.5.2 Disassemble the bracket from the carriage

Overview

To replace the motor and/or the gearbox, it is possible to disassemble the motor bracket from the top plate and then push the carriage away. It is recommended to have 2 technicians to work together.

The figure below shows how pushing the carriage away from the motor bracket exposes the motor, gearbox and cable chain connection point. This makes the following components accessible for maintenance:



xx1800002034

A	Carriage - pushed away
B	Motor bracket - remains stationary
C	Motor - remains stationary
D	Gearbox - remains stationary
E	Pinion - remains stationary
F	Cable chain - remains stationary

Required equipment



Equipment	Note
Standard toolkit	The content is defined in Standard toolkit on page 120 .
Torque wrench	The tightening torque of the hexagon socket head cap M6x25 class 12.9 screws that secure the gearbox to the bracket is 16.5 Nm. There are also specific tightening torques for the motor shaft and gearbox assembly. See the details in maintenance instructions.

Continues on next page

4.5.2 Disassemble the bracket from the carriage
Continued

Equipment	Note
<p>For the dowel pin extraction, you will need: M6 screws of different lengths. For example: M6x10, M6x15, M6x35 1 thick washer inside diameter 6mm 1 spacer 30 mm long, inside diameter no smaller than the dowel pin diameter (10 mm), and outside diameter no bigger than the thick washer outside diameter.</p>	

Instructions


	Action	Note
1	 WARNING When doing manual jogging with power and pneumatic on inside the cell (Max at 10%), the maintenance personnel should stay away from motion unit in safe area.	
2	<p>If a robot is mounted on the carriage, move its arm to the opposite side of the motor bracket in order to unload it.</p>	 <p>xx1800002035</p>
3	 WARNING Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.	
4	<p>Disassemble the necessary carriage side cover, the FlexTrack end cover (if present) and the mechanical stop.</p>	
5	<p>If there is no robot on the track, loose the screws connecting the bearing support and mounting plate more than 1 mm. Use a jack to secure the height of the carriage plate (don't rise it more than 1 mm).</p>  WARNING Rising the carriage more then 1 mm can seriously damage the remaining three ball bearing blocks.	 <p>xx2000002609</p>

Continues on next page

4 Repair





4.5.2 Disassemble the bracket from the carriage

Continued

	Action	Note
6	Loosen the 4 pcs M12x55 class 12.9 screws. Use a ratchet wrench.	 xx1800002036
7	Extraction of the dowel: Place the spacer on the dowel pin, insert the longest screw with the thick washer and screw it to start extracting the dowel. Use shorter screws when necessary.	 xx1800002037
8	Stop when the dowel pin is extracted from the top plate. It is not necessary to extract it from the bracket.	 xx1800002038
9	Remove the 4 pcs M12x55 class 12.9 screws and contact-lock washers M12-24. Use a ratchet wrench.	 xx1800002036
10	Disconnect the 2 lubrication tubes from the fitting of the ball bearing block and from the support located near the pinion. Loosen all the clamps (circled in red on the picture) to release the tubes from the bracket (the tubes will be pushed away along with the carriage).	 xx1800002039

Continues on next page

4.5.2 Disassemble the bracket from the carriage
Continued

	Action	Note								
11	If present, disconnect the cables from the tooling or robot mounted on the carriage. Remove the upper part of the cable tray so that the connectors can pass through.	 <p>xx1800002040</p>								
12	Push the carriage away from the bracket. The bracket, gearbox and pinion, motor, cable chain support and cable chain, stay stationary. If present, pay attention to the cables and their connectors: You must guide them through the cable tray while you push the carriage away.	 <p>xx1800002041</p>  <p>xx1800002042</p> <table border="1" data-bbox="1059 1189 1436 1323"> <tr> <td>A</td> <td>Carriage</td> </tr> <tr> <td>B</td> <td>Motor bracket</td> </tr> <tr> <td>C</td> <td>Cable tray</td> </tr> </table>	A	Carriage	B	Motor bracket	C	Cable tray		
A	Carriage									
B	Motor bracket									
C	Cable tray									
13	Remove the covers. The drive unit is now accessible.	 <p>xx1800002043</p> <table border="1" data-bbox="1059 1682 1436 1861"> <tr> <td>A</td> <td>Motor</td> </tr> <tr> <td>B</td> <td>Gearbox</td> </tr> <tr> <td>C</td> <td>Pinion</td> </tr> <tr> <td>D</td> <td>Motor bracket</td> </tr> </table>	A	Motor	B	Gearbox	C	Pinion	D	Motor bracket
A	Motor									
B	Gearbox									
C	Pinion									
D	Motor bracket									



4 Repair

4.5.3 Replace motor

4.5.3 Replace motor

Instructions

Follow the directions below to disassemble the motor:



	Action	Note				
1	 WARNING Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.					
2	Unplug the power and resolver plugs from the motor. Guide the cables in the tray area.	 <p data-bbox="1027 994 1136 1012">xx1800002044</p> <table border="1" data-bbox="1027 1032 1410 1126"> <tr> <td data-bbox="1027 1032 1070 1075">A</td> <td data-bbox="1070 1032 1410 1075">Power cable</td> </tr> <tr> <td data-bbox="1027 1075 1070 1126">B</td> <td data-bbox="1070 1075 1410 1126">signal cable</td> </tr> </table>	A	Power cable	B	signal cable
A	Power cable					
B	signal cable					
3	Remove the threaded cover plug to access the motor coupling screw. If you do not see the coupling screw, remove the 4 screws that attach the motor to the gearbox, and rotate the motor until you can see the coupling screw. Untight it (without removing it) and separate the motor from the gearbox.	 <p data-bbox="1027 1559 1136 1576">xx1800002045</p>				
4	Replace the motor. For instructions about how to reassemble the motor to the gearbox and issues that need attention, see Motor and gearbox assembly on page 168					
5	Re-assemble the bracket with the carriage. (Tightening torque: 132 Nm) Re-connect the lubrication pipe to the block and secure it to the bracket with the flanges.	Use hexagon socket head cap M12x55 class 12.9 screws and contact-lock washers M12- 24 tightened at 132 Nm to secure the bracket.				
6	Turn the power on and perform a fine calibration.					

4.5.4 Replace gearbox

Instructions

If you need to replace the gearbox, you must first remove the motor such as described in [Replace motor on page 164, step2](#) and [step3](#) of the disassembly instructions.

Follow the directions below to disassemble the gearbox:



	Action	Note/Illustration
1	 WARNING Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.	
2	Remove the section of rack that is next to the section of rack with which the gearbox pinion is meshing.	Unscrew all the hexagon head M8x55 screws with contact-lock washers M8-18 and flat washers 8x25x3 to remove the rack from the sidemember.  xx1800002046
3	Push the bracket and gearbox out of the rack section.	 xx1800002047
4	Remove the hexagon socket head cap M6x25 class 12.9 screws that secure the gearbox to the bracket and remove the gearbox.	 CAUTION The complete gearbox weighs about 30 kg! All lifting equipment used must be sized accordingly!
5	Replace the gearbox and tighten the hexagon socket head cap M6x25 class 12.9 screws and contact-lock washers M6-12 with a torque wrench. (Tightening torque: 16.5 Nm)	

Continues on next page


4 Repair

4.5.4 Replace gearbox

Continued

	Action	Note/Illustration
6	Push the bracket and gearbox back to the rack section.	 <p>xx1800002048</p>
7	Re-assemble the rack with the sidemember. (Tightening torque: 40 Nm)	<p>Before tightening all the hexagon head M8x55 class 12.9 screws with contact-lock washers M8-18 and flat washers 8x25x3, ensure that the rack section is completely pushed against its mounting surface, using on both of its ends the mounting rack section 3HAWL000011:</p>  <p>xx1800002049</p> <p>and the clamps 3HAW107700357:</p>  <p>xx1800002050</p>
8	Follow the instructions see Motor and gearbox assembly on page 168 .	

Continues on next page

	Action	Note/Illustration
9	If there is pin used to support the bracket, reassemble the pin first.	 <p>xx2000002663</p>
10	Re-assemble the bracket with the carriage. (Tightening torque: 132 Nm) Re-connect the lubrication pipe to the block and secure it to the bracket with the flanges.	Use hexagon socket head cap M12x55 class 12.9 screws and contact-lock washers M12-24 tightened at 132 Nm to secure the bracket.  Tip If there is no pin, pre-install the screws and move the carriage to make sure that the bracket is installed well. Then fasten the screws to secure the bracket.
11	Turn the power on and perform a fine calibration.	See Fine calibration on page 184 .

4 Repair

4.5.5 Motor and gearbox assembly

4.5.5 Motor and gearbox assembly

FlexTrack IRT 501- 66, gearbox ratio $i=10$

The motor for the IRT 501-66 has a shaft diameter = $\varnothing 26$.


The gearbox for the IRT 501-66 has a slotted coupling diameter = $\varnothing 38$.

A slotted ring $\varnothing 26/\varnothing 38$ is mounted into the coupling to tighten the motor shaft.



Note

Slots of both parts must be in line for a maximum tightening force:



Slotted coupling $\varnothing 38$

Slotted ring $\varnothing 26/\varnothing 38$

2 slots in line

xx1800002051

The tightening screw of slotted coupling, SW1 = 8 mm, must be tightened to TA1 = 69 Nm.

The plug, SW2 = 10 mm, must be tightened to TA2 = 50 Nm.

(SW: width across flats. See motor mounting instructions below for details)

Continues on next page

FlexTrack IRT 501- 66R, 90 90R, gearbox ratio i=16 or i=20

The motor for the IRT 501-66R, 90 & 90R has a shaft diameter = Ø22.

Gears for the IRT 501-66R, 90 & 90R have a slotted coupling diameter = Ø28.


A malleable ring Ø24/Ø28 is mounted into the coupling.



A slotted ring Ø22/Ø24 is mounted into the malleable ring to tighten the motor shaft.

xx1800002052

Slots of both parts must be in line for a maximum tightening force:



Slotted coupling Ø28

Slotted ring Ø22/Ø24

2 slots in line

xx1800002053

The tightening screw of slotted coupling, SW1 = 6 mm, must be tightened to TA1 = 35 Nm.

The plug, SW2 = 10 mm, must be tightened to TA2 = 50 Nm.

(SW: width across flats. See motor mounting instructions below for details)

Continues on next page



4 Repair

4.5.5 Motor and gearbox assembly




Continued

Motor assembly

The following instructions are based on the Alpha gearbox and motor assembly manual:

Action/Note/Illustration	
1	 <ul style="list-style-type: none">• Verschlusschraube lösen und aufbewahren• Release plug and reserve• Desserrer le bouchon obturateur et le conserver• Allentare e riporre il tappo a vite• Soltar el tornillo de cierre y conservarlo• Soltar parafuso de fechamento e guardá-lo <p>xx1800002054</p>
2	 <ul style="list-style-type: none">• Gründlich reinigen – keine Pressluft verwenden• Clean thoroughly – do not use compressed air• Nettoyer entièrement – ne pas utiliser d'air comprimé• Pulire accuratamente. Non usare aria compressa• Limpiar a fondo – No usar aire comprimido• Limpar criteriosamente – não usar ar comprimido <p>xx1800002055</p>





Continues on next page

Action/Note/Illustration	
3	<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;">  </div> <div> <ul style="list-style-type: none"> • Lagerichtig drehen • Turn into correct position • Tourner dans la bonne position • Girare in posizione corretta • Girarlo a la posición prescrita • Girar para a posição correta </div> </div> <p style="margin-top: 10px;">xx1800002056</p>
4	<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <ul style="list-style-type: none"> • Bei genuteter Motorwelle: Passfeder entfernen. Schlitz, Distanzhülse und Passfedernut lagerichtig montieren. • With grooved shaft: remove feather key. Mount slot, spacer sleeve and feather key groove in the correct position • Pour les arbres de moteur cannelés: retirer la clavette. Monter la fente, la bague et la rainure pour clavette de manière à ce qu'elles se trouvent dans la bonne position. • Per alberi motore con chiavetta: rimuovere la chiavetta. Montare una mezza chiavetta, la bussola distanziale e posizionare la mezza chiavetta nella posizione corretta. • Si se trata de un eje de motor ranurado: saque la claveta. Montar de acuerdo a la posición prescrita la entalladura, el casquillo y la ranura de la claveta. • No caso de eixo do motor com ranhura: Remover chaveta. Montar fenda, manga distanciadora e chaveta na posição correta. </div> <div style="margin-left: 20px;">  </div> </div> <p style="margin-top: 10px;">xx1800002057</p>
5	<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;">  </div> <div> <ul style="list-style-type: none"> • ACHTUNG! Wenn Sie den Motor nicht leicht aufschieben können: Die Schraube in Bild 4 um eine Umdrehung lösen • CAUTION! If the motor does not move into position easily: Loosen the screw in fig. 4 by one rotation • ATTENTION !! Si le moteur ne peut pas être légèrement poussé: desserrer d'un tour la vis illustrée sur la figure 4 • ATTENZIONE! Se risultasse difficoltoso portare il motore in posizione: allentare di un giro la vite in figura 4 • ¡ATENCIÓN! Si al montar el motor no puede deslizarlo con facilidad: suelte una vuelta el tornillo de la figura 4 • ATENÇÃO! Caso não consiga colocar o motor facilmente: Soltar o parafuso da figura 4 por um giro </div> </div> <p style="margin-top: 10px;">xx1800002058</p>

4 Repair

4.5.5 Motor and gearbox assembly


Continued

	Action/Note/Illustration													
6	 <p data-bbox="481 779 590 801">xx1800002059</p>													
7	 <p data-bbox="481 1321 590 1344">xx1800002060</p>													
8	<div data-bbox="574 1500 734 1579"> <p>SW: Width across flats</p> <p>T_A Tightening torque</p> </div> <div data-bbox="774 1400 973 1635">  </div> <div data-bbox="1133 1400 1348 1635">  </div> <table border="1" data-bbox="494 1691 1061 1825"> <thead> <tr> <th></th> <th>SW₁ [mm]</th> <th>T_{A1} [Nm]</th> </tr> </thead> <tbody> <tr> <td>FlexTrack IRT 501-66, Ratio i=10</td> <td>6</td> <td>39</td> </tr> <tr> <td>FlexTrack IRT 501-66R / 90 / 90R, Ratio i=16 or 20</td> <td>8</td> <td>49</td> </tr> </tbody> </table> <table border="1" data-bbox="1133 1691 1396 1758"> <thead> <tr> <th>SW₂ [mm]</th> <th>T_{A2} [Nm]</th> </tr> </thead> <tbody> <tr> <td>10</td> <td>50</td> </tr> </tbody> </table> <p data-bbox="481 1870 590 1892">xx1800002061</p>		SW ₁ [mm]	T _{A1} [Nm]	FlexTrack IRT 501-66, Ratio i=10	6	39	FlexTrack IRT 501-66R / 90 / 90R, Ratio i=16 or 20	8	49	SW ₂ [mm]	T _{A2} [Nm]	10	50
	SW ₁ [mm]	T _{A1} [Nm]												
FlexTrack IRT 501-66, Ratio i=10	6	39												
FlexTrack IRT 501-66R / 90 / 90R, Ratio i=16 or 20	8	49												
SW ₂ [mm]	T _{A2} [Nm]													
10	50													

4.6 Replace the cable chain or the cable

Overview

It is possible to remove the complete cable chain in order to replace it. It is recommended to have 2 technicians to work together.



xx1800002062

Cable chain of different supplier

Cable chain of ABB FlexTrack has two suppliers, Kabelschlepp and IGUS, which are not compatible with each other.

The following table shows you the difference between two different suppliers:



Kabelschlepp	IGUS
Cable chain link unit	
	
xx1800002063	xx1800002064
Cable separator	

Continues on next page

4 Repair

4.6 Replace the cable chain or the cable

Continued

Kabelschlepp	IGUS
	
xx1800002065	xx1800002066
Cable chain end units, Tiewrap plate	
	
xx1800002067	xx1800002069
	
xx1800002068	

Required equipment






Equipment	Note
Standard toolkit	The content is defined in section 3.2, standard toolkit .
Cables	
Cable chain parts	

Replace cable chain

 Tip Remove all cover plates before turning off all electric power. Without 24V DC the carriage can not be moved.		
	Action	Note/Illustration
1	 WARNING When doing manual jogging with power and pneumatic on inside the cell (Max at 10%), the maintenance personnel should stay away from motion unit in safe area.	

Continues on next page

4.6 Replace the cable chain or the cable
Continued


	Action	Note/Illustration
2	Jog and move the track carriage in order to have it positioned just above the fixed point of the cable chain. Doing so you just have to remove two covers in the same zone to access both fixed & moving points of the cable chain.	 <p>Moving point</p> <p>Fixed point</p> <p>xx1800002070</p>
3	 <p>WARNING</p> <p>Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.</p>	
4	Remove two covers.	 <p>xx1800002071</p>
5	Open the cable chain opening and separate the cables from cable chain.	
6	Remove screws at fixed point, pull-out cable chain, help the cables through the carriage opening.	 <p>xx1800002072</p>
7	 <p>Tip</p> <p>To facilitate assembly, take a picture of the placement in the cable chain before removing cables.</p>	 <p>xx1800002073</p>
8	Remove screws at fixed point, pull the complete chain out.	 <p>xx1800002074</p>

Continues on next page

4 Repair

4.6 Replace the cable chain or the cable

Continued

	Action	Note/Illustration
9	Install the new cable chain, and ensure the correct installation as described in Installation of the cable chain on page 84 .	 xx1800001922

Replace cables





Tip

Remove all cover plates before turning off all electric power. Without 24V DC the carriage can not be moved.








WARNING

When doing manual jogging with power and pneumatic on inside the cell (Max at 10%), the maintenance personnel should stay away from motion unit in safe area.

	Action	Note/Illustration
1	 WARNING When doing manual jogging with power and pneumatic on inside the cell (Max at 10%), the maintenance personnel should stay away from motion unit in safe area.	
2	Move the track carriage in order to have it positioned just above the fixed point of the cable chain. Doing so you just have to remove two covers in the same zone to access both fixed & moving points of the cable chain.	 xx1800002070
3	 WARNING Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.	
4	Remove two covers.	 xx1800002071

Continues on next page

4.6 Replace the cable chain or the cable
Continued



	Action	Note/Illustration						
5	Open the cable chain opening and separate the cables from cable chain.							
6	Remove screws at the fixed point on the carriage, pull-out cable chain, help the cables through the carriage opening.	 <p>xx1800002072</p>						
7	Remove screws at the opposite fixed point on the ground, pull the complete chain out.	 <p>xx1800002074</p>						
8	<p> Tip</p> <p>Before removing damaged cables, take a picture of the placement of the cables on the connect plate. This will facilitate reassembly.</p>	 <p>xx1800002075</p> <table border="1" data-bbox="1059 1167 1430 1234"> <tr> <td>X</td> <td>Cable length projecting from the cable chain</td> </tr> </table>  <p>xx1800002073</p>	X	Cable length projecting from the cable chain				
X	Cable length projecting from the cable chain							
9	Cut off the ties that fix the cables to the tiwrap plate and cable chain end unit at the fix end and moving end of the cable chain.	 <p>xx1800002076</p> <table border="1" data-bbox="1059 1727 1430 1912"> <tr> <td>A</td> <td>Tiewrap plate of the fix end cable chain</td> </tr> <tr> <td>B</td> <td>End unit of the move end cable chain</td> </tr> <tr> <td>C</td> <td>Ties fixing cables</td> </tr> </table>	A	Tiewrap plate of the fix end cable chain	B	End unit of the move end cable chain	C	Ties fixing cables
A	Tiewrap plate of the fix end cable chain							
B	End unit of the move end cable chain							
C	Ties fixing cables							

Continues on next page

4 Repair

4.6 Replace the cable chain or the cable


Continued

	Action	Note/Illustration						
10	Open the cover strips of the cable chain.	 <p>xx1800001920</p>						
11	Remove the cables.							
12	Install the new cables. Make sure the replacement cable is at the same position and is projecting the same length with the old one.							
13	Close the cover of the cable chain.							
14	Fix the cable on the tiewrap plate and the cable chain end unit with ties.	 <p>xx1800002076</p> <table border="1" data-bbox="1029 1064 1404 1265"> <tr> <td data-bbox="1029 1064 1069 1131">A</td> <td data-bbox="1069 1064 1404 1131">Tiewrap plate of the fix end cable chain</td> </tr> <tr> <td data-bbox="1029 1131 1069 1198">B</td> <td data-bbox="1069 1131 1404 1198">End unit of the move end cable chain</td> </tr> <tr> <td data-bbox="1029 1198 1069 1265">C</td> <td data-bbox="1069 1198 1404 1265">Ties fixing cables</td> </tr> </table>	A	Tiewrap plate of the fix end cable chain	B	End unit of the move end cable chain	C	Ties fixing cables
A	Tiewrap plate of the fix end cable chain							
B	End unit of the move end cable chain							
C	Ties fixing cables							
15	Reinstall the new cable chain, and ensure the correct installation as described in Installation of the cable chain on page 84 .	 <p>xx1800001922</p>						

4.7 Replace the laser scanner and reflector

Location

The figure below shows the location of the laser scanner and reflector:



xx2000002595

	Description
A	Laser scanner
B	Laser reflector

Required equipment

Equipment	Note
Standard toolkit	The content is defined in Standard toolkit on page 120 .
Loctite 243	Apply Loctite 243 on the screws that hold the linear rails.

Disassemble

Follow the directions below to disassemble the laser scanner and the reflector:




	Action	Note
1	 WARNING Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.	

Continues on next page

4 Repair

4.7 Replace the laser scanner and reflector

Continued

	Action	Note
2	Disconnect the movement cable from the laser scanner.	 xx2000002599
3	Remove the screws locking the laser scanner to the bracket.	 xx2000002607
4	Remove the laser scanner.	
5	Remove the screws locking the laser reflector to the bracket.	 xx2000002608
6	Remove the laser reflector.	




Assemble

	Action	Note/Illustration
1	 WARNING Turn off all electric power, hydraulic and pneumatic pressure supplies to the robot and FlexTrack IRT 501 before doing any repairing work.	

Continues on next page

4.7 Replace the laser scanner and reflector

Continued

	Action	Note/Illustration
2	Refit the laser reflector to the bracket and secure with screws.	<p>Screws: 2 pcs x M3x10 Tightening torque: 1.3 Nm</p>  <p>xx2000002608</p>
3	Refit the laser scanner to the bracket and secure with screws.	<p>Screws: 2 pcs x M4x50 Tightening torque: 3 Nm</p>  <p>xx2000002607</p>
4	Reconnect the movement cable to the laser scanner.	 <p>xx2000002599</p>

This page is intentionally left blank

5 Calibration

5.1 Overview

General

This chapter includes general information about different calibration methods and detailed procedures that do not require specific calibration equipment.

When the robot system must be recalibrated, it is done according to the documentation enclosed with the calibration tools.



WARNING

Make sure no persons are on the FlexTrack when the carriage is in motion. Also make sure that the FlexTrack's cover plates are free from loose objects, otherwise they can get trapped between the carriage and the plates.



Note

The FlexTrack does not need to be calibrated during restart. The resolvers only need to be calibrated when commissioning the system.

When to calibrate

The system must be calibrated if any of the below occurs.

The resolver values are changed

If resolver values are changed, the robot must be recalibrated using the calibration methods supplied from ABB. Calibrate the FlexTrack IRT 501 carefully with standard calibration. The resolver values will change when parts affecting the calibration position are replaced on the FlexTrack IRT 501, e.g. motor, or part of transmission. This is detailed in [Fine calibration on page 184](#).

Contents of the revolution counter memory are lost

If the contents of the revolution counter memory are lost, the counters must be updated as detailed in [Update revolution counters on page 185](#). This will occur when:

- the battery is discharged
- a resolver error occurs
- the signal between a resolver and measurement board is interrupted
- a robot axis is moved with the control system disconnected

The revolution counters must also be updated after the robot and controller are connected at the first installation.

The FlexTrack IRT 501 is rebuilt

If the track has been rebuilt, e.g. after a crash or when the track has been changed for other reachability, it needs to be recalibrated for new resolver values. This is detailed in [Fine calibration on page 184](#).


5 Calibration

5.2 Fine calibration

5.2 Fine calibration

General


This procedure must be applied at the first start or after mechanical intervention (motor change, gearbox).

	Action	Note/Illustration
1	Using the FlexPendant, jog the carriage close to the calibration gauge position.	
2	Jog the carriage to move it until the calibration holes line up.	 xx1800002077
3	Insert the calibration pin (3HAW107700354). A dowel pin diameter 8 mm can also be used.	 xx1800001960
4	Tap ABB on the top left of the FlexPendant	
5	Tap Calibration .	
6	Select the desired mechanical unit.	
7	Tap Fine calibration .	
8	Select the desired axis.	
9	Tap Calibrate .	

5.3 Update revolution counters

Procedure

This procedure must be applied if revolution counter value is loss for the Track.

	Action	Note/Illustration
1	Align the sharp edge of the moving part of the calibration marker with the line of the fixed part calibration marker.	 xx1800002078
2	Tap ABB on the top left of the FlexPendant.	
3	Tap Calibration .	
4	Select the desired mechanical unit.	
5	Tap Update revolution counters .	
6	Select the desired axis.	
7	Tap Update .	

This page is intentionally left blank

6 Decommissioning

6.1 Introduction

Introduction

This chapter contains information to consider when taking a product, robot or controller, out of operation.

It details with how to handle potentially dangerous components and potentially hazardous material.

General

All used grease/oils and dead batteries must be disposed of in accordance with the current legislation of the country in which the robot and the control unit are installed.

If the robot or the control unit is partially or completely disposed of, the various parts must be grouped together according to their nature (that is, all iron together and all plastic together), and disposed of accordingly. These parts must also be disposed of in accordance with the current legislation of the country in which the robot and control unit are installed.


6 Decommissioning

6.2 Environmental information

6.2 Environmental information

Symbol

The following symbol indicates that the product must not be disposed of as common garbage. Handle each product according to local regulations for the respective content (see table below).



xx1800000058

Hazardous material

The table specifies some of the materials in the product and their respective use throughout the product.

Dispose components properly to prevent health or environmental hazards.

Material	Example application
Batteries, NiCad or Lithium	Serial measurement board
Copper	Cables, motors
Cast iron/nodular iron	Crossmembers, linear carriage brackets
Steel	Covers, sidemembers, carriage top plate, screws
Neodymium	Brakes, motors
Plastic/rubber (PVC)	Cables, connectors, hard stop bumper
Oil, grease	Lubrication system, gearbox
Aluminium	Motor and gearbox housing

Continues on next page

Oil and grease

Where possible, arrange for oil and grease to be recycled. Dispose of via an authorized person/contractor in accordance with local regulations. Do not dispose of oil and grease near lakes, ponds, ditches, down drains, or onto soil. Incineration must be carried out under controlled conditions in accordance with local regulations.

Also note that:

- Spills can form a film on water surfaces causing damage to organisms. Oxygen transfer could also be impaired.
- Spillage can penetrate the soil causing ground water contamination.

This page is intentionally left blank

7 Reference information

7.1 Introduction

General

This chapter includes general information, complementing the more specific information in the different procedures in the manual.

7 Reference information

7.2 Applicable safety standards

7.2 Applicable safety standards

Standards, EN ISO

The robot system is designed in accordance with the requirements of:

Standard	Description
EN ISO 12100-1	Safety of machinery - Basic terminology
EN ISO 12100-2	Safety of machinery - Technical principles/specifications - Emergency stop
EN ISO 13850	Safety of machinery - Emergency stop - Principles for design
EN ISO 13851: 2019-11	Safety of machinery, two hand control device
EN ISO 13732	Ergonomics of the thermal environment - Part 1
EN ISO 10218-1	Robots for industrial environments - Safety requirements - Part 1 Robot
EN ISO 60204-1	Safety of machinery - Electrical equipment of machines - Part 1 General requirement
EN ISO 13849-2	Safety of machinery, safety related parts of the control system - Part 2 Validation
EN ISO 13857	Safety of machinery -- Safety distances to prevent hazard zones being reached by upper and lower limbs
EN ISO 14010	Guidelines for environmental auditing - General principles
EN ISO 14120: 2016-05	Safety of machinery, fixed/movable guards
EN ISO 14121-2	Safety of machinery -- Risk assessment -- Part 2: Practical guidance and examples of methods
EN ISO 14122	Safety of machinery -- Permanent means of access to machinery

European standards

Standard	Description
EN 614-1	Safety of machinery, ergonomic design principles
EN 61000-6-4: 2007 + A1: 2011 IEC 61000-6-4: 2006 + A1: 2010 (option 129-1)	EMC, Generic emission
EN 61000-6-2: 2005 IEC 61000-6-2: 2005	EMC, Generic immunity

7.3 Unit conversion

Converter table

Use the following table to convert units used in this manual.


Quantity	Units		
Length	1 m	3.28 ft.	39.37 in
Weight	1 kg	2.21 lb.	
Weight	1 g	0.035 ounces	
Pressure	1 bar	100 kPa	14.5 psi
Force	1 N	0.225 lbf	
Moment	1 Nm	0.738 lbf-ft	
Volume	1 L	0.264 US gal	

This page is intentionally left blank

8 Spare parts


8.1 Carriage IRT501

With four bearings



xx1800001862

With six bearings



xx2000002590

Continues on next page


8 Spare parts

8.1 Carriage IRT501

Continued

Item	Quantity	ABB part reference no.	Description	IRT501-66	IRT501-66R	IRT501-90	IRT501-90R	IRT501-90RE	IRT501-90RS
A	1	3HAWC116592	Motor	1					1
		3HAWC116593	Motor		1	1	1	1	
		3HAW107710190	Motor		1	1	1	1	
B	1	3HAWC116589	Gearbox + pinion	1					
		3HAWC116590	Gearbox + pinion		1	1			
		3HAWC116596	Gearbox + pinion				1	1	
		3HAW107710281	Gearbox + pinion						1
C	4	3HAWL000021	Ball bearing block (Rexroth)	4	4	4	4	6	6
		3HAWC116594	Ball bearing block (INA)	4	4	4	4	6	6
D	4	3HAWL000049	D6-M6 lubrication elbow fitting	4	4	4	4	6	6

8.2 Track



xx1800002080

Item	ABB part reference no.	Description
A	3HAWL000016	Linear rail 2,625 mm (Rexroth)
	3HAWL000015	Linear rail 2,100 mm (Rexroth)
	3HAWL000014	Linear rail 1,575 mm (Rexroth)
	3HAWC116829	Linear rail 2,625 mm (INA)
	3HAWC116827	Linear rail 2,100 mm (INA)
	3HAWC116828	Linear rail 1,575 mm (INA)
B	3HAW107700347	Toothed rack 1,000 mm
	3HAW107720000	Toothed rack 1,000 mm
C	3HAW107700342	Rack cover
D	3HAW107700343	Upper cover for FlexTrack IRT 501-66 & 66R
	3HAW107700431	Upper cover for FlexTrack IRT 501-90 & 90R
E	3HAW107700337	Bracket for cover for FlexTrack IRT 501-66 & 66R
	3HAW107700430	Bracket for cover for FlexTrack IRT 501-90 & 90R
F	3HAW107700359	Cable tray L=1,050 mm
G	3HAW108201422	Levelling screw M60 x 2
H	3HAWC100857	Slotted round nut KM 12


**Note**

For how to identify cable chain from different supplier, see [Linear rail of different supplier on page 148](#).

8 Spare parts

8.3 Limit switch and calibration

8.3 Limit switch and calibration




xx1800002081

Item	Quantity	ABB part reference no.	Description
A	1	3HAWC116586	Limit switch 1 sensor
		3HAW107710206	Limit switch 2 sensor
		3HAWL000022	Limit switch 4 sensor
B	1	3HAWC116599	Limit switch cam tray L=1,000 mm
		3HAW107700657	Limit switch cam tray L=1,200 mm
C	2(min)	3HAWC116600	Cam (on both ends of the FlexTrack)
D	4	3HAWC106195	Hard stop bumper (a pair on both ends of the FlexTrack)
E	1	3HAW107700344	Calibration gauge (fixed, on FlexTrack)
		3HAW107700540	Calibration gauge (mobile, on carriage)
-	1	3HAW107700354	Calibration pin

8.4 Automatic lubrication system

Lubrication system



xx1800002082

Item	Quantity	ABB part reference no.	Description
A	1	3HAW107700590-004	Automatic lubrication, complete kit for 1 carriage. Contain all items below.
B	1	3HAWC116978	240cc HPS Mega grease cartridge + battery
C	1	3HAWC114278	Automatic grease dispenser Memolub HPSMEGA
	1	3HAW060012002	Grease dispenser Memolub Pump EPS
D	1	3HAWL000050	Set of washers for automatic oil dispenser output volume setting
E	0.2 m	3HAWC116980	Tube D8x6 (from dispenser to splitter only)
F	1	3HAWC116979	Grease splitter 6 outputs
		3HAW050040462	Grease splitter 8 outputs
G	25 m	3HAWL000032	Tube D6x4. 5 m are required in one carriage.


Continues on next page

8 Spare parts

8.4 Automatic lubrication system

Continued

Feedback



xx2200000627

Item	Quantity	ABB part reference no.	Description
A	1	3HAW107710204	Switch
B	1	3HAW107710205	M12 Connector
C	1	3HAWC116988	M12 Cable
	1	3HAWC116987	M12 Cable
	1	3HAWC116986	M12 Cable
	1	3HAW050059800	M12 Cable
	1	3HAW050059801	M12 Cable

8.5 Cable chains

Formula


If you need to replace elements of the cable chain, please calculate your needs: The cable chain is made of modular elements which quantity depends on the stroke of your FlexTrack.

S is the Stroke of the FlexTrack in mm (from hard stop to hard stop)

L is the length of the cable chain in mm

$$L = S/2 + 510$$

Internal chain spare parts



xx1800002083

Item	Quantity	ABB part reference no.	Description
A	1 m chain requires 15 pcs	3HAWL000017	Cable chain link unit (Kabelschlepp)
		3HAWL000051	Cable chain link unit (IGUS)
B	1 m chain requires 28 pcs	3HAWL000018	Cable chain link unit (Kabelschlepp)
		3HAWL000053	Cable chain link unit (IGUS)
C	1	3HAWL000019	Cable chain end units (1 mobile + 1 fixed) (Kabelschlepp)
D	1	3HAWL000020	Tiewrap plate (1 per cable chain) (Kabelschlepp)
C & D	1	3HAWL000052	Cable chain end units (1 mobile + 1 fixed), Tiewrap plate (1 per cable chain) (IGUS)



Note

For how to identify cable chain from different supplier, see [Cable chain of different supplier on page 173](#).

Continues on next page

8 Spare parts


8.5 Cable chains

Continued

External chain spare parts

If the internal cable chain is not wide enough to fit all the required cables, a wider external cable chain, assembled in a complete housing for optimal protection, may be used.

This option is used only on FlexTrack types IRT 501-90 and IRT 501-90R.



xx1800002084

Item	Quantity	ABB part reference no.	Description
A	1 m of chain requires 15 pcs	3HAWL000042	External cable chain link unit (Kabelschlepp)
		3HAW107710233	External cable chain link unit (IGUS)
B	1 m chain requires 28 pcs	3HAWL000018	Cable separator (Kabelschlepp)
		3HAWL000053	Cable separator (IGUS)
C	1 mobile + 1 fixed	3HAWL000043	External cable chain end units (Kabelschlepp)
D	1 plate per cable chain	3HAWL000041	External cable chain end tiewrap plate (Kabelschlepp)
C & D	1 mobile + 1 fixed	3HAW107710234	Cable chain end units (1 mobile + 1 fixed), Tiewrap plate (1 per cable chain) (IGUS)
E	1 m chain requires 1 pcs	3HAW107700442	External cable chain bow
F	1 m chain requires 1 pcs	3HAW107700443	External cable chain cover module
G	1 m chain requires 1 pcs	3HAW107700449	External cable chain floor guide

Continues on next page



Note

For how to identify cable chain from different supplier, see [Cable chain of different supplier on page 173](#).

8 Spare parts

8.6 Electrical spare parts and cables


8.6 Electrical spare parts and cables

SMB box and battery

NOTE: The SMB box contains a main board and a battery for the memory backup in order to maintain position data.

SMB boxes manufactured before 2015 are equipped with a SMB board DSQC633 Ref. 3HAC031851-001 and a SMB battery Ref. 3HAC16831-1.

SMB boxes manufactured after 2015 are equipped with a SMB board RMU101 Ref. 3HAC044168-001 and a Battery pack RMU Ref. 3HAC044075-001.




xx1800001993

ABB part reference no.	Description
3HAW050008604	SMB box 1 axis M2008
3HAW050008605	SMB box 3 axis M2008
3HAW050008651	SMB box 6 axis M2011
3HAC031851-001	SMB Main board DSQC633. Phased out! Order instead the set 3HAC046686-001 (board RMU101 + battery pack RMU)
3HAC16831-1	Battery pack for SMB board DSQC633. For SMB boxes manufactured before 2015 only.
3HAC044168-001	SMB Main board RMU101
3HAC044075-001	Battery pack for SMB board RMU101
3HAW050008607	PTC shunt M2008

Continues on next page

Motor cables and resolver cables

Following is a typical cabling layout of FlexTrack. Please refer to the layout to confirm what kind of motor cables and resolver cables are needed.



xx1800001914

Type	ABB part reference no.	Description
Static cable - motor	3HAW050008613-005	1 axis motor static cable 5 m
	3HAW050008613-010	1 axis motor static cable 10 m
	3HAW050008613-015	1 axis motor static cable 15 m
	3HAW050008614-005	3 axis motor static cable 5 m
	3HAW050008614-010	3 axis motor static cable 10 m
	3HAW050008614-015	3 axis motor static cable 15 m
	3HAW050008614-025	3 axis motor static cable 25 m
	3HAW050008615-005	6 axis motor static cable 5 m
	3HAW050008615-010	6 axis motor static cable 10 m
	3HAW050008615-015	6 axis motor static cable 15 m
	3HAW050008615-025	6 axis motor static cable 25 m
	3HAW050008635-005	1 Motor Static XP7 M2008 5 m, for FlexTrack controlled without external SMB box
	3HAW050008635-010	1 Motor Static XP7 M2008 10 m, for FlexTrack controlled without external SMB box
3HAW050008635-015	1 Motor Static XP7 M2008 15 m, for FlexTrack controlled without external SMB box	
Static cable - resolver	3HAW050008612-005	6 axis motor static cable 5 m
	3HAW050008612-010	6 axis motor static cable 10 m
	3HAW050008612-015	6 axis motor static cable 15 m
	3HAW050008612-025	6 axis motor static cable 25 m
Static/Extension cable - motor	3HAW050008624-005	1 Motor Static or Extension M2008 5 m
	3HAW050008624-010	1 Motor Static or Extension M2008 10 m
	3HAW050008624-015	1 Motor Static or Extension M2008 15 m
Static/Extension cable - resolver	3HAW050008625-005	1 Resolver M2008 5 m
	3HAW050008625-010	1 Resolver M2008 10 m
	3HAW050008625-015	1 Resolver M2008 15 m

Continues on next page

8 Spare parts

8.6 Electrical spare parts and cables

Continued


Type	ABB part reference no.	Description
Movement cable - motor	3HAW050008608-005	1 axis motor movement cable 5 m
	3HAW050008608-007	1 axis motor movement cable 7.5 m
	3HAW050008608-010	1 axis motor movement cable 10 m
	3HAW050008608-015	1 axis motor movement cable 15 m
Movement cable - resolver	3HAW050008609-005	1 axis motor movement cable 5 m
	3HAW050008609-007	1 axis motor movement cable 7.5 m
	3HAW050008609-010	1 axis motor movement cable 10 m
	3HAW050008609-015	1 axis motor movement cable 15 m
	3HAW050008637-001	1 Resolver Track M2008 1.2 m, connects to robot base
	3HAW050008637-002	1 Resolver Track M2008 2 m, connects to robot base
	3HAW050008637-003	1 Resolver Track M2008 3 m, connects to robot base
	3HAW050008637-005	1 Resolver Track M2008 5 m, connects to robot base
	3HAW050008637-010	1 Resolver Track M2008 10 m, connects to robot base
	3HAW050008637-015	1 Resolver Track M2008 15 m, connects to robot base
Limit switch cable	3HAW050008610-005	Limit switch cable 1 position 5 m
	3HAW050008610-010	Limit switch cable 1 position 10 m
	3HAW050008610-015	Limit switch cable 1 position 15 m
	3HAW050008654-005	Limit switch cable 2 position 5 m
	3HAW050008654-010	Limit switch cable 2 position 10 m
	3HAW050008654-015	Limit switch cable 2 position 15 m
	3HAW050008611-005	Limit switch cable 4 position 5 m
	3HAW050008611-010	Limit switch cable 4 position 10 m
	3HAW050008611-015	Limit switch cable 4 position 15 m

Robot cable & pipe

Type	ABB part reference no.	Description
Application cable	3HAW050008628-005	Welding Power cable of robot 5 m
	3HAW050008628-010	Welding Power cable of robot 10 m
	3HAW050008628-015	Welding Power cable of robot 15 m
Air pipe	3HAW050008638-005	Air pipe DN12 5 m
	3HAW050008638-010	Air pipe DN12 10 m
	3HAW050008638-015	Air pipe DN12 15 m

8.7 Anti collision

Anti collision spare parts



xx2000002595

	ABB part reference no.	Description
-	3HAW107700581	Collision system assembly (Including the laser scanner, reflector and the brackets)
A	3HAW107710201	Laser scanner
B	3HAWC116985	Laser reflector

Collision system cable & panel

Type	ABB part reference no.	Description
Movement cable	3HAWC116986	Movement cable 5 m
	3HAWC116987	Movement cable 10 m
	3HAWC116988	Movement cable 15 m
	3HAWC116989	Movement cable 20 m
Static cable	3HAWC116990	Static cable 5 m
	3HAWC116991	Static cable 10 m
	3HAWC116992	Static cable 15 m
	3HAWC116993	Static cable 20 m
Internal static	3HAWC116994	Internal static
Wall panel	3HAWC116983	Wall panel

This page is intentionally left blank

9 Appendix

9.1 Wiring diagrams

Table

This table contains the following wiring diagrams:

Document	Article number
SMB box for 1 axis M2008	3HAW050008604
SMB box for 3 axis M2008	3HAW050008605
SMB box for 6 axis M2011	3HAW050008651
PTC Shunt M2008	3HAW050008607
6 axis resolver static cable XS41-2, XP2 to SMB	3HAW050008612
1 axis motor static cable XP7 400-600V	3HAW050008613
3 axis motor static cable XP7 400-600V	3HAW050008614
6 axis motor static cable high voltage XP1 to SMB 600V	3HAW050008615
1 Motor static extension M2008	3HAW050008624
1 Resolver static extension M2008	3HAW050008625
1 Motor Static XP7 M2008 (No SMB box)	3HAW050008635
1 Resolver Static M2008 (No SMB box)	3HAW050008636
Extension welding power cable	3HAW050008628
1 Motor power flex cable- Electrical Spot Gun, from SMB.MP&SMB.MR to R1.SP	3HAW050008631
1 axis motor movement cable	3HAW050008608
1 axis resolver movement cable	3HAW050008609
Limit switch cable 1 position	3HAW050008610
Limit switch cable 2 positions	3HAW050008654
Limit switch cable 4 positions	3HAW050008611
Power supply 24V DC output & communication flexible cable	3HAW050008633
1 Resolver, Robot Axis 7 Feedback- motor resolver, Track M2008 No SMB	3HAW050008637

This page is intentionally left blank

Index

A

aluminum
disposal, 188

B

batteries
disposal, 188

C

cast iron
disposal, 188
copper
disposal, 188

G

grease
disposal, 188

L

Lithium
disposal, 188

N

neodymium

disposal, 188

NiCad

disposal, 188
nodular iron
disposal, 188

O

oil
disposal, 188

P

plastic
disposal, 188

R

replacing
xx, 188
rubber
disposal, 188

S

steel
disposal, 188

X

xx
replacing, 188



ABB Automation GmbH
Unternehmensbereich Robotics
Grüner Weg 6
61169 Friedberg
GERMANY
Telephone +49 6031 85-0

ABB Engineering (Shanghai) Ltd.
No.4528, Kangxin Highway
Pudong New District
SHANGHAI 201319, China
Telephone: +86 21 6105 6666

ABB Inc.
Discrete Automation and Motion
Robotics
1250 Brown Road
Auburn Hills, MI 48326
USA
Telephone: +1 248 391 9000

abb.com/robotics