

ROBOTICS

Product manual

IRB 14050 gripper



Trace back information:
Workspace 21B version a6
Checked in 2021-05-31
Skribenta version 5.4.005

Product manual
IRB 14050 gripper
OmniCore

Document ID: 3HAC064626-001
Revision: E

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2019-2021 ABB. All rights reserved.
Specifications subject to change without notice.

Table of contents

| | |
|--|------------|
| Overview of this manual | 7 |
| Product documentation | 9 |
| 1 Safety | 11 |
| 1.1 Introduction to safety information | 11 |
| 1.2 General safety risks | 12 |
| 1.2.1 Safety risks during installation and service work on the IRB 14050 gripper | 12 |
| 1.2.2 Safety risks related to tools/work pieces | 13 |
| 1.2.3 Risks associated with live electric parts | 14 |
| 2 Installation and commissioning | 15 |
| 2.1 Introduction | 15 |
| 2.2 Unpacking | 16 |
| 2.2.1 Pre-installation procedure | 16 |
| 2.2.2 Requirements | 18 |
| 2.3 Technical data | 19 |
| 2.3.1 General | 19 |
| 2.3.2 Servo module | 23 |
| 2.3.3 Vacuum module | 26 |
| 2.3.4 Vision module | 27 |
| 2.3.5 Fingers | 30 |
| 2.4 On-site installation | 31 |
| 2.4.1 Air and power supply | 31 |
| 2.4.2 Recommended standard tightening torque | 32 |
| 2.4.3 Mounting the gripper | 33 |
| 2.4.4 Mounting the fingers | 39 |
| 2.4.5 Mounting tools to the vacuum module | 40 |
| 2.5 IRB 14050 gripper FlexPendant application | 42 |
| 2.5.1 Installing IRB 14050 gripper FlexPendant application | 43 |
| 2.5.2 Updating IRB 14050 gripper FlexPendant application | 44 |
| 2.5.3 IRB 14050 gripper FlexPendant application GUI | 45 |
| 2.6 Commissioning | 51 |
| 2.6.1 Firmware update | 51 |
| 2.6.2 System commissioning | 56 |
| 3 Maintenance | 61 |
| 3.1 Inspection activities | 61 |
| 4 Repair | 63 |
| 4.1 Introduction | 63 |
| 4.2 Replacing the filter and suction cup | 64 |
| 4.3 Replacing the fingers | 69 |
| 4.4 Replacing the shell | 75 |
| 4.5 Replacing the pneumatic block | 82 |
| 4.6 Replacing the camera | 94 |
| 4.7 Replacing the servo base | 102 |
| 5 RAPID references | 115 |
| 5.1 Overview | 115 |
| 5.2 Instructions | 117 |
| 5.2.1 RAPID instructions for grippers | 117 |
| 5.2.1.1 g_Init - Initialize the gripper | 117 |
| 5.2.1.2 g_JogIn - Jog the gripper to move inward | 119 |
| 5.2.1.3 g_JogOut - Jog the gripper to move outward | 120 |
| 5.2.1.4 g_MoveTo - Move the gripper to a target position | 121 |

Table of contents

| | | |
|--------------|---|------------|
| 5.2.1.5 | g_GripIn - Jog the gripper to grip inward | 123 |
| 5.2.1.6 | g_GripOut - Jog the gripper to grip outward | 126 |
| 5.2.1.7 | g_Calibrate - Calibrate the gripper | 129 |
| 5.2.1.8 | g_Stop - Stop the gripper | 130 |
| 5.2.1.9 | g_SetMaxSpd - Set the maximum speed | 131 |
| 5.2.2 | RAPID instructions for pneumatic modules | 132 |
| 5.2.2.1 | g_BlowOn1 - Turn on blowing channel 1 | 132 |
| 5.2.2.2 | g_BlowOff1 - Turn off blowing channel 1 | 133 |
| 5.2.2.3 | g_BlowOn2 - Turn on blowing channel 2 | 134 |
| 5.2.2.4 | g_BlowOff2 - Turn off blowing channel 2 | 135 |
| 5.2.2.5 | g_VacuumOn1 - Turn on vacuum channel 1 | 136 |
| 5.2.2.6 | g_VacuumOff1 - Turn off vacuum channel 1 | 137 |
| 5.2.2.7 | g_VacuumOn2 - Turn on vacuum channel 2 | 138 |
| 5.2.2.8 | g_VacuumOff2 - Turn off vacuum channel 2 | 139 |
| 5.3 | Functions | 140 |
| 5.3.1 | RAPID functions for servo module | 140 |
| 5.3.1.1 | g_IsCalibrated - Get gripper calibration status | 140 |
| 5.3.1.2 | g_GetPos - Get current gripper position | 141 |
| 5.3.1.3 | g_GetSpd - Get current gripper speed | 142 |
| 5.3.1.4 | g_GetState - Get current gripper status | 143 |
| 5.3.1.5 | g_GetErrID - Get current gripper error ID | 145 |
| 5.3.2 | RAPID functions for pneumatic module | 147 |
| 5.3.2.1 | g_GetPressure1 - Get vacuum pressure 1 | 147 |
| 5.3.2.2 | g_GetPressure2 - Get vacuum pressure 2 | 148 |
| 5.3.3 | RAPID functions for camera module | 149 |
| 5.3.3.1 | g_IsCamOnline - Get handheld camera connection status | 149 |
| 6 | Decommissioning | 151 |
| 6.1 | Environmental information | 151 |
| 7 | Reference information | 153 |
| 7.1 | Introduction | 153 |
| 7.2 | Unit conversion | 154 |
| 7.3 | Standard toolkit | 155 |
| 8 | Spare parts | 157 |
| 8.1 | Introduction | 157 |
| 8.2 | Spare part lists and illustrations | 158 |
| 8.2.1 | Parts | 158 |
| Index | | 163 |

Overview of this manual

About this manual

This manual contains instructions for:

- mechanical and electrical installation of the IRB 14050 gripper
- maintenance of the IRB 14050 gripper
- mechanical and electrical repair of the IRB 14050 gripper

Usage

This manual should be used during:

- installation to make the IRB 14050 gripper ready for operation
- maintenance work
- repair work and calibration.

Who should read this manual?

This manual is intended for:

- installation personnel
- maintenance personnel
- repair personnel.

Prerequisites

A maintenance/repair/installation craftsman working with the IRB 14050 gripper must:

- be trained by ABB and have the required knowledge of mechanical and electrical installation/repair/maintenance work.

Product manual scope

The manual covers all variants and designs of the IRB 14050 gripper. Some variants and designs may have been removed from the business offer and are no longer available for purchase.

Organization of chapters

The manual is organized in the following chapters:

| Chapter | Contents |
|--------------------------------|---|
| Safety | Safety information that must be read through before performing any installation or service work on the IRB 14050 gripper. Contains general safety aspects as well as more specific information on how to avoid personal injuries and damage to the product. |
| Installation and commissioning | Required information about installation of the IRB 14050 gripper. |
| Maintenance | Step-by-step procedures that describe how to perform maintenance of the IRB 14050 gripper. Based on a maintenance schedule that may be used to plan periodical maintenance. |
| Repair | Step-by-step procedures that describe how to perform repair activities of the IRB 14050 gripper. Based on available spare parts. |

Continues on next page

| Chapter | Contents |
|-----------------------|--|
| Operation | RAPID reference information and operation using FlexPendant for the IRB 14050 gripper. |
| Decommissioning | Environmental information about the IRB 14050 gripper and its components. |
| Reference information | Useful information when performing installation, maintenance or repair work. Includes lists of necessary tools, additional documents, safety standards, etc. |
| Spare parts | Reference to the spare part list for the IRB 14050 gripper. |

References

Documentation referred to in the manual, is listed in the table below.

| Document name | Document ID |
|---|----------------|
| <i>Product manual - IRB 14050</i> | 3HAC064625-001 |
| <i>Product specification - IRB 14050</i> | 3HAC064627-001 |
| <i>Technical reference manual - System parameters</i> | 3HAC065041-001 |
| <i>Safety manual for robot - Manipulator and IRC5 or OmniCore controller</i> ⁱ | 3HAC031045-001 |

ⁱ This manual contains all safety instructions from the product manuals for the manipulators and the controllers.

Revisions

| Revision | Description |
|----------|---|
| A | First edition. |
| B | Published in release 20A. The following updates are made in this revision: <ul style="list-style-type: none"> Smart Gripper add-in replaced by Smart Gripper Support option in entire manual. |
| C | Published in release 20B. The following updates are made in this revision: <ul style="list-style-type: none"> O-ring 3x2 (3HAB3772-174) changed to O-ring 4x2 (3HAC063220-001). |
| D | Published in release 21A. The following updates are made in this revision: <ul style="list-style-type: none"> The instruction <code>g_SetForce</code> is no longer supported and therefore removed from the manual. |
| E | Published in release 21B. The following updates are made in this revision: <ul style="list-style-type: none"> Added new spare parts vacuum sensor (3HAC047823-001), connector board (3HAC051609-001), FFC for pneumatic block connector board (3HAC051610-002) and FFC for camera (3HAC054157-002); related repair procedures, spare part list and spare part images are also updated. |

Product documentation

Categories for user documentation from ABB Robotics

The user documentation from ABB Robotics is divided into a number of categories. This listing is based on the type of information in the documents, regardless of whether the products are standard or optional.



Tip

All documents can be found via myABB Business Portal, www.abb.com/myABB.

Product manuals

Manipulators, controllers, DressPack/SpotPack, and most other hardware is delivered with a **Product manual** that generally contains:

- Safety information.
- Installation and commissioning (descriptions of mechanical installation or electrical connections).
- Maintenance (descriptions of all required preventive maintenance procedures including intervals and expected life time of parts).
- Repair (descriptions of all recommended repair procedures including spare parts).
- Calibration.
- Decommissioning.
- Reference information (safety standards, unit conversions, screw joints, lists of tools).
- Spare parts list with corresponding figures (or references to separate spare parts lists).
- References to circuit diagrams.

Technical reference manuals

The technical reference manuals describe reference information for robotics products, for example lubrication, the RAPID language, and system parameters.

Application manuals

Specific applications (for example software or hardware options) are described in **Application manuals**. An application manual can describe one or several applications.

An application manual generally contains information about:

- The purpose of the application (what it does and when it is useful).
- What is included (for example cables, I/O boards, RAPID instructions, system parameters, software).
- How to install included or required hardware.
- How to use the application.
- Examples of how to use the application.

Continues on next page

Operating manuals

The operating manuals describe hands-on handling of the products. The manuals are aimed at those having first-hand operational contact with the product, that is production cell operators, programmers, and troubleshooters.

1 Safety

1.1 Introduction to safety information

Overview

This chapter describes the safety information specific to the IRB 14050 gripper only. It does not contain complete safety information for the IRB 14050 robot system. The following additional documents are essential for correct and safe usage of the IRB 14050 robot system, including the gripper:

- *Product manual - IRB 14050*

Disposition

The safety information in this manual is divided into two categories:

- General safety aspects, important to attend to before performing any service work on the grippers. These are applicable for all service works and can be found in the section [General safety risks on page 12](#).
- Specific safety information, pointed out in the procedures. How to avoid and eliminate the danger is described directly in the procedure.

1 Safety

1.2.1 Safety risks during installation and service work on the IRB 14050 gripper

1.2 General safety risks

1.2.1 Safety risks during installation and service work on the IRB 14050 gripper

Overview

This section includes information about general safety risks to be considered when performing installation and service work on the IRB 14050 gripper.

General risks during installation and service

- The instructions in the product manual in chapters [Installation and commissioning on page 15](#), and [Repair on page 63](#) must always be followed.
- Those in charge of operations must make sure that safety instructions are available for the installation in question.
- Those who install the IRB 14050 gripper must have the appropriate training for the robot system in question and in any safety matters associated with it.
- The power supply of 24 V DC to the robot tool flange must be shut off when installing or servicing the gripper. This can be done from the robot main switch or from a predefined I/O signal that controls the power to the tool flange.
- Air supply to the robot must be shut off when installing or servicing the gripper.
- Make sure that all bolts have been tightened before starting any operation after maintenance work.
- Make sure that no foreign material is lying on the IRB 14050 gripper before starting an operation.
- Damaged or broken equipment can result in a safety risk.

1.2.2 Safety risks related to tools/work pieces

Safe handling

The IRB 14050 gripper is designed to allow manual release and removal of gripped work pieces. Both servo and vacuum modules can be overridden by manual force. If end tools (such as fingers and suction tools) and work pieces are not correctly designed and chosen, gravity or robot acceleration may cause a work piece held by the gripper to drop during motion. The work pieces must meet the weight requirements, and the end tools must be suitably designed to grip the work pieces.

Safe design

The IRB 14050 is intended for collaborative applications, where occasional contacts between the robot and operators is safe. End tools (such as fingers and suction tools), as well as work pieces handled by the robot, must be designed and chosen so that such contacts does not introduce safety hazards.

The IRB 14050 gripper is not designed to retain work pieces in case of power loss. Objects held by the servo and vacuum modules may be released, in the event of pneumatic or electric power loss to the gripper. The work pieces handled by the robot, as well as the collaborative work station where the robot operates, should be chosen and designed so that such release does not introduce safety hazards.

All end tools and work pieces must be included in the risk assessment by the system integrator.

1 Safety

1.2.3 Risks associated with live electric parts

1.2.3 Risks associated with live electric parts

Voltage related risks

The IRB 14050 gripper is powered by 24 V DC from the robot tool flange. A risk for short-circuit and sparks exists. All installation and service works should be done with power disconnected from the gripper and the tool flange. This can be done from the robot main switch or from a predefined I/O signal that controls the power to the tool flange. Service works shall, whenever possible, be done with the gripper mechanically removed from the robot arm.

All work must be performed by qualified personnel.

2 Installation and commissioning

2.1 Introduction

General

This chapter contains information for installing the IRB 14050 gripper at the working site.

More detailed technical data about the gripper can be found in the *Product specification* for the robot.

Safety information

Before any installation work is conducted, it is extremely important that all safety information is observed!

There are general safety aspects that must be read through, as well as more specific safety information that describes the danger and safety risks when performing the procedures. Read the chapter [Safety on page 11](#) before performing any installation work.



Note

If the robot where the gripper shall be mounted is connected to power, always ensure that the robot is connected to protective earth before starting any installation work.

For more information, see *Product manual* for the robot.

2 Installation and commissioning

2.2.1 Pre-installation procedure

2.2 Unpacking

2.2.1 Pre-installation procedure

Introduction

This section describes the unpacking and installation of the IRB 14050 gripper for the first time. It also covers re-installation of the IRB 14050 gripper.

Packing, gripper

The IRB 14050 gripper is packed following the standards of sea transportation, land transportation and air transportation on delivery.

Check the following item list in the standard delivery package before proceeding with the installation of the gripper.

| No | Item | Description |
|----|---|---|
| 1 | Servo module | For the Servo option |
| 2 | Servo module + one vacuum module | For the Servo + Vacuum 1 option |
| 3 | Servo module + two vacuum modules | For the servo + Vacuum 1 + Vacuum 2 option |
| 4 | Servo module + one vision module | For the servo + Vision option |
| 5 | Servo module + one vision module +one vacuum module | For the servo + Vacuum 1 + Vision option |
| 6 | Getting-started fingers | For all options |
| 7 | Suction tools | Delivered together only with items 2, 3, or 5 |
| 8 | Screw package | For all options |

Checking the pre-requisites for installation

Installation personnel working with the IRB 14050 gripper must:

- be trained by ABB and have the required knowledge of mechanical and electrical installation/maintenance/repair work
- conform to all national and local codes.

| | Action |
|---|---|
| 1 | Visually inspect the grippers to make sure that they are not damaged. |
| 2 | If the grippers are not installed directly, they must be stored as described in: <ul style="list-style-type: none">• Storage conditions, gripper on page 18 |
| 3 | Make sure that the expected operating environment of the grippers conforms to the specifications as described in: <ul style="list-style-type: none">• Operating conditions, gripper on page 18 |
| 4 | Before taking the grippers to the installation site, make sure that the site conforms to: <ul style="list-style-type: none">• Protection classes, gripper on page 18• Requirements, robot tool flange on page 18 |
| 5 | When these prerequisites are met, the grippers can be taken to the installation site as described in section: <ul style="list-style-type: none">• On-site installation on page 31 |

Continues on next page

2 Installation and commissioning

2.2.1 Pre-installation procedure

Continued

| | Action |
|---|-------------------------------------|
| 6 | Install required equipment, if any. |

2 Installation and commissioning

2.2.2 Requirements

2.2.2 Requirements

Requirements, robot tool flange

Make sure the area around the robot wrist has no particles that would obstruct the installation of the IRB 14050 gripper or be dangerous to the operator.

Storage conditions, gripper

The table shows the allowed storage conditions for the gripper:

| Parameter | Value |
|--|--|
| Minimum ambient temperature | -20 °C |
| Maximum ambient temperature | +45 °C |
| Maximum ambient temperature (less than 24 hrs) | +55 °C |
| Maximum ambient humidity | 85% at constant temperature (gaseous only) |

Operating conditions, gripper

The table shows the allowed operating conditions for the gripper:

| Parameter | Value |
|-----------------------------|--|
| Minimum ambient temperature | +5 °C |
| Maximum ambient temperature | +45 °C |
| Maximum ambient humidity | 85% at constant temperature (gaseous only) |

Protection classes, gripper

The table shows the available protection types of the gripper, with the corresponding protection class.

| Protection type | Protection class |
|-----------------------------------|------------------|
| Gripper, protection type Standard | IP30 |

Food contact

The gripper is not intended to be in contact with food.

Sterile environments

The gripper is not intended to be operated in sterile environments.

2.3 Technical data

2.3.1 General

Weight and load capacity

| Combination | Weight (g) without fingers, suction cup(s), and filter(s) ⁱ | Weight (g) of the whole gripper | Max. load capacity (g) without fingers, suction cup(s), and filter(s) ⁱⁱ | Max. load capacity (g) of the whole gripper ⁱⁱ |
|-----------------------------|--|---------------------------------|---|---|
| Servo | 215 | 230 | 285 | 270 |
| Servo + Vacuum 1 | 225.5 | 248 | 274.5 | 252 |
| Servo + Vacuum 1 + Vacuum 2 | 250 | 280 | 250 | 220 |
| Servo + Vision | 229 | 244 | 271 | 256 |
| Servo + Vision + Vacuum 1 | 239.5 | 262 | 260.5 | 238 |

ⁱ The getting-started fingers weighs 15 gram, and the standard suction cups and filters weighs 7.5 gram per set.

ⁱⁱ Load capacity = 500 - weight
Center of gravity (CoG) limitations applied. See the load diagram for the robot.

Detailed mass data - Center of Gravity

| Combination | CoG (mm) without fingers, suction cup(s), and filter(s) | | | CoG (mm) of the whole gripper | | |
|-----------------------------|---|------|------|-------------------------------|------|------|
| | x | y | z | x | y | z |
| Servo | 8.7 | 12.3 | 49.2 | 8.2 | 11.7 | 52 |
| Servo + Vacuum 1 | 8.9 | 12.3 | 48.7 | 8.6 | 11.7 | 52.7 |
| Servo + Vacuum 1 + Vacuum 2 | 7.4 | 12.4 | 44.8 | 7.1 | 11.9 | 47.3 |
| Servo + Vision | 7.9 | 12.4 | 48.7 | 7.5 | 11.8 | 52.7 |
| Servo + Vision + Vacuum 1 | 8.2 | 12.5 | 48.1 | 7.8 | 11.9 | 50.7 |

Detailed mass data - Inertia

| Combination | Inertia (kgm ²) without fingers, suction cup(s), and filter(s) | | | Inertia (kgm ²) of the whole gripper | | |
|-----------------------------|--|---------|---------|--|---------|---------|
| | lxx | lyy | lzz | lxx | lyy | lzz |
| Servo | 0.00017 | 0.00020 | 0.00008 | 0.00021 | 0.00024 | 0.00009 |
| Servo + Vacuum | 0.00017 | 0.00020 | 0.00008 | 0.00021 | 0.00024 | 0.00009 |
| Servo + Vacuum 1 + Vacuum 2 | 0.00020 | 0.00024 | 0.00011 | 0.00025 | 0.00029 | 0.00012 |
| Servo + Vision | 0.00017 | 0.00019 | 0.00008 | 0.00021 | 0.00023 | 0.00008 |

Continues on next page

2 Installation and commissioning

2.3.1 General

Continued

| Combination | Inertia (kgm ²) without fingers, suction cup(s), and filter(s) | | | Inertia (kgm ²) of the whole gripper | | |
|-------------------------|--|---------|---------|--|---------|---------|
| | lxx | lyy | lzz | lxx | lyy | lzz |
| Servo + Vision + Vacuum | 0.00018 | 0.00020 | 0.00009 | 0.00022 | 0.00024 | 0.00009 |

Tooldata definitions without fingers, suction cup(s), and filter(s)

| Combination | Tooldata |
|-----------------------------|--|
| Servo | [TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.215, [8.7, 12.3, 49.2], [1, 0, 0, 0], 0.00017, 0.00020, 0.00008]] |
| Servo + Vacuum | [TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.226, [8.9, 12.3, 48.7], [1, 0, 0, 0], 0.00017, 0.00020, 0.00008]] |
| Servo + Vacuum 1 + Vacuum 2 | [TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.250, [7.4, 12.4, 44.8], [1, 0, 0, 0], 0.00020, 0.00024, 0.00011]] |
| Servo + Vision | [TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.229, [7.9, 12.4, 48.7], [1, 0, 0, 0], 0.00017, 0.00019, 0.00008]] |
| Servo + Vision + Vacuum | [TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.240, [8.2, 12.5, 48.1], [1, 0, 0, 0], 0.00018, 0.00020, 0.00009]] |


Tooldata definitions with fingers, suction cup(s), and filter(s)

| Combination | Tooldata |
|-----------------------------|--|
| Servo | [TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.230, [8.2, 11.7, 52.0], [1, 0, 0, 0], 0.00021, 0.00024, 0.00009]] |
| Servo + Vacuum | [TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.248, [8.6, 11.7, 52.7], [1, 0, 0, 0], 0.00021, 0.00024, 0.00009]] |
| Servo + Vacuum 1 + Vacuum 2 | [TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.280, [7.1, 11.9, 47.3], [1, 0, 0, 0], 0.00025, 0.00029, 0.00012]] |
| Servo + Vision | [TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.244, [7.5, 11.8, 52.7], [1, 0, 0, 0], 0.00021, 0.00023, 0.00008]] |
| Servo + Vision + Vacuum | [TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.262, [7.8, 11.9, 50.7], [1, 0, 0, 0], 0.00022, 0.00024, 0.00009]] |

Continues on next page

Mass data, illustration

The following figure shows the mass data of the gripper with one servo module and one vacuum module as an example.



xx150000826

| | |
|---|--|
| A | CoG Note: Dimensions of CoG in the brackets are without the fingers and suction tools |
| B | Getting-started finger length |
| C | Travel length: 0-50 mm |

Continues on next page

2 Installation and commissioning

2.3.1 General

Continued

Airborne noise level

| Description | Note |
|----------------------------------|--|
| The sound pressure level outside | < 55 dB, measured at a location 0.5 m away from the gripper. |

Power consumption


The gripper is powered by 24 V DC and the maximum power consumption of the whole gripper is 9 W.

Air consumption

Maximum air consumption is 15 liters/minute for a single pneumatic module.

Dimensions

The following figure shows the dimension of the gripper with one servo module and two vacuum modules. The dimensions of other gripper options can be obtained by simply removing the dimension data of the suction cups and filters. For the specific dimension of the camera used in the gripper with a vision module, see [Camera, dimensions on page 27](#).



xx1500000106

| Pos | Description |
|-----|-------------------------|
| A | Travel length = 0-50 mm |

2.3.2 Servo module

Travel length

| Description | Data |
|---------------|---------------------------------|
| Travel length | 0-50 mm (max. 25 mm per finger) |

Maximum speed

| Description | Data |
|---------------|----------|
| Speed | 25 mm/s |
| Repeatability | ±0.05 mm |


Gripping force

| Description | Data |
|---|--|
| Gripping direction | Inward or outward |
| Maximum gripping force | 20 N (at the gripping point of 40 mm) ⁱ |
| External force (not in gripping directions) | 15 N (at the gripping point of 40 mm) |
| Force control accuracy | ±3 N |

ⁱ The gripping times of getting-started fingers is 10,000 under the maximum gripping force 20 N.

Load diagram

The following figures show the relationship between the maximum allowed gripping force and gripping point to the finger flange.




xx1500000792

Continues on next page

2 Installation and commissioning

2.3.2 Servo module


Continued



xx1500000797


| Pos | Description |
|-----|--|
| F | Gripping force, in unit of N |
| L | Length from the gripping point to the finger flange, in unit of mm |

The following figures show the relationship between the maximum allowed external force and gripping point to the finger flange.



xx1500000798

Continues on next page



xx150000799

| Pos | Description |
|-----|--|
| F | External force, in unit of N |
| L | Length from the gripping point to the finger flange, in unit of mm |

Position control and calibration

The servo module has integrated position control with the repeatability of ± 0.05 mm. The servo module is calibrated by RAPID instructions or using the FlexPendant interface. For details, see the section [IRB 14050 gripper FlexPendant application on page 42](#) and chapter [RAPID references on page 115](#).

2 Installation and commissioning

2.3.3 Vacuum module

2.3.3 Vacuum module

Vacuum generator

The vacuum module has an integrated vacuum generator that is designed with a maximum payload of 150 g. The actual payload capacity depends on the following factors:

- Suction tool design and the choice of suction cups
- The surface structure of the object being picked
- The pickup point and the CoG of the object being picked
- Robot motion while the object is picked
- Air pressure input to the robot

Vacuum pressure sensor

The air pressure of the vacuum module can be monitored in real time using an in-built vacuum sensor. This makes it possible to detect whether the object is correctly picked up by the suction tool.

Blow-off actuator

To minimize cycle time and ensure accurate drop-off of the picked objects, a blow-off actuator is integrated in the vacuum module.

2.3.4 Vision module

General


The vision module includes a Cognex AE3 camera and provides powerful and reliable vision and identification tools.

Camera, specification

| Description | Data |
|----------------------------------|---|
| Resolution | 1.3 Megapixel |
| Lens | 6.2 mm f/5 |
| Illumination | Integrated LED with programmable intensity |
| Software engine | Powered by Cognex In-Sight |
| Application programming software | ABB Integrated vision or Cognex In-Sight Explorer |

Camera, dimensions

The following figure shows the dimension of the Cognex AE3 camera.



xx1500001395

| Pos | Description |
|-----|-----------------------|
| A | Internal illumination |

Continues on next page

2 Installation and commissioning



2.3.4 Vision module

Continued



| Pos | Description |
|-----|-------------|
| B | Lens |

Lens focusing

Use the following procedure to focus the lens of the Cognex AE3 camera.

| | Action | Note |
|---|--|---|
| 1 | For the gripper also with a vacuum module, twist and remove the filter and suction cup first. | |
| 2 | Remove the screws that fasten the shell, and then press the shell sides gently to detach the shell. The shell consists of two parts: <ul style="list-style-type: none"> • lower shell • upper shell |  <p>xx150000759</p> <p>xx1400002152</p> |
| 3 | Rotate the focusing ring of the 6.2 mm lens to fit the application. |  <p>xx1500001621</p> |

Continues on next page

| | Action | Note |
|---|---|--|
| 4 | Put the shell to the base plate by locating the location pins to the location holes on the base plate. Press the two shell parts together. Then, refit the two M1.2 screws. |  <p data-bbox="1059 680 1166 696">xx1400002155</p>  <p data-bbox="1059 1099 1166 1115">xx1500000759</p> |
| 5 | For the gripper also with a vacuum module, refit the filter and suction cup by twisting them. | |

2.4 On-site installation

2.4.1 Air and power supply

Requirements

The IRB 14050 gripper is supplied with air and 24 V DC power from the IRB 14050 tool flange.

Before installing the gripper, ensure that air and electric power supply to the tool flange is shut off. The electric power can be shut off from the robot main switch or from a predefined I/O signal that controls power to the tool flange. The air supply cannot be controlled from within the robot, or from the robot main switch, and has to be shut off externally.

The air supply to the robot should be 5.5-6 bar, filtered and non-lubricated. The nominal operating pressure is 6 bar.

Before any installation or service work on the gripper, ensure that the safety instructions in section [Safety on page 11](#) are followed.

2 Installation and commissioning

2.4.2 Recommended standard tightening torque

2.4.2 Recommended standard tightening torque

Standard tightening torque


The table below specifies the recommended standard tightening torque for the screws.

| Screw type | Tightening torque (Nm) on metal | Tightening torque (Nm) on plastic |
|--------------------------------------|---------------------------------|-----------------------------------|
| M1.2 | N/A | 0.05 |
| M1.6 (12.9 class carbon steel screw) | 0.25 | N/A |
| M1.6 (stainless steel screw) | N/A | 0.05 |
| M2 | 0.25 | 0.1 |
| M2.5 | 0.45 | 0.45 |

2.4.3 Mounting the gripper

Mounting flange

Three M2.5 holes and one guide pin are used to assemble the gripper to the arm tool flange.



xx1500000126

| Pos | Description |
|-----|------------------------------------|
| A | Recommended screws, three M2.5 x 8 |
| B | Air hose |
| C | 8-pin connector (spring-loaded) |
| D | Guide pin |


Continues on next page

2 Installation and commissioning

2.4.3 Mounting the gripper

Continued

The pins of the connector (shown as C in the preceding figure) are defined as follows.




xx1500000796

| Pin | Description |
|-----|--------------|
| A | EtherNet RD- |
| B | EtherNet TD- |
| C | EtherNet RD+ |
| D | EtherNet TD+ |
| E | PE |
| F | Spare |
| G | 0V, IO |
| H | 24V, IO |

Continues on next page

Hole configuration, mounting base

The following figure shows the hole configuration when assembling the gripper to the arm tool flange.



xx1500000793

| Pos | Description |
|-----|---------------|
| B | Stroke = 1 mm |

Installing the gripper

Required tools and equipment

| Equipment | Article number | Note |
|------------------|----------------|--|
| Standard toolkit | - | Content is defined in section Standard toolkit on page 155 . |

Continues on next page

2 Installation and commissioning

2.4.3 Mounting the gripper


Continued

Required spare part

| Spare part | Part No. | Note |
|-----------------------------|----------------|--|
| SERVO | 3HAC054831-001 | Used when the Servo gripper is chosen. |
| SERVO + VISION | 3HAC054832-001 | Used when the Servo + Vision gripper is chosen. |
| SERVO + VACUUM 1 | 3HAC054833-001 | Used when the Servo + Vacuum 1 gripper is chosen. |
| SERVO + VACUUM 1 + VISION | 3HAC054834-001 | Used when the Servo + Vision + Vacuum 1 gripper is chosen. |
| SERVO + VACUUM 1 + VACUUM 2 | 3HAC054835-001 | Used when the Servo + Vacuum 1 + Vacuum 2 gripper is chosen. |

Procedure




Use the following procedure to install a whole gripper onto the robot arm.

| | Action | Note |
|---|--|--|
| 1 |  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off. | For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 . |
| 2 | Position the gripper to the arm tool flange on the axis 6 of the robot. |  <p>xx1500001394</p> <p>A Arm tool flange B Axis 6 of the robot</p> |
| 3 | Use the guide pin and air hose hole to make the gripper align with the arm tool flange. | For the positions of the guide pin and air hose hole, see Mounting flange on page 33 . |

Continues on next page

2 Installation and commissioning

2.4.3 Mounting the gripper Continued


| | Action | Note |
|---|---|--|
| 4 | For the gripper with a vacuum module, fit an O-ring in the air hose hole. | O-ring 4x2: 3HAC063220-001 (1 pcs)  xx1500001625 |
| 5 | Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw. | Screw: M2.5x8, 3HAC051701-001 (1 pcs)  xx1500001391 |
| 6 | Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw. | Screw: M2.5x8, 3HAC051701-001 (1 pcs)  xx1500001392 |

Continues on next page

2 Installation and commissioning

2.4.3 Mounting the gripper

Continued

| | Action | Note |
|---|--|--|
| 7 | Rotate the flange with 90 degrees to access the last screw hole and then refit the screw. | Screw: M2.5x8, 3HAC051701-001 (1 pcs)  xx1500001393 |
| 8 | Turn on the power and air supply to the gripper and then perform commissioning on the gripper. | |


2.4.4 Mounting the fingers

General

A pair of getting-started fingers are provided together with the gripper for demo and test purposes. These fingers should be replaced with fingers designed for the actual application by the system integrator and must be included in the final risk assessment done by the system integrator.

Hole configuration, finger flange

The following figures show the hole configuration and main dimensions of the finger flanges.



xx150000794

| Pos | Description |
|-----|--------------------------------------|
| A | Position of the maximum displacement |
| B | Maximum hole depth |

2 Installation and commissioning

2.4.5 Mounting tools to the vacuum module

2.4.5 Mounting tools to the vacuum module

General

The vacuum module is delivered with a first set of suction cups and filters for demo and test purposes. Application-specific suction tools should be designed and chosen by the system integrator. Air filters are required in the suction tools to ensure the long-term performance of the vacuum module. If the vacuum function is not required, passive assembly tools, such as press tools, can also be mounted to the suction tool interface. Any tools mounted to the gripper must be included in the final risk assessment by the system integrator.

Continues on next page


2 Installation and commissioning

2.4.5 Mounting tools to the vacuum module

Continued

Hole configuration, vacuum tools

The following figure shows the hole configuration and tool interface of the vacuum module.



xx150000795

| Pos | Description |
|-----|---|
| A | Length from the center to the outer shell surface |
| B | Length from the center to the inner shell surface |
| C | Shell hole depth |

2 Installation and commissioning

2.5 IRB 14050 gripper FlexPendant application

2.5 IRB 14050 gripper FlexPendant application

Overview

The following requirements must be met for the gripper configuration.

| Item | Note |
|--|---|
| Options for manipulator and controller | The gripper option must be chosen. |
| RobotWare | <ul style="list-style-type: none">• RobotWare 7.0 or later• SmartGripper Support option SmartGripper Support is a RobotWare option for ABB smart grippers. All files related to ABB smart grippers will be installed automatically, such as configuration files, RAPID driver and FlexPendant application. |

Continues on next page

2.5.1 Installing IRB 14050 gripper FlexPendant application

Installation procedure

- 1 During the creating or modification of a robot system using the installation manager, select **SmartGripper Support** under **Gripper** in the **System Options** tab page.
- 2 Install the robot system and restart the controller.
The **SmartGripper** icon is displayed in the **Settings** menu on the FlexPendant.

2 Installation and commissioning

2.5.2 Updating IRB 14050 gripper FlexPendant application

2.5.2 Updating IRB 14050 gripper FlexPendant application


Updating procedure

- 1 Since the Smart Gripper is a part of the RobotWare product, the update procedure is same as updating the RobotWare product. See *Operating manual - RobotStudio*.
- 2 Install the robot system and restart the controller.
The **SmartGripper** icon is displayed in the setting menu on the FlexPendant.

2.5.3 IRB 14050 gripper FlexPendant application GUI


Main page

The following figure shows the main page of FlexPendant application.



xx1900000917

If you click on the **Setting** icon, the **SmartGripper** icon will be displayed as shown in the following figure.



xx1800001267

Continues on next page


2 Installation and commissioning

2.5.3 IRB 14050 gripper FlexPendant application GUI

Continued


Configuration page

The following figure shows the configuration page for the IRB 14050 gripper.



xx1800001268

In the configuration page, you can choose the gripper type that has been mounted on the robot.




xx1800001269


Continues on next page

Servo module tab page

The following figure shows the **Servo module** tab page in the hand page, which provides operations related to gripper motion.



xx1800001270




xx1800001478

Continues on next page

2 Installation and commissioning

2.5.3 IRB 14050 gripper FlexPendant application GUI

Continued



xx1800001480


Four function groups are available on the Servo module tab page: **Setup**, **Command**, **Status**, and **Firmware Upgrade**.

| Group | Parameter | Description |
|------------------|------------------------------|---|
| Setup | Calibrate | Calibrates the gripper at the current position. |
| | Speed | Sets the movement speed of fingers on the gripper. |
| | Force | Sets the gripping force of fingers on the gripper. |
| Command | Jog/Stop/Grip+/Grip-/Move to | If the gripper is not calibrated, only the functions Jog and Stop can be used, and the functions Grip+ , Grip- and Move to are disabled. |
| Status | Calibration | The calibration status of the robot. |
| | Current position | Indicates the current position of the gripper. |
| | Current state | Indicates the state of the gripper. For details about the gripper states, see Returned value on page 143 . |
| Firmware Upgrade | Current Version | Ver. 5.1 |

Continues on next page

Pneumatic module tab page

The following figure shows the **Pneumatic module** tab page in the hand page, which is used for instructing the built-in valves to finish vacuum-sucking and blow-off operations.



xx1800001479

Two pneumatic block parts are available for different variants of the gripper. Suction and blow-off functions are exclusive to each other. That is, if one function is turned on, the other will be turned off.

Continues on next page


2 Installation and commissioning

2.5.3 IRB 14050 gripper FlexPendant application GUI

Continued

Camera module tab page

The following figure shows the **Camera module** tab page in the hand page, which can only be set in RobotStudio now. For more information of the camera module, see the *Application manual of Integrated Vision*.



xx1900000709

2.6 Commissioning

2.6.1 Firmware update

Overview

The TFTP method is available for updating the firmware of ABB smart grippers in RobotWare 7.0.

TFTP method

General

The SmartGripper firmware with a version earlier than 4.7 is limited to use the TFTP method for firmware updating.

The TFTP method works after the SmartGripper restarted. It will cost 8s for a new firmware downloading. If the new firmware upgrade fails, the SmartGripper will continue use the TFTP method.

Prerequisites

- PC with a network adapter
The firewall of the PC must be shut down.
- Tftpd client
Tftpd32 developed by Philippe JOUNIN is recommended. For details about Tftpd32, visit <http://tftpd32.jounin.net/>.
- Image binary file
The file must be a BIN file and named like "HandSWx_x.bin". Obtain the proper file by visiting the **ABB Download Center** website and searching with key words "IRB 14050 gripper software".

Continues on next page

2 Installation and commissioning


2.6.1 Firmware update

Continued

Update procedure

Use this procedure to update the firmware for the gripper:

- 1 Select **Disable Power To Gripper** to disconnect the flange 24V power to gripper. The TFTP method will be available for updating.




xx1900000711

- 2 Connect the PC to the Service port of the robot controller.
Ensure that the IP address of the PC is obtained automatically or within the same subnet (192.168.125.xxx) with robot controller.

Continues on next page

- 3 Open the **Tftpd32** program and click **Tftp Client**. Then, configure the parameters shown in the following figure.



xx150000629

- The value of the **Server interfaces** parameter must be the IP address of the network adapter that is used to connect the PC with the robot.
- The value of the **Host** parameter must be set to the IP address of the target gripper.
192.168.125.30 is the default address for the gripper.
- The value of the **Port** parameter must be set to **69**.
- In the **Local File** text box, select the image stored on the PC with which the target gripper is to be upgraded.
- The value of the **Block Size** parameter must be set to **512**.


Continues on next page

2 Installation and commissioning

2.6.1 Firmware update

Continued


- 4 Power on the target gripper again through the **Enable Power To Gripper** button.



xx1900000712

**Note**

There is a wait time after pressing the **Enable Power To Gripper** button to enable the Hand device. At this duration, the power on button will be disabled until the Hand turns running.



xx1900000713

Continues on next page

- 5 When the network LED on the target gripper begins blinking, click the **Put** button on the **Tftp Client** tab page.



Note

The **Put** button must be clicked within 8 seconds when you observe the LED blinking. After 8 seconds, the LED stops blinking for a few seconds and then restart blinking. If you click the **Put** button during this re-blinking period, you will experience failures.

- 6 Close the **Tftpd32** program after the transmission is completed.
The gripper is automatically booted with the firmware in the new version. Then, the firmware version of the gripper can be checked using the **ABB Smart Gripper Support** option.

2 Installation and commissioning

2.6.2 System commissioning



2.6.2 System commissioning

Servo module



Prerequisites

- The gripper has been installed onto the robot arm correctly.
- Smart Gripper Support option has been selected during installation.
- The gripper has been powered on and the communication is established.

Procedure

| | Action | Note |
|---|---|--|
| 1 | Open Smart Gripper and choose the gripper to be tested. | See IRB 14050 gripper FlexPendant application on page 42 . |
| 2 | On the Servo module tab page, click the Jog - button until the two fingers of the gripper are in direct contact with each other, which is the zero position used for calibration. |  <p>xx1800001270</p> |
| 3 | Click the Calibrate button to perform the calibration. |  <p>xx1900000710</p> |

Continues on next page

| | Action | Note |
|---|--|---|
| 4 | Input value in the text box next to the Move to button and then click the button . |  <p>xx1800001478</p> |
| 5 | Check the current position of the gripper, which is shown in Position of the Status area. |  <p>xx1800001481</p> |
| 6 | The gripper works properly if all the preceding actions complete normally. | |

Vacuum module

Prerequisites

- A gripper with at least one vacuum module has been installed onto the robot arm correctly.
- Suction tools including the suction cup and filter have been installed correctly.
- Smart Gripper Support option has been selected during installation.
- The gripper has been powered on and the communication is established.
- A test object with a smooth surface has been prepared.

Procedure


| | Action | Note |
|---|---|--|
| 1 | Open Smart Gripper and choose the gripper to be tested. | See IRB 14050 gripper FlexPendant application on page 42 . |

Continues on next page

2 Installation and commissioning

2.6.2 System commissioning

Continued

| | Action | Note |
|---|--|--|
| 2 | <p>Click Pneumatic module to enter the Pneumatic module tab page for commissioning the vacuum module.</p> <p>If any of Pneumatic 1 or Pneumatic 2 is available, the value of Gas pressure should be about 100 KPa. If the value is 0 KPa, no such vacuum module exists or the vacuum sensor of the vacuum module is broken.</p> |  <p>xx1800001479</p> |
| 3 | <p>Check the air supply and test object to ensure that the air pressure to the AIR interfaces on the left side panel of the IRB 14050 controller is proper and the test object is in the proper position for the test.</p> | |
| 4 | <p>Click the Suction On button.</p> | |
| 5 | <p>Verify that the object is picked up successfully.</p> <p>If yes, the value of Gas pressure should be less than 70 kPa.</p> | |
| 6 | <p>The vacuum module works properly if all the preceding actions complete normally.</p> | |

Vision module

Prerequisites

- A gripper with one vision module has been installed onto the robot arm correctly.
- Smart Gripper Support option has been selected during installation.
- The IV option has been installed to use ABB Integrated Vision for testing the vision module.
- The gripper has been powered on and the communication is normally.
- A PC with the RobotStudio installed has been prepared.



Note

The Cognex In-Sight explorer can also be used for the commissioning of the vision module. In this case, a PC with the Cognex In-Sight software installed must be prepared.



CAUTION

Do not change the firmware of the Cognex AE3 camera; otherwise, communication errors will occur.

Continues on next page

Procedure

See *Application manual - Integrated Vision* for how to perform commissioning on the vision module of the gripper. Verify that:

- The communication between the robot controller/PC and the vision module of the gripper is established.
- The IP address configuration of the vision module is correct. Users can select any available IP address on the subnet 192.168.125.xxx or use the DHCP.
- The vision module can take pictures normally using RobotStudio or Cognex In-Sight.

This page is intentionally left blank

3 Maintenance

3.1 Inspection activities

Required tools and equipment

Visual inspection, no tools are required.



CAUTION

All power to the manipulator must be shut off when inspecting the gripper. This can be done from the robot main switch on the controller.

Periodicity

Visually inspect the gripper regularly before starting an operation.

Inspecting the gripper

| Part | Verify that... |
|----------------------|--|
| Whole gripper | <ul style="list-style-type: none"> The gripper is not loose from the robot arm. The screws attaching the gripper to the arm flange remain in place and are tightened. Make sure that there is grease on the spindles and sliders. |
| Shell/Cover | <ul style="list-style-type: none"> The shell/cover is not loose. No cracks or other mechanical damage. <div style="margin-top: 10px;">  Note Mechanical damage can only be inspected by removing the cover with appropriate tools and ESD precautions. </div> |
| Finger | <ul style="list-style-type: none"> No finger is loose. Gripping jaws are correctly mounted on finger and not loose. Workpiece fit properly in between gripping jaws, no wear. The screws attaching the fingers to the finger brackets remain in place and are tightened. No cracks or mechanical damage are in the fingers. |
| Suction tools | Suction cup(s) and filter(s) are properly fastened and has no mechanical damage. |
| Camera window | The window is clean and has no damage. |
| LEDs and lightguides | The LEDs and lightguides are functional. |

This page is intentionally left blank

4 Repair

4.1 Introduction

Structure of this chapter

This chapter describes all repair activities recommended for the IRB 14050 gripper. It is made up of separate procedures, each describing a specific repair activity. Each procedure contains all the information required to perform the activity, for example spare parts numbers, required special tools, and materials. The procedures are gathered in sections, divided according to the component location on the IRB 14050 gripper.

Required equipment

The details of the equipment required to perform a specific repair activity are listed in the respective procedures. The details of equipment are also available in different lists in the chapter [Reference information on page 153](#).

Safety information

There are general safety information and specific safety information. The specific safety information describes the danger and safety risks while performing specific steps in a procedure. Make sure to read through the chapter [Safety on page 11](#) before commencing any service work.



Note

If the robot where the gripper shall be mounted is connected to power, always ensure that the robot is OFF and is connected to protective earth before starting any installation work.

Product manual - IRB 14050

4 Repair

4.2 Replacing the filter and suction cup

4.2 Replacing the filter and suction cup

Location of the filter and suction cup

The filter and suction cup are located as shown in the figure.



xx150000628

| | |
|---|-------------|
| A | Suction cup |
| B | Filter |

Required tools and equipment

| Equipment | Article number | Note |
|------------------|----------------|--|
| Standard toolkit | - | Content is defined in section Standard toolkit on page 155 . |

Required spare parts


| Spare part | Article number | Note |
|-------------------|----------------|------|
| Vacuum filter | 3HAC047854-001 | |
| Vacuum rubber cup | 3HAC047927-001 | |

Continues on next page

Removing the filter and suction cup

Use this procedure to remove the filter and suction cup.

Removing the whole gripper

| | Action | Note |
|---|---|--|
| 1 | <p> CAUTION</p> <p>Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur.</p> <p>Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off.</p> | <p>For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46.</p> |
| 2 | <p>Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw.</p> |  <p>xx1500001390</p> |
| 3 | <p>Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange.</p> | |

Continues on next page

4 Repair

4.2 Replacing the filter and suction cup

Continued

Removing the filter and suction cup

| | Action | Note/Illustration |
|---|---|---|
| 1 | Twist and remove the filter and suction cup.  Note The filter and suction cup are provided as a set and recommended to be replaced together. A built-in screw is mounted on the filter, which enables a simple removal of filter and suction cup by just twisting them. |  <p data-bbox="957 728 1061 750">xx1400002624</p> <p data-bbox="989 761 1165 828"> A Suction cup B Filter </p> |

Refitting the filter and suction cup

Use this procedure to refit the filter and suction cup.


Refit the filter and suction cup


| | Action | Note/Illustration |
|---|--|---|
| 1 | Refit the filter and suction cup by twisting them. | <p data-bbox="957 1064 1404 1131"> Vacuum filter , 3HAC047854-001 Vacuum rubber cup , 3HAC047927-001 </p>  <p data-bbox="957 1489 1061 1512">xx1400002624</p> <p data-bbox="989 1523 1165 1590"> A Suction cup B Filter </p> |

Refitting the whole gripper


| | Action | Note |
|---|---|--|
| 1 |  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off. | For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 . |

Continues on next page

| | Action | Note |
|---|---|--|
| 2 | Position the gripper to the arm tool flange on the axis 6 of the robot. |  <p>xx1500001394</p> <p>A Arm tool flange B Axis 6 of the robot</p> |
| 3 | Use the guide pin and air hose hole to make the gripper align with the arm tool flange. | For the positions of the guide pin and air hose hole, see Mounting flange on page 33 . |
| 4 | For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged. | O-ring 4x2: 3HAC063220-001 (1 pcs) |
| 5 | Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs) |



xx1500001625





xx1500001391

Continues on next page

4 Repair

4.2 Replacing the filter and suction cup


Continued

| | Action | Note |
|---|--|---|
| 6 | Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001392 |
| 7 | Rotate the flange with 90 degrees to access the last screw hole and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001393 |
| 8 | Turn on the power and air supply to the gripper and then perform commissioning on the gripper. | |

4.3 Replacing the fingers

Location of the fingers

The fingers are located as shown in the figure.



xx1400002616

Required tools and equipment

| Equipment | Article number | Note |
|------------------|----------------|--|
| Standard toolkit | - | Content is defined in section Standard toolkit on page 155 . |

Required spare parts

| Spare part | Article number | Note |
|---------------------------|----------------|---|
| Fingers | 3HAC052976-001 | Two getting-started fingers are delivered with the gripper. It is also possible to use customized fingers based on actual requirements. |
| Hex socket head cap screw | 3HAC051700-001 | |

Continues on next page

4 Repair


4.3 Replacing the fingers

Continued

Removing the fingers



Use this procedure to remove the fingers.

Removing the whole gripper

| | Action | Note |
|---|--|--|
| 1 |  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off. | For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 . |
| 2 | Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw. |  xx1500001390 |
| 3 | Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange. | |

Continues on next page

Removing the fingers

| | Action | Note/Illustration |
|---|--|--|
| 1 | Remove the screws that hold the finger. |  <p>xx1400002617</p> |
| 2 | If two pins are used for positioning, remove the pins. |  <p>xx1500000607</p> |
| 3 | Pull out the finger from the finger flange. | |

Refitting the fingers

Use this procedure to refit the fingers.

Refitting the fingers



| | Action | Note/Illustration |
|---|--|--------------------------|
| 1 | Place a new finger on the finger flange. | Fingers , 3HAC052976-001 |

Continues on next page

4 Repair

4.3 Replacing the fingers




Continued

| | Action | Note/Illustration |
|---|---|---|
| 2 | <p>For metal fingers, insert two pins for positioning.</p> <p> Note</p> <p>Pins can be designed based on actual requirements. For details about the hole configuration, see Hole configuration, mounting base on page 35.</p> | <p>Pin (2 pcs for each finger) 2x6, h8 ISO 2338</p>  <p>xx150000607</p> |
| 3 | <p>Refit and tighten the screws.</p> | <p>Hex socket head cap screw , 3HAC051700-001: M2x7, class 8.8 (8 pcs) Tightening torque: 0.2 Nm</p>  <p>xx1400002617</p> |

Refitting the whole gripper

| | Action | Note |
|---|--|--|
| 1 | <p> CAUTION</p> <p>Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur.</p> <p>Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off.</p> | <p>For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46.</p> |

Continues on next page



| | Action | Note |
|---|---|--|
| 2 | Position the gripper to the arm tool flange on the axis 6 of the robot. |  <p>xx1500001394</p> <p>A Arm tool flange B Axis 6 of the robot</p> |
| 3 | Use the guide pin and air hose hole to make the gripper align with the arm tool flange. | For the positions of the guide pin and air hose hole, see Mounting flange on page 33 . |
| 4 | For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged. | O-ring 4x2: 3HAC063220-001 (1 pcs) |
| 5 | Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw. |  <p>xx1500001625</p>  <p>xx1500001391</p> |

Continues on next page

4 Repair

4.3 Replacing the fingers


Continued

| | Action | Note |
|---|--|---|
| 6 | Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001392 |
| 7 | Rotate the flange with 90 degrees to access the last screw hole and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001393 |
| 8 | Turn on the power and air supply to the gripper and then perform commissioning on the gripper. | |

4.4 Replacing the shell

Location of the shell

The shell is located as shown in the figure.



xx150000638

Required tools and equipment

| Equipment | Article number | Note |
|------------------|----------------|--|
| Standard toolkit | - | Content is defined in section Standard toolkit on page 155 . |

Required spare parts

| Spare part | Article number | Note |
|-------------------------------------|----------------|---|
| Shell complete (with camera window) | 3HAC054986-001 | Used for the gripper with a camera. Use together with O-ring 1.8x1.8 , 3HAB3772-175 |

Continues on next page

4 Repair


4.4 Replacing the shell

Continued

| Spare part | Article number | Note |
|--|----------------|--|
| Shell complete (without camera window) | 3HAC054987-001 | Used for the gripper without a camera. Use together with O-ring 1.8x1.8 , 3HAB3772-175 |
| O-ring 1.8x1.8 | 3HAB3772-175 | |

Removing the shell

Removing the whole gripper



| | Action | Note |
|---|--|--|
| 1 |  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off. | For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 . |
| 2 | Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw. |  xx1500001390 |
| 3 | Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange. | |

Continues on next page

Removing the filter and suction cup

| Action | Note/Illustration |
|--|---|
| <p>1 Twist and remove the filter and suction cup.</p> <p> Note</p> <p>The filter and suction cup are provided as a set and recommended to be replaced together. A built-in screw is mounted on the filter, which enables a simple removal of filter and suction cup by just twisting them.</p> |  <p>xx1400002624</p> <p>A Suction cup B Filter</p> |

Removing the shell

| Action | Note/Illustration |
|---|---|
| <p>1 Remove the screws that fasten the shell.</p> |  <p>xx1500000759</p> |
| <p>2 Press the locations shown in the figure gently to detach the shell.</p> <p>The shell consists of two parts:</p> <ul style="list-style-type: none"> • lower shell • upper shell |  <p>xx1400002152</p> |

Continues on next page



4 Repair

4.4 Replacing the shell


Continued

Refitting the shell

Refitting the shell

| | Action | Note/Illustration |
|---|--|--|
| 1 | Put the lower shell to the base plate and insert the locating pins on the lower shell to the location holes on the base plate. | <p data-bbox="959 421 1404 533">Shell complete (with camera window), 3HAC054986-001 Shell complete (without camera window), 3HAC054987-001</p>  <p data-bbox="959 972 1066 992">xx1400002155</p> |
| 2 | Put the upper shell to the base plate. |  <p data-bbox="959 1621 1066 1641">xx1500000769</p> |
| 3 | Press the lower shell and upper shell together. | |

Continues on next page

| | Action | Note/Illustration |
|---|---------------------------------------|--|
| 4 | Refit the screws to fasten the shell. | Screw M1.2 (2 pcs)  xx150000759 |

Refit the filter and suction cup

| | Action | Note/Illustration |
|---|--|---|
| 1 | Refit the filter and suction cup by twisting them. | Vacuum filter , 3HAC047854-001 Vacuum rubber cup , 3HAC047927-001  xx1400002624 A Suction cup B Filter |

Refitting the whole gripper




| | Action | Note |
|---|---|--|
| 1 |  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off. | For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 . |

Continues on next page



4 Repair

4.4 Replacing the shell

Continued

| | Action | Note |
|---|---|--|
| 2 | Position the gripper to the arm tool flange on the axis 6 of the robot. |  <p>xx1500001394</p> <p>A Arm tool flange B Axis 6 of the robot</p> |
| 3 | Use the guide pin and air hose hole to make the gripper align with the arm tool flange. | For the positions of the guide pin and air hose hole, see Mounting flange on page 33 . |
| 4 | For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged. | <p>O-ring 4x2: 3HAC063220-001 (1 pcs)</p>  <p>xx1500001625</p> |
| 5 | Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw. | <p>Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)</p>  <p>xx1500001391</p> |

Continues on next page

| | Action | Note |
|---|--|---|
| 6 | Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw. | <p>Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)</p>  <p>xx1500001392</p> |
| 7 | Rotate the flange with 90 degrees to access the last screw hole and then refit the screw. | <p>Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)</p>  <p>xx1500001393</p> |
| 8 | Turn on the power and air supply to the gripper and then perform commissioning on the gripper. | |


4 Repair

4.5 Replacing the pneumatic block

4.5 Replacing the pneumatic block

Location of the pneumatic block

The pneumatic block is located as shown in the figure.



xx1400002626

Required tools

| Equipment | Article number | Note |
|------------------|----------------|--|
| Standard toolkit | - | Content is defined in section Standard toolkit on page 155 . |

Required spare parts


| Spare part | Article number | Note |
|---------------------------------|----------------|------|
| Pneumatic block | 3HAC054989-001 | |
| Pneumatic block | 3HAC054990-001 | |
| Vacuum sensor | 3HAC047823-001 | |
| Pneumatic block connector board | 3HAC051609-001 | |

Continues on next page

| Spare part | Article number | Note |
|---|----------------|----------------------|
| FFC for pneumatic block connector board | 3HAC051610-002 | 9 pin; pitch 1.0 |
| FFC for camera | 3HAC054157-002 | 31 pin; 76-mm length |

Removing the pneumatic block

Removing the whole gripper

| | Action | Note |
|---|--|--|
| 1 |  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off. | For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 . |
| 2 | Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw. |  <small>xx1500001390</small> |
| 3 | Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange. | |

Continues on next page

4 Repair



4.5 Replacing the pneumatic block

Continued

Removing the filter and suction cup




| Action | Note/Illustration |
|--|--|
| <p>1 Twist and remove the filter and suction cup.</p> <p> Note</p> <p>The filter and suction cup are provided as a set and recommended to be replaced together. A built-in screw is mounted on the filter, which enables a simple removal of filter and suction cup by just twisting them.</p> |  <p>xx1400002624</p> <p>A Suction cup B Filter</p> |

Removing the shell

| Action | Note/Illustration |
|--|--|
| <p>1 Remove the screws that fasten the shell.</p> |  <p>xx1500000759</p> |
| <p>2 Press the locations shown in the figure gently to detach the shell.</p> <p>The shell consists of two parts:</p> <ul style="list-style-type: none">• lower shell• upper shell |  <p>xx1400002152</p> |

Continues on next page

Removing the pneumatic block




| | Action | Note/Illustration |
|---|--|--|
| 1 | Disconnect the connectors from the vacuum sensor and valve. |  <p>xx1400002618</p> |
| 2 | Disconnect the motor cable. |  <p>xx1400002619</p> |
| 3 | For the left pneumatic block, disconnect the flexible cable for connector board. |  <p>xx150000608</p> |

Continues on next page



4 Repair

4.5 Replacing the pneumatic block

Continued


| | Action | Note/Illustration |
|---|--|---|
| 4 | For the gripper with a camera, disconnect the flexible flat cable (FFC) from the camera. |  <p>xx150000612</p> |
| 5 | Remove the screws to detach the main PCB. |  <p>xx1400002621</p> |
| 6 | Remove the screws to detach the pneumatic block from the servo base. |  <p>xx150000610</p> |

Continues on next page

| | Action | Note/Illustration |
|---|--|---|
| 7 | For the left pneumatic block, remove the screws to remove the connector board. |  <p>xx150000609</p> |
| 8 | Remove the vacuum sensor. |  <p>xx210000696</p> |

Refitting the pneumatic block

Refitting the pneumatic block




| | Action | Note/Illustration |
|---|--------------------------|---|
| 1 | Refit the vacuum sensor. | <p>Vacuum sensor, 3HAC047823-001</p>  <p>xx210000696</p> |

Continues on next page


4 Repair

4.5 Replacing the pneumatic block


Continued

| | Action | Note/Illustration |
|---|--|--|
| 2 | For the left pneumatic block, refit the connector board with screws. | <p>Pneumatic block connector board, 3HAC051609-001</p>  <p>xx150000609</p> |
| 3 | Refit the new pneumatic block to the servo base with screws. | <p>Screw M2.5 (3 pcs) Pneumatic block, 3HAC054989-001 Pneumatic block, 3HAC054990-001</p>  <p>xx150000610</p> |
| 4 | Refit the main PCB. |  <p>xx1400002621</p> |

Continues on next page

| | Action | Note/Illustration |
|---|---|---|
| 5 | Check the FFC for the pneumatic block connector board and FFC for the camera. Replace if damaged. | FFC for pneumatic block connector board, 3HAC051610-002 FFC for camera, 3HAC054157-002 |
| 6 | Reconnect the connectors: <ul style="list-style-type: none"> • Vacuum sensor and valve • motor cable • FFC for the pneumatic block connector board • FFC for the camera |  <p>xx1400002628</p> |

Refitting the shell



| | Action | Note/Illustration |
|---|--|--|
| 1 | Put the lower shell to the base plate and insert the locating pins on the lower shell to the location holes on the base plate. | Shell complete (with camera window), 3HAC054986-001 Shell complete (without camera window), 3HAC054987-001  <p>xx1400002155</p> |

Continues on next page

4 Repair

4.5 Replacing the pneumatic block

Continued


| | Action | Note/Illustration |
|---|---|---|
| 2 | Put the upper shell to the base plate. |  <p>xx150000769</p> |
| 3 | Press the lower shell and upper shell together. | |
| 4 | Refit the screws to fasten the shell. | <p>Screw M1.2 (2 pcs)</p>  <p>xx150000759</p> |

Continues on next page

Refit the filter and suction cup

| | Action | Note/Illustration |
|---|--|--|
| 1 | Refit the filter and suction cup by twisting them. | <p>Vacuum filter , 3HAC047854-001 Vacuum rubber cup , 3HAC047927-001</p>  <p>xx1400002624</p> <p>A Suction cup B Filter</p> |

Refitting the whole gripper




| | Action | Note |
|---|--|--|
| 1 | <p> CAUTION</p> <p>Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur.</p> <p>Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off.</p> | <p>For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46.</p> |
| 2 | Position the gripper to the arm tool flange on the axis 6 of the robot. |  <p>xx1500001394</p> <p>A Arm tool flange B Axis 6 of the robot</p> |

Continues on next page


4 Repair

4.5 Replacing the pneumatic block

Continued

| | Action | Note |
|---|---|--|
| 3 | Use the guide pin and air hose hole to make the gripper align with the arm tool flange. | For the positions of the guide pin and air hose hole, see Mounting flange on page 33 . |
| 4 | For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged. | O-ring 4x2: 3HAC063220-001 (1 pcs)  xx1500001625 |
| 5 | Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001391 |
| 6 | Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001392 |

Continues on next page

| | Action | Note |
|---|--|--|
| 7 | Rotate the flange with 90 degrees to access the last screw hole and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001393 |
| 8 | Turn on the power and air supply to the gripper and then perform commissioning on the gripper. | |


4 Repair

4.6 Replacing the camera

4.6 Replacing the camera

Location of the camera

The camera is located as shown in the figure.



xx150000611

Required tools

| Equipment | Article number | Note |
|------------------|----------------|--|
| Standard toolkit | - | Content is defined in section Standard toolkit on page 155 . |


Required spare parts

| Spare part | Article number | Note |
|---------------------------|----------------|----------------------|
| Camera AE3 | 3HAC051676-001 | |
| Hex socket head cap screw | 3HAC051700-001 | |
| FFC for camera | 3HAC054157-002 | 31 pin; 76-mm length |

Continues on next page

Removing the camera

Removing the whole gripper

| | Action | Note |
|---|--|--|
| 1 |  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off. | For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 . |
| 2 | Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw. |  xx1500001390 |
| 3 | Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange. | |

Removing the filter and suction cup

| | Action | Note/Illustration |
|---|---|--|
| 1 | Twist and remove the filter and suction cup.  Note The filter and suction cup are provided as a set and recommended to be replaced together. A built-in screw is mounted on the filter, which enables a simple removal of filter and suction cup by just twisting them. |  xx1400002624 A Suction cup B Filter |



Continues on next page

4 Repair


4.6 Replacing the camera

Continued


Removing the shell

| | Action | Note/Illustration |
|---|---|---|
| 1 | Remove the screws that fasten the shell. |  <p>xx150000759</p> |
| 2 | Press the locations shown in the figure gently to detach the shell. The shell consists of two parts: <ul style="list-style-type: none">• lower shell• upper shell |  <p>xx1400002152</p> |

Removing the camera



| | Action | Note |
|---|-------------------------------------|---|
| 1 | Disconnect the FFC from the camera. |  <p>xx150000612</p> |

Continues on next page

| | Action | Note |
|---|---|--|
| 2 | Remove the screws to detach the camera with the camera bracket from the servo base. |  <p>xx1500000614</p> |

Refitting the camera

Refitting the camera

| | Action | Note/Illustration |
|---|---|---|
| 1 | Refit the camera with the camera bracket to the servo base. | <p>Camera AE3, 3HAC051676-001 Hex socket head cap screw , 3HAC051700-001: M2x7, class 8.8 (2 pcs)</p>  <p>xx1500000614</p> |
| 2 | Check the FFC for the camera. Replace if damaged. | FFC for camera, 3HAC054157-002 |
| 3 | Connect the FFC to the camera. |  <p>xx1500000612</p> |



Continues on next page

4 Repair


4.6 Replacing the camera

Continued

Refitting the shell

| | Action | Note/Illustration |
|---|--|---|
| 1 | Put the lower shell to the base plate and insert the locating pins on the lower shell to the location holes on the base plate. | <p>Shell complete (with camera window), 3HAC054986-001</p> <p>Shell complete (without camera window), 3HAC054987-001</p>  <p>xx1400002155</p> |
| 2 | Put the upper shell to the base plate. |  <p>xx1500000769</p> |
| 3 | Press the lower shell and upper shell together. | |

Continues on next page

| | Action | Note/Illustration |
|---|---------------------------------------|--|
| 4 | Refit the screws to fasten the shell. | <p>Screw M1.2 (2 pcs)</p>  <p>xx150000759</p> |

Refit the filter and suction cup

| | Action | Note/Illustration |
|---|--|--|
| 1 | Refit the filter and suction cup by twisting them. | <p>Vacuum filter , 3HAC047854-001 Vacuum rubber cup , 3HAC047927-001</p>  <p>xx1400002624</p> <p>A Suction cup B Filter</p> |

Refitting the whole gripper




| | Action | Note |
|---|--|--|
| 1 | <p> CAUTION</p> <p>Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur.</p> <p>Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off.</p> | <p>For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46.</p> |

Continues on next page



4 Repair

4.6 Replacing the camera

Continued

| | Action | Note |
|---|---|--|
| 2 | Position the gripper to the arm tool flange on the axis 6 of the robot. |  <p>xx1500001394</p> <p>A Arm tool flange B Axis 6 of the robot</p> |
| 3 | Use the guide pin and air hose hole to make the gripper align with the arm tool flange. | For the positions of the guide pin and air hose hole, see Mounting flange on page 33 . |
| 4 | For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged. | <p>O-ring 4x2: 3HAC063220-001 (1 pcs)</p>  <p>xx1500001625</p> |
| 5 | Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw. | <p>Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)</p>  <p>xx1500001391</p> |

Continues on next page

| | Action | Note |
|---|--|---|
| 6 | Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw. | <p>Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)</p>  <p>xx1500001392</p> |
| 7 | Rotate the flange with 90 degrees to access the last screw hole and then refit the screw. | <p>Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)</p>  <p>xx1500001393</p> |
| 8 | Turn on the power and air supply to the gripper and then perform commissioning on the gripper. | |


4 Repair

4.7 Replacing the servo base

4.7 Replacing the servo base

Location of the servo base

The servo base is located as shown in the figure.



xx1400002623

Required tools

| Equipment | Article number | Note |
|------------------|----------------|--|
| Standard toolkit | - | Content is defined in section Standard toolkit on page 155 . |


Required spare parts

| Spare part | Article number | Note |
|------------|----------------|------|
| Servo base | 3HAC054988-001 | |

Continues on next page

Removing the servo base

Removing the whole gripper

| | Action | Note |
|---|--|--|
| 1 |  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off. | For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 . |
| 2 | Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw. |  xx1500001390 |
| 3 | Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange. | |

Removing the filter and suction cup

| | Action | Note/Illustration |
|---|---|--|
| 1 | Twist and remove the filter and suction cup.  Note The filter and suction cup are provided as a set and recommended to be replaced together. A built-in screw is mounted on the filter, which enables a simple removal of filter and suction cup by just twisting them. |  xx1400002624 A Suction cup B Filter |



Continues on next page

4 Repair


4.7 Replacing the servo base

Continued




Removing the shell

| | Action | Note/Illustration |
|---|---|---|
| 1 | Remove the screws that fasten the shell. |  <p>xx150000759</p> |
| 2 | Press the locations shown in the figure gently to detach the shell. The shell consists of two parts: <ul style="list-style-type: none">• lower shell• upper shell |  <p>xx1400002152</p> |

Removing the pneumatic block

| | Action | Note/Illustration |
|---|---|--|
| 1 | Disconnect the connectors from the vacuum sensor and valve. |  <p>xx1400002618</p> |

Continues on next page




| | Action | Note/Illustration |
|---|--|--|
| 2 | Disconnect the motor cable. |  <p>xx1400002619</p> |
| 3 | For the left pneumatic block, disconnect the flexible cable for connector board. |  <p>xx1500000608</p> |
| 4 | For the gripper with a camera, disconnect the flexible flat cable (FFC) from the camera. |  <p>xx1500000612</p> |

Continues on next page


4 Repair

4.7 Replacing the servo base



Continued

| | Action | Note/Illustration |
|---|--|--|
| 5 | Remove the screws to detach the main PCB. |  <p>xx1400002621</p> |
| 6 | Remove the screws to detach the pneumatic block from the servo base. |  <p>xx1500000610</p> |
| 7 | For the left pneumatic block, remove the screws to remove the connector board. |  <p>xx1500000609</p> |

Continues on next page

| | Action | Note/Illustration |
|---|---------------------------|---|
| 8 | Remove the vacuum sensor. |  <p data-bbox="986 750 1093 772">xx210000696</p> |

Removing the camera

| | Action | Note |
|---|---|--|
| 1 | Disconnect the FFC from the camera. |  <p data-bbox="986 1265 1093 1288">xx150000612</p> |
| 2 | Remove the screws to detach the camera with the camera bracket from the servo base. |  <p data-bbox="986 1668 1093 1691">xx150000614</p> |

Continues on next page



4 Repair

4.7 Replacing the servo base


Continued

Refitting the servo base




Refitting the camera

| | Action | Note/Illustration |
|---|---|--|
| 1 | Refit the camera with the camera bracket to the servo base. | Camera AE3, 3HAC051676-001 Hex socket head cap screw , 3HAC051700-001: M2x7, class 8.8 (2 pcs)  xx150000614 |
| 2 | Check the FFC for the camera. Replace if damaged. | FFC for camera, 3HAC054157-002 |
| 3 | Connect the FFC to the camera. |  xx150000612 |

Refitting the pneumatic block

| | Action | Note/Illustration |
|---|--------------------------|---|
| 1 | Refit the vacuum sensor. | Vacuum sensor, 3HAC047823-001  xx210000696 |

Continues on next page


| | Action | Note/Illustration |
|---|--|--|
| 2 | For the left pneumatic block, refit the connector board with screws. | <p>Pneumatic block connector board, 3HAC051609-001</p>  <p>xx150000609</p> |
| 3 | Refit the new pneumatic block to the servo base with screws. | <p>Screw M2.5 (3 pcs) Pneumatic block, 3HAC054989-001 Pneumatic block, 3HAC054990-001</p>  <p>xx150000610</p> |
| 4 | Refit the main PCB. |  <p>xx1400002621</p> |

Continues on next page


4 Repair

4.7 Replacing the servo base



Continued

| | Action | Note/Illustration |
|---|---|--|
| 5 | Check the FFC for the pneumatic block connector board and FFC for the camera. Replace if damaged. | FFC for pneumatic block connector board, 3HAC051610-002 FFC for camera, 3HAC054157-002 |
| 6 | Reconnect the connectors: <ul style="list-style-type: none"> • Vacuum sensor and valve • motor cable • FFC for the pneumatic block connector board • FFC for the camera |  <p>xx1400002628</p> |

Refitting the shell

| | Action | Note/Illustration |
|---|--|---|
| 1 | Put the lower shell to the base plate and insert the locating pins on the lower shell to the location holes on the base plate. | Shell complete (with camera window), 3HAC054986-001 Shell complete (without camera window), 3HAC054987-001  <p>xx1400002155</p> |

Continues on next page

| | Action | Note/Illustration |
|---|---|---|
| 2 | Put the upper shell to the base plate. |  <p>xx150000769</p> |
| 3 | Press the lower shell and upper shell together. | |
| 4 | Refit the screws to fasten the shell. | <p>Screw M1.2 (2 pcs)</p>  <p>xx150000759</p> |

Continues on next page

4 Repair


4.7 Replacing the servo base

Continued




Refit the filter and suction cup

| | Action | Note/Illustration |
|---|--|---|
| 1 | Refit the filter and suction cup by twisting them. | Vacuum filter , 3HAC047854-001 Vacuum rubber cup , 3HAC047927-001  <small>xx1400002624</small> A Suction cup B Filter |

Refitting the whole gripper

| | Action | Note |
|---|---|--|
| 1 |  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off. | For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 . |
| 2 | Position the gripper to the arm tool flange on the axis 6 of the robot. |  <small>xx1500001394</small> A Arm tool flange B Axis 6 of the robot |

Continues on next page


| | Action | Note |
|---|---|---|
| 3 | Use the guide pin and air hose hole to make the gripper align with the arm tool flange. | For the positions of the guide pin and air hose hole, see Mounting flange on page 33 . |
| 4 | For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged. | O-ring 4x2: 3HAC063220-001 (1 pcs)  <small>xx1500001625</small> |
| 5 | Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  <small>xx1500001391</small> |
| 6 | Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  <small>xx1500001392</small> |

Continues on next page

4 Repair

4.7 Replacing the servo base

Continued

| | Action | Note |
|---|--|--|
| 7 | Rotate the flange with 90 degrees to access the last screw hole and then refit the screw. | Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001393 |
| 8 | Turn on the power and air supply to the gripper and then perform commissioning on the gripper. | |


5 RAPID references

5.1 Overview

RAPID instruction/function naming

A shorter name is introduced to each RAPID instruction/function, such as, `g_Init` corresponding to the original `Hand_Intialize`. The shorter and longer names of a RAPID instruction/function are totally compatible to each other, that is, having the same usage, arguments and syntax.

The longer names may become invalid in a short future. Users are recommended to use the shorter names that are also easy to remember and use. If the users continue using the longer instruction/function name, the following notification will be displayed to prompt the using of newly shorter ones.



xx1800001482

Continues on next page

5 RAPID references

5.1 Overview

Continued

Program execution on virtual controller

| If the following instruction/function is executed on the virtual controller, | Then, |
|---|---|
| <ul style="list-style-type: none">• g_Init• g_JogIn• g_JogOut• g_MoveTo• g_GripIn• g_GripOut• g_Calibrate• g_Stop• g_SetMaxSpd• g_SetForce• g_BlowOn1• g_BlowOn2• g_BlowOff1• g_BlowOff2 | the program execution returns immediately to the calling procedure. In this case, the gripper performs no action and no error reports. |
| <ul style="list-style-type: none">• g_VacuumOn1• g_VacuumOn2• g_VacuumOff1• g_VacuumOff2 | the program execution returns HIGH after turning on the vacuum channel and returns LOW after turning off the vacuum channel. |
| <ul style="list-style-type: none">• g_GetPos• g_GetSpd• g_GetErrID• g_GetState | the program execution returns 0. |
| <ul style="list-style-type: none">• g_GetPressure1• g_GetPressure2 | the program execution returns 0 if the vacuum channel was turned on before by using g_VacuumOn1 or g_VacuumOn2 and returns 100 if the vacuum channel was turned off before by using g_VacuumOff1 or g_VacuumOff2 . g_GetPressure1 is for the first pneumatic module and g_GetPressure2 is for the second pneumatic module. |
| <ul style="list-style-type: none">• g_IsCalibrated• g_isCamOnline | the program execution returns FALSE. |

5.2 Instructions

5.2.1 RAPID instructions for grippers

5.2.1.1 g_Init - Initialize the gripper

Usages

`g_Init` (replacing the original `Hand_Intialize`) is used to initialize the gripper with optionally specified values. For the values that are not specified, the default values will be used.

This instruction can be called before all other gripper-related statements.

Basic examples

Example 1

```
g_Init \maxSpd := 20, \holdForce := 10;
```

In this example, the gripper will be initiated with a maximum speed of 20 mm/s and a holding force of 10 N.

Example 2

```
g_Init \Calibrate;
```

In this example, the gripper will be initiated with default parameter values. The argument `Calibrate` is used to close the fingers and then perform a calibration without holding force.

Example 3

```
g_Init \Calibrate, \Grip;
```

In this example, the gripper will be initiated with default parameter values. The argument `Grip` is used to close the fingers and then perform a calibration with the default holding force of 20 N.

Arguments

```
g_Init [\maxSpd] [\holdForce] [\phyLimit] [\Calibrate] [\Grip]
```

`[\maxSpd]`

Data type: num

The gripper's maximum allowed speed in unit of mm/s. If it is not set, the default maximum speed 25 mm/s will be used.

`[\holdForce]`

Data type: num

The gripper's expected force in unit of N when gripping and holding the target object. If this is not set, the default force 20 N will be used.

`[\phyLimit]`

Data type: num

Continues on next page

5 RAPID references

5.2.1.1 g_Init - Initialize the gripper

Continued

Sometimes, the gripper works in a smaller travel range than the recommended value 25 mm. Given this argument, the system will use the value to determine the maximum possible travel range of the gripper.

The value should be within 0-25 mm. If it is not set, the default value 25 will be used.

`[\Calibrate]`

Data type: `switch`

If this argument is declared, the gripper will undergo a calibrating process without holding force. Note that the gripper will move inward to the limit first.

`[\Grip]`

Data type: `switch`

If this argument is declared, the gripper will undergo a calibrating process with the default holding force of 20 N. Note that the gripper will move inward to the limit first.

This argument is always used together with the argument `[\Calibrate]`.

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Program execution

If `Calibrate` or `[\Grip]` is declared, the program will pause until the calibration process is completed.

Syntax

```
g_Init
  [\' maxSpd ::='] <expression (IN) of num> ', '
  [\' holdForce ::='] <expression (IN) of num> ', '
  [\' phyLimit ::='] <expression (IN) of num> ', '
  [\' Calibrate ] ', '
  [\' Grip ] ';'
;
```

5.2.1.2 g_JogIn - Jog the gripper to move inward

Usages

`g_JogIn` (replacing the original `Hand_JogInward`) is used to move the gripper inward, and does not stop until reaching a mechanical limit or timeout.

Basic examples

```
g_JogIn;
```

Limitations

This instruction is allowed only in gripper tasks `T_ROB1`.

Program execution

The program will pause until the gripper reaches a mechanical limit or timeout. Even if the gripper is stuck mechanically, no error or warning is raised and the program execution will go on.

Syntax

```
g_JogIn ' ; '
```

5 RAPID references

5.2.1.3 g_JogOut - Jog the gripper to move outward

5.2.1.3 g_JogOut - Jog the gripper to move outward

Usages

`g_JogOut` (replacing the original `Hand_JogOutward`) is used to move the gripper outward, and does not stop until reaching a mechanical limit or timeout.

Basic examples

```
g_JogOut ;
```

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Program execution

The program will pause until the gripper reaches a mechanical limit or timeout. Even if the gripper is stuck mechanically, no error or warning is raised and the program execution will go on.

Syntax

```
g_JogOut ' ; '
```

5.2.1.4 g_MoveTo - Move the gripper to a target position

Usages

`g_MoveTo` (replacing the original `Hand_MoveTo`) is used to move the gripper to a specified position and requires that the gripper must have been calibrated.

Basic examples

Example 1

```
g_MoveTo 15;
```

In this example, the gripper will move to the position that is 15 mm away from the calibrated zero point. The program will pause until the movement is completed.

Example 2

```
g_MoveTo 20, \NoWait;
```

In this example, the gripper will move to the position that is 20 mm away from the calibrated zero point. However, the program will continue to the next statement regardless of whether the movement has completed or not.

Arguments

```
g_MoveTo [targetPos] [\NoWait]
```

[targetPos]

Data type: num

The target position to which the gripper is specified to move with the unit of mm. The value should be within 0-25 mm or 0-`phyLimit` if `phyLimit` is set in `g_Init`.

[\NoWait]

Data type: switch

If `NoWait` is set, the program will continue to the next statement upon the sending of the command to the gripper, regardless of whether the movement has completed or not.

Limitations

This instruction is allowed only in gripper tasks `T_ROB1`.

Program execution

If `NoWait` is not set, the program will pause for the movement to complete or raise an error when the movement is not completed within the given time 5 seconds.

If `NoWait` is set, the program will go directly to the next statement regardless of the movement status. However, the program may need to check the movement result later.

If the specified distance is too small, for example, less than 0.2 mm, the gripper will not move.

Continues on next page

5 RAPID references

5.2.1.4 g_MoveTo - Move the gripper to a target position

Continued

Error handling

If the gripper is not calibrated, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_NOTCALIBRATED`. The error can be handled in the error handler.

If the gripper does not reach the specified target position within the given time 5 seconds, or the movement is mechanically blocked before reaching the target position, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_FAILEDMOVEPOS`. The error can be handled in the error handler. If `NoWait` is set, `ERR_HAND_FAILEDMOVEPOS` will not be raised.

If the robot loses the communication with the gripper, the error `ERR_NORUNUNIT` will be raised.

Syntax

```
g_MoveTo
  [targetPos ']:='] <expression (IN) of num> ', '
  ['\ ' NoWait ] ';'

```

5.2.1.5 g_GripIn - Jog the gripper to grip inward

Usages

`g_GripIn` (replacing the original `Hand_GripInward`) is used to indicate the gripper to grip inward and requires that the gripper must be calibrated.

Basic examples

Example 1

```
g_GripIn;
```

In this example, the gripper will try to grip inward with the default force. If there is no object, the two fingers of the gripper will move together and press each other tightly.

Example 2

```
g_GripIn \holdForce := 15;
```

In this example, the gripper is instructed to grip the target object with a 15 N force.

Example 3

```
g_GripIn \holdForce :=15, \ targetPos := 10;
```

In this example, the gripper will try to successfully grip around the particular point (10 mm) with a 15 N force. If the gripper does not touch any object in that point, an error is raised.

Example 4

```
g_GripIn \ targetPos:=5, \ posAllowance := 1;
```

In this example, the gripper will try to successfully grip around the particular point (5 mm) with the default force. The gripping position should be at 5 ± 1 mm. Otherwise, an error is raised.

Example 5

```
g_GripIn \NoWait;
```

In this example, the gripper will directly grip inward with the default force. Instead of waiting for the completion of gripping, the RAPID program will go to the next statement directly after sending out the gripping command.

In this case, the user should check the completion of gripping operation themselves. This argument is used to achieve a fast gripping operation without any lag in robot moving. For details, see example 6.

Example 6

```

BOOL GripSuccess:=FALSE;
BOOL GripEvaluated :=FALSE;
MoveL Offs(GripPosition,0,0,50), z10
MoveLSync Offs(GripPosition,0,0,5), z0,"CloseHand";
MoveL GripPosition,z0;
MoveLSync Offs(GripPosition,0,0,50), z10,"EvaluateGrip";
MoveL GripComple, z10
Waituntil GripEvaluated;
IF GripSuccess THEN
! go on with next step.
```

Continues on next page

5 RAPID references

5.2.1.5 g_GripIn - Jog the gripper to grip inward

Continued

```
ELSE
  ! retry to pick the part.
ENDIF
PROC CloseHand()
g_GripIn\NoWait;
ENDPROC
PROC EvaluateGrip()
WaitUnit Hand_GetActualSpd(=0;
IF Hand_GetActualPos() > 10 AND Hand_GetActualPos()<12 THEN
GripSuccess:=TRUE;
ELSE
GripSuccess:=FALSE;
ENDIF
GripEvaluated:=TRUE;
ENDPROC
```

In this example, the gripping operation will be executed as an interrupt. That means that even a continuous robot moving without fine point pause is allowed here. After the gripping operation, the program will check whether this gripping is successfully performed.

Arguments

`g_GripIn` [`\holdForce`] [`\targetPos`] [`posAllowance`][`\NoWait`]

[`\holdForce`]

Data type: num

The force used by the gripper to hold the object. The value should be within 0-20 N. If this argument is not assigned, the default value 20 N will be used.

[`\targetPos`]

Data type: num

If `targetPos` is set but the gripper does not touch any object within the range from `targetPos-posAllowance` to `targetPos+posAllowance`, an error is raised.

The value should be within 0-25 mm.

[`posAllowance`]

Data type: num

Ignored if `targetPos` is not set.

If `targetPos` is set but `posAllowance` is not, the default value 2 will be used.

[`\NoWait`]

Without this argument, the program will wait until a completion or failure of gripping operation.

If this argument is declared, the program will go to the next statement directly regardless of how the gripping will be executed.

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Continues on next page

Program execution

If `NoWait` is not declared, the program will pause until the gripper holds the object successfully. Otherwise, an error is raised. If `NoWait` is declared, the call to this instruction will be ended and the program will directly go to the next statement.

If no detection is required, both `targetPos` and `posAllowance` can be omitted.

The gripping is supposed to last less than 5 minutes in normal operations. To avoid overheating of the gripper and other impacts caused by a long time of continuous gripping, the gripping force will be released automatically after an uninterrupted gripping for 30 minutes.

Error handling

If the gripper is not calibrated, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_NOTCALIBRATED`. The error can be handled in the error handler.

If the gripper is not in an expected state, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_WRONGSTATE`. The error can be handled in the error handler.

If `targetPos` is set but the object is not held within the expected range, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_FAILEDGRIPPOS`. The error can be handled in the error handler.

If `targetPos` is set to a larger value than the current position, the gripper cannot grip with an inward force. Then, an error is raised and the system variable `ERRNO` will be set to `FAILEDGRIPINWARD`. The error can be handled in the error handler.

Syntax

```
g_GripIn
  ['\ ' holdForce ':='] <expression (IN) of num> ', '
  ['\ ' targetPos ':='] <expression (IN) of num> ', '
  ['\ ' posAllowance ':='] <expression (IN) of num> ', '
  ['\ ' NoWait ] ';'

```

5 RAPID references

5.2.1.6 g_GripOut - Jog the gripper to grip outward

5.2.1.6 g_GripOut - Jog the gripper to grip outward

Usages

`g_GripOut` (replacing the original `Hand_GripOutward`) is used to indicate the gripper to grip outward and requires that the gripper must be calibrated.

Basic examples

Example 1

```
g_GripOut;
```

In this example, the gripper will try to grip outward with the default force. If there is no object to grip, the two fingers of the gripper will press tightly against the mechanic limits.

Example 2

```
g_GripOut \holdForce := 15;
```

In this example, the gripper is instructed to grip the target object with a 15 N outward force.

Example 3

```
g_GripOut \holdForce :=15, \targetPos := 10;
```

In this example, the gripper will try to successfully grip around the particular point (10 mm) with a 15 N force. If the gripper does not touch any object in that point, an error is raised.

Example 4

```
g_GripOut \targetPos:=5, \posAllowance := 1;
```

In this example, the gripper will try to successfully grip around the particular point (5 mm) with the default outward force. The gripping position should be at 5 ± 1 mm. Otherwise, an error is raised.

Example 5

```
g_GripOut \NoWait;
```

In this example, the gripper will directly grip outward with the default force. Instead of waiting for the completion of gripping, the RAPID program will go to the next statement directly after sending out the gripping command.

In this case, the user should check the completion of gripping operation themselves. This argument is used to achieve a fast gripping operation without any lag in robot moving. For details, see example 6.

Example 6

```
BOOL GripSuccess:=FALSE;  
BOOL GripEvaluated :=FALSE;  
MoveL Offs(GripPosition,0,0,50), z10  
MoveLSync Offs(GripPosition,0,0,5), z0,"CloseHand";  
MoveL GripPosition,z0;  
MoveLSync Offs(GripPosition,0,0,50), z10,"EvaluateGrip";  
MoveL GripComple, z10  
Waituntil GripEvaluated;  
IF GripSuccess THEN
```

Continues on next page

5.2.1.6 g_GripOut - Jog the gripper to grip outward
Continued

```

! go on with next step.
ELSE
! retry to pick the part.
ENDIF
PROC CloseHand()
g_GripOut\NoWait;
ENDPROC
PROC EvaluateGrip()
WaitUnit Hand_GetActualSpd()=0;
IF Hand_GetActualPos() > 10 AND Hand_GetActualPos()<12 THEN
GripSuccess:=TRUE;
ELSE
GripSuccess:=FALSE;
ENDIF
GripEvaluated:=TRUE;
ENDPROC

```

In this example, the gripping operation will be executed as an interrupt. That means that even a continuous robot moving without fine point pause is allowed here. After the gripping operation, the program will check whether this gripping is successfully performed.

Arguments

```
g_GripOut [\holdForce] [\targetPos] [\posAllowance][\NoWait]
```

[\holdForce]

Data type: num

The force used by the gripper to hold the object. The value should be within 0-20 N. If this argument is not assigned, the default value 20 N will be used.

[\targetPos]

Data type: num

If **targetPos** is set but the gripper does not touch any object within the range from **targetPos-posAllowance** to **targetPos+posAllowance**, an error is raised.

The value should be within 0-25 mm.

[\posAllowance]

Data type: num

Ignored if **targetPos** is not set.

If **targetPos** is set but **posAllowance** is not, the default value 2 will be used.

[\NoWait]

Without this argument, the program will wait until a completion or failure of gripping operation.

If this argument is declared, the program will go to the next statement directly regardless of how the gripping will be executed.

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Continues on next page

5 RAPID references

5.2.1.6 g_GripOut - Jog the gripper to grip outward

Continued

Program execution

If `NoWait` is not declared, the program will pause until the gripper holds the object successfully. Otherwise, an error is raised. If `NoWait` is declared, the call to this instruction will be ended and the program will directly go to the next statement.

If no detection is required, both `targetPos` and `posAllowance` can be omitted.

The gripping is supposed to last less than 5 minutes in normal operations. To avoid overheating of the gripper and other impacts caused by a long time of continuous gripping, the gripping force will be released automatically after an uninterrupted gripping for 30 minutes.

Error handling

If the gripper is not calibrated, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_NOTCALIBRATED`. The error can be handled in the error handler.

If the gripper is not in an expected state, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_WRONGSTATE`. The error can be handled in the error handler.

If `targetPos` is set but the object is not held within the expected range, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_FAILEDGRIPPOS`. The error can be handled in the error handler.

If `targetPos` is set to a smaller value than the current position, the gripper cannot grip with an outward force. Then, an error is raised and the system variable `ERRNO` will be set to `FAILEDGRIPOUTWARD`. The error can be handled in the error handler.

Syntax

```
g_GripOut
  ['\ ' holdForce ':='] <expression (IN) of num> ', '
  ['\ ' targetPos ':='] <expression (IN) of num> ', '
  ['\ ' posAllowance ':='] <expression (IN) of num> ', '
  ['\ ' NoWait ] ';'

```

5.2.1.7 g_Calibrate - Calibrate the gripper

Usages

`g_Calibrate` (replacing the original `Hand_DoCalibrate`) is used to calibrate the gripper in a particular position. Only after the gripper is calibrated, it can be instructed to perform movement or gripping.

Basic examples

Example 1

```
g_Calibrate;
```

In this example, the gripper will set the current position as the zero point.

Example 2

```
g_Calibrate \Jog;
```

In this example, the two fingers of the gripper will move together at the middle point first and then that point will be set as the zero point.

Example 3

```
g_Calibrate \Grip;
```

In this example, the gripper will undergo a calibrating process with the default holding force of 20 N and set the current position as the zero point.

Argument

```
[\Jog] [\Grip]
```

`[\Jog]`

Data type: `switch`

With this argument is declared, the gripper fingers will move to the middle point first and then that point will be set as the zero point.

`[\Grip]`

Data type: `switch`

If this argument is declared, the gripper will undergo a calibrating process with the default holding force of 20 N and set the current position as the zero point.

Limitations

This instruction is allowed only in gripper tasks `T_ROB1`.

Program execution

The program does not continue to the next statement until the calibrating process is completed.

Syntax

```
g_Calibrate
  ['\ Jog] ','
  ['\ Grip] ';
```

5 RAPID references

5.2.1.8 g_Stop - Stop the gripper

5.2.1.8 g_Stop - Stop the gripper

Usages

`g_Stop` (replacing the original `Hand_Stop`) is used to stop any action of the gripper. Especially, the motor will lose power.

Basic examples

```
g_Stop;
```

Program execution

The instruction will stop any movement or gripping operation of the gripper. Then, the program will continue.

Syntax

```
g_Stop ';' ;
```

5.2.1.9 g_SetMaxSpd - Set the maximum speed

Usage

`g_SetMaxSpd` (replacing the original `Hand_SetMaxSpeed`) is used to set the maximum allowed speed of the gripper. Note that the actual maximum speed may be limited by the acceleration time.

Basic examples

```
g_SetMaxSpd 15;
```

In this example, the gripper is configured with a maximum allowed speed of 15 mm/s.

Arguments

```
g_SetMaxSpd maxSpd
```

`maxSpd`

Data type: num

The maximum allowed speed of the gripper in unit of mm/s.

The value should be within 0-25 mm/s.

Program execution

This instruction will give the gripper a new maximum speed. The new setting will be kept until you change it again or restart the robot system.

Error handling

If the robot loses the communication with the gripper, the error `ERR_NORUNUNIT` will be raised.

Syntax

```
g_SetMaxSpd  
[maxSpd ':='] <expression (IN) of num> ';' 
```

5 RAPID references

5.2.2.1 g_BlowOn1 - Turn on blowing channel 1

5.2.2 RAPID instructions for pneumatic modules

5.2.2.1 g_BlowOn1 - Turn on blowing channel 1

Usage

`g_BlowOn1` (replacing the original `Hand_TurnOnBlow1`) is used to turn on the blowing channel in gripper pneumatic module 1.

Basic examples

```
g_BlowOn1;
```

In this example, whether vacuum channel 1 is turned on will be inspected first and then is closed if necessary. Then, blow channel 1 will be turned on.

Program execution

The program will turn on the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_BlowOn1 ';' ;
```

5.2.2.2 g_BlowOff1 - Turn off blowing channel 1

Usage

`g_BlowOff1` (replacing the original `Hand_TurnOffBlow1`) is used to turn off the blowing channel in gripper pneumatic module 1.

Basic examples

```
g_BlowOff1;
```

In this example, blow channel 1 will be turned off.

Program execution

The program will turn off the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_BlowOff1 ';' ;'
```

5 RAPID references

5.2.2.3 g_BlowOn2 - Turn on blowing channel 2

5.2.2.3 g_BlowOn2 - Turn on blowing channel 2

Usage

`g_BlowOn2` (replacing the original `Hand_TurnOnBlow2`) is used to turn on the blowing channel in gripper pneumatic module 2.

Basic examples

```
g_BlowOn2;
```

In this example, whether vacuum channel 2 is turned on will be inspected first and then is closed if necessary. Then, blow channel 2 will be turned on.

Program execution

The program will turn on the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_BlowOn2 ';' ;'
```

5.2.2.4 g_BlowOff2 - Turn off blowing channel 2

Usage

`g_BlowOff2` (replacing the original `Hand_TurnOffBlow2`) is used to turn off the blowing channel in gripper pneumatic module 2.

Basic examples

```
g_BlowOff2;
```

In this example, blow channel 2 will be turned off.

Program execution

The program will turn off the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_BlowOff2 ';' ;'
```

5 RAPID references

5.2.2.5 g_VacuumOn1 - Turn on vacuum channel 1

5.2.2.5 g_VacuumOn1 - Turn on vacuum channel 1

Usage

`g_VacuumOn1` (replacing the original `Hand_TurnOnVacuum1`) is used to turn on the vacuum channel in hand pneumatic module 1. After turning on the vacuum channel, the vacuum pressure in the pneumatic module will also be verified with the given threshold. If there is no enough vacuum, an error is raised.

Basic examples

Example 1

```
g_VacuumOn1;
```

In this example, whether blowing channel 1 is turned on will be checked first and then is closed if necessary. Then, vacuum channel 1 will be turned on.

Example 2

```
g_VacuumOn1 \threshold := 30;
```

After turning on the vacuum valve, the program will also read the vacuum pressure from the interior sensor. If the pressure is larger than 30 kpa, an error is raised.

Arguments

```
g_VacuumOn1 \threshold;
```

`\threshold`

Data type: num

Expected upper limit of the vacuum pressure. Normally, the value should be within 0-110 kpa.

Program execution

The program will turn on the corresponding I/O signal. It will also read the vacuum pressure from the interior sensor and compare it with the given threshold. The vacuum has 1s to reach the expected pressure.

Error handling

If `threshold` is set but the reading value of the pressure sensor is larger than the `threshold`, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_FAILEDVACUUM`. The error can be handled in the error handler.

Syntax

```
g_VacuumOn1  
['\' threshold ':'] <expression (IN) of num> ';'
```

5.2.2.6 g_VacuumOff1 - Turn off vacuum channel 1

Usage

`g_VacuumOff1` (replacing the original `Hand_TurnOffVacuum1`) is used to turn off the vacuum channel in hand pneumatic module 1.

Basic examples

```
g_VacuumOff1;
```

In this example, vacuum channel 1 will be turned off.

Program execution

The program will turn off the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_VacuumOff1 ';' ;'
```

5 RAPID references

5.2.2.7 g_VacuumOn2 - Turn on vacuum channel 2

5.2.2.7 g_VacuumOn2 - Turn on vacuum channel 2

Usage

`g_VacuumOn2` (replacing the original `Hand_TurnOnVacuum2`) is used to turn is used to turn on the vacuum channel in hand pneumatic module 2. After turning on the vacuum channel, the vacuum pressure in the pneumatic module will also be verified with the given threshold. If there is no enough vacuum, an error is raised.

Basic examples

Example 1

```
g_VacuumOn2;
```

In this example, whether blowing channel 2 is turned on will be inspected first and then is closed if necessary. Then, vacuum channel 2 will be turned on.

Example 2

```
g_VacuumOn2 \threshold := 15;
```

After turning on the vacuum valve, the program will also read the vacuum pressure from the interior sensor. If the pressure is larger than 15 kpa, an error is raised.

Arguments

```
g_VacuumOn2 \threshold;
```

\threshold

Data type: num

Expected upper limit of the vacuum pressure. Normally, the value should be within 0-110 kpa.

Program execution

The program will turn on the corresponding I/O signal. It will also read the vacuum pressure from the interior sensor and compare it with the given threshold. The vacuum has 1s to reach the expected pressure.

Error handling

If threshold is set but the reading value of the pressure sensor is larger than the threshold, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_FAILEDVACUUM`. The error can be handled in the error handler.

Syntax

```
g_VacuumOn2  
['\ threshold ' := ' ] <expression (IN) of num> ' ;'
```

5.2.2.8 g_VacuumOff2 - Turn off vacuum channel 2

Usage

`g_VacuumOff2` (replacing the original `Hand_TurnOffVacuum2`) is used to turn off the vacuum channel in hand pneumatic module 1.
is used to turn off the vacuum channel in hand pneumatic module 2.

Basic examples

```
g_VacuumOff2;
```

In this example, vacuum channel 2 will be turned off.

Program execution

The program will turn off the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_VacuumOff2 ';' ;'
```

5 RAPID references

5.3.1.1 g_IsCalibrated - Get gripper calibration status

5.3 Functions

5.3.1 RAPID functions for servo module

5.3.1.1 g_IsCalibrated - Get gripper calibration status

Usages

`g_IsCalibrated` (replacing the original `Hand_IsCalibrated`) is used to retrieve the calibration status of the gripper.

Basic examples

```
VAR bool isRightHandCalibrated;  
isRightHandCalibrated := g_IsCalibrated();
```

Returned value

Data type: `bool`

The function will return `TRUE` if the gripper has been calibrated, while `FALSE` if not calibrated.

Syntax

```
g_IsCalibrated '('  
  [ Value ':= ' ] <expression (IN) of num>  
' )'
```

5.3.1.2 g_GetPos - Get current gripper position

Usages

`g_GetPos` (replacing the original `Hand_GetActualPos`) is used to retrieve the current position of the gripper, based on the previous calibrated zero point. Note that this result may have no sense if the gripper is not calibrated.

Basic examples

```
VAR num nRightHandPos;  
nRightHandPos:= g_GetPos();
```

Returned value

Data type: num

The function will return the value of the current position in unit of mm.

Error handling

If the communication to the corresponding gripper fails, the error `ERR_NORUNUNIT` will be raised.

If the gripper has not been calibrated, the error `ERR_NOTCALIBRATED` will be raised.

Syntax

```
g_GetPos '('  
  [ Value ':= ' ] <expression (IN) of num>  
' )'
```

5 RAPID references

5.3.1.3 g_GetSpd - Get current gripper speed

5.3.1.3 g_GetSpd - Get current gripper speed

Usages

`g_GetSpd` (replacing the original `Hand_GetActualSpd`) is used to retrieve the current speed of the gripper.

Basic examples

```
VAR num nRightHandSpd;  
nRightttHandSpd:= g_GetSpd();
```

Returned value

Data type: num

The function will return the value of the current speed in unit of mm/s.

Error handling

If the communication to the corresponding gripper fails, the error `ERR_NORUNUNIT` will be raised.

Syntax

```
g_GetSpd '('  
  [ Value ':= ' ] <expression (IN) of num>  
' )'
```

5.3.1.4 g_GetState - Get current gripper status

Usages

`g_GetState` (replacing the original `Hand_GetFingerState`) is used to retrieve the current state of the gripper.

Basic examples

```
VAR num nRightHandState;
nRightHandState:= g_GetState();
```

Returned value

Data type: num

The function will return the value of the current state. The following table describes the gripper states.

| Code | State | Description |
|------|------------------------|--|
| 0x0 | Ready | The gripper is in free state and ready for receiving new commands. |
| 0x1 | Error | The gripper is in error state. Check what the error is based on the error ID. For details about the error IDs, see Error handling on page 145 . |
| 0x2 | Free_Move_Outward | The gripper is moving outward. |
| 0x3 | Free_Move_Inward | The gripper is moving inward. |
| 0x4 | Grip_Move_Inward | The gripper is moving inward and the movement stops only after the gripper reaches the target object or mechanical limit. |
| 0x5 | Grip_Move_Outward | The gripper is moving outward. The moving will stop only after the gripper reaches the target object or mechanical limit. |
| 0x6 | Action_Completed | The command is executed successfully. |
| 0x7 | Grip_Forcing_Inward | The gripper is adjusting its inward gripping force. |
| 0x8 | Grip_Forcing_Outward | The gripper is adjusting its outward gripping force. |
| 0x9 | Keep_Object | The gripper has completed the gripping operation and is holding the object. |
| 0xA | Calibration | The gripper is under calibration. |
| 0xB | Jog_Open | The gripper is jogged to move outward. |
| 0xC | Jog_Close | The gripper is jogged to move inward. |
| 0x10 | Agile_Gripping_Inward | The gripper is moving inward with limited force (less than the assigned gripping force). The movement stops only after the gripper reaches the target object or mechanical limit. |
| 0x11 | Agile_Gripping_Outward | The gripper is moving outward with limited force (less than the assigned gripping force). The movement stops only after the gripper reaches the target object or mechanical limit. |

Continues on next page

5 RAPID references

5.3.1.4 g_GetState - Get current gripper status

Continued

Error handling

If the communication to the corresponding gripper fails, the error `ERR_NORUNUNIT` will be raised.

Syntax

```
g_GetState '('  
  [ Value ':= ' ] <expression (IN) of num>  
  ')'
```

5.3.1.5 g_GetErrID - Get current gripper error ID

Usages

`g_GetErrID` (replacing the original `Hand_GetFingerErrID`) is used to retrieve the current error ID of the gripper. The error ID indicates the error type and designed to store the last error. Note that even if the gripper is recovered from an error state, the error ID does not reset automatically.

Basic examples

```
VAR num nRightHandLastError;
nRightHandLastError:= g_GetErrID();
```

Returned value

Data type: num

The function returns the value of current error ID.

Error handling

If the communication to the corresponding gripper fails, the error `ERR_NORUNUNIT` will be raised.

The following table provides some common hardware exceptions and related handling actions.

| Error ID (HEX) | Error ID (BCD) | Description | Action |
|----------------|----------------|--|--|
| 0x00 | 0 | The system runs properly. | N/A |
| 0x51 | 81 | A wrong Hall sensor feedback is found in clockwise movement. | Check the connection between the Hall sensor output of the motor and the main board. |
| 0x52 | 82 | A wrong Hall sensor feedback is found in counter-clockwise movement. | Check the connection between the Hall sensor output of the motor and the main board. |
| 0x58 | 88 | There is an unexpected Hall sensor reading. | <ul style="list-style-type: none"> Check the motor cable connection. Check the motor or PCB. |
| 0x63 | 99 | The gripper is not calibrated. | Calibrate the gripper and try again. |
| 0x64 | 100 | The gripper is blocked. | Check whether there is anything blocking the gripper. |
| 0x65 | 101 | The object grasped by the gripper drops. | Increase the gripping force. |
| 0xF0 | 240 | The internal voltage is abnormal. | <ul style="list-style-type: none"> Check the power supply of the gripper. Check the MPB. |
| 0xF1 | 241 | The CPU temperature is over-high. | <ul style="list-style-type: none"> Check the cooling system. Check the MPB. |

Continues on next page

5 RAPID references

5.3.1.5 g_GetErrID - Get current gripper error ID

Continued

| Error ID (HEX) | Error ID (BCD) | Description | Action |
|----------------|----------------|----------------------------------|--|
| 0xF2 | 242 | The DC bus voltage is abnormal. | Check the power supply of the gripper. |
| 0xF3 | 243 | The DC bus current is too large. | Check the power supply of the gripper. |

Syntax

```
g_GetErrID '('  
  [ Value ':' '=' ] <expression (IN) of num>  
  ')'
```

5.3.2 RAPID functions for pneumatic module

5.3.2.1 g_GetPressure1 - Get vacuum pressure 1

Usages

`g_GetPressure1` (replacing the original `Hand_GetVacuumPressure1`) is used to retrieve the current vacuum pressure of pneumatic module 1. If the value 0 is returned, it means that no corresponding pneumatic module is included for this gripper or means there is no successful communication to the pressure sensor.

Basic examples

```
VAR num nRightHandPressure1;  
nRightHandPressure1:= g_GetPressure1();
```

Returned value

Data type: num

The function will return the value of that sensor in unit of kpa.

Error handling

If the communication to the corresponding gripper fails, the error `ERR_NORUNUNIT` will be raised.

Syntax

```
g_GetPressure1 '('  
  [ Value ':= ' ] <expression (IN) of num>  
  ')'
```

5 RAPID references

5.3.2.2 g_GetPressure2 - Get vacuum pressure 2

5.3.2.2 g_GetPressure2 - Get vacuum pressure 2

Usages

`g_GetPressure2` (replacing the original `Hand_GetVacuumPressure2`) is used to retrieve the current vacuum pressure of pneumatic module 2. If the value 0 is returned, it means that no corresponding pneumatic module is included for this gripper or means there is no successful communication to the pressure sensor.

Basic examples

```
VAR num nRightHandPressure2;  
nRightHandPressure2:= g_GetPressure2();
```

Returned value

Data type: num

The function will return the value of that sensor in unit of kpa.

Error handling

If the communication to the corresponding gripper fails, the error `ERR_NORUNUNIT` will be raised.

Syntax

```
g_GetPressure2 '('  
  [ Value ':= ' ] <expression (IN) of num>  
  ')'
```

5.3.3 RAPID functions for camera module

5.3.3.1 g_IsCamOnline - Get handheld camera connection status

Usages

`g_IsCamOnline` (replacing the original `Hand_IsCamConnected`) is used to retrieve the connection status of the handheld camera.

Basic examples

```
VAR bool isRighthCamConnected;  
isRightCamConnected:= g_IsCamOnline();
```

Returned value

Data type: `bool`

The function will return the connection status of the handheld camera. The value `TRUE` is for connected, while `FALSE` for unconnected.

Error handling

If the communication to the corresponding gripper fails, the error `ERR_NORUNUNIT` will be raised.

Syntax

```
g_IsCamOnline '('  
  [ Value ':= ' ] <expression (IN) of num>  
' )'
```


This page is intentionally left blank

6 Decommissioning

6.1 Environmental information

Symbol

The following symbol indicates that the product must not be disposed of as common garbage. Handle each product according to local regulations for the respective content (see table below).



xx180000058

Hazardous material

The table specifies some of the materials in the product and their respective use throughout the product.

Dispose components properly according to local regulations to prevent health or environmental hazards.

| Material | Example application |
|----------------|---|
| Aluminium | Other parts |
| Copper | Cables and motor |
| Magnesium | Base plate |
| Oil, grease | Linear guide, pinion and rack |
| Plastic/rubber | Cables, connectors, fingers, shell and vacuum units |
| Steel | Slide plates |

Oil and grease

Where possible, arrange for oil and grease to be recycled. Dispose of via an authorized person/contractor in accordance with local regulations. Do not dispose of oil and grease near lakes, ponds, ditches, down drains, or onto soil. Incineration must be carried out under controlled conditions in accordance with local regulations.

Also note that:

- Spills can form a film on water surfaces causing damage to organisms. Oxygen transfer could also be impaired.
- Spillage can penetrate the soil causing ground water contamination.

This page is intentionally left blank

7 Reference information

7.1 Introduction

General

This chapter includes general information, complementing the more specific information in the different procedures in the manual.

7 Reference information

7.2 Unit conversion

7.2 Unit conversion

Converter table

Use the following table to convert units used in this manual.

| Quantity | Units | | |
|----------|-------|--------------|----------|
| Length | 1 m | 3.28 ft. | 39.37 in |
| Weight | 1 kg | 2.21 lb. | |
| Weight | 1 g | 0.035 ounces | |
| Pressure | 1 bar | 100 kPa | 14.5 psi |
| Force | 1 N | 0.225 lbf | |
| Moment | 1 Nm | 0.738 lbf-ft | |
| Volume | 1 L | 0.264 US gal | |

7.3 Standard toolkit

General

All service (repairs, maintenance, and installation) procedures contains lists of tools required to perform the specified activity.

All special tools required are listed directly in the procedures while all the tools that are considered standard are gathered in the standard toolkit and defined in the following table.

This way, the tools required are the sum of the standard toolkit and any tools listed in the instruction.

Contents, standard toolkit

| Qty | Tool | Rem. |
|-----|--------------------------------------|------|
| 1 | Slot screwdriver for M1.2 | |
| 1 | Socket head cap screwdriver for M1.6 | |
| 1 | Socket head cap screwdriver for M2 | |
| 1 | Socket head cap screwdriver for M2.5 | |
| 1 | Plus screwdriver M2 | |
| 1 | Torx screwdriver M2 | |
| 1 | Tweezer | |

This page is intentionally left blank

8 Spare parts

8.1 Introduction

General

This chapter include spare part lists and spare part illustrations for the IRB 14050 gripper and all its variants.

Spare part level

ABB spare parts are categorized into two levels, L1 and L2. Always check the part level before conducting a service work on a spare part.

- L1 spare parts

The L1 parts can be replaced in the field. The maintenance and replacement instructions given in the related product manuals must be strictly followed. If there are any problems, contact your local ABB for support.

- L2 spare parts

To replace the L2 parts require specialized training and might need special tools. Only ABB field service personnel or qualified personnel trained by ABB can replace L2 parts.


8 Spare parts

8.2.1 Parts

8.2 Spare part lists and illustrations

8.2.1 Parts

Spare part list and exploded view for servo with vacuum and vision



xx150000640

| Pos | Article number | Description | Spare part level | Qty |
|-----|----------------|---|------------------|-----|
| A | 3HAC051608-001 | Main PCB | L1 | 1 |
| B | 3HAC063220-001 | O-ring 4x2 | L1 | 1 |
| C | 3HAB3772-175 | O-ring 1.8x1.8 | L1 | 1 |
| D | 3HAC051610-002 | FFC for pneumatic block connector board | L1 | 1 |
| E | 3HAC051609-001 | Pneumatic block connector board | L1 | 1 |

Continues on next page

8 Spare parts

8.2.1 Parts

Continued

| Pos | Article number | Description | Spare part level | Qty |
|-----|----------------|---|------------------|-----|
| F | 3HAC047823-001 | Vacuum sensor | L1 | 1 |
| G | 3HAC054989-001 | Pneumatic block | L1 | 1 |
| H | 3HAC051676-001 | Camera AE3 | L1 | 1 |
| J | 3HAC047854-001 | Vacuum filter | L1 | 2 |
| K | 3HAC047927-001 | Vacuum rubber cup | L1 | 2 |
| L | 3HAC054157-002 | FFC for camera | L1 | 1 |
| M | 3HAC054988-001 | Servo base | L1 | 1 |
| N | 3HAC051700-001 | Hex socket head cap screw (M2x7) | L1 | 8 |
| P | 3HAC052976-001 | Fingers  Note Gripper fingers are wear parts. | L1 | 1 |
| Q | 3HAB3772-173 | O-ring 7x1 | L1 | 1 |
| R | 3HAC054986-001 | Shell complete (with camera window) | L1 | 1 |


Continues on next page

8 Spare parts

8.2.1 Parts

Continued

Spare part list and exploded view for servo with vacuum1 and vacuum2



xx150000641

| Pos | Article number | Description | Spare part level | Qty |
|-----|----------------|---|------------------|-----|
| A | 3HAC051608-001 | Main PCB | L1 | 1 |
| B | 3HAB3772-175 | O-ring 1.8x1.8 | L1 | 1 |
| C | 3HAC052976-001 | Fingers  Note Gripper fingers are wear parts. | L1 | 1 |
| D | 3HAC047823-001 | Vacuum sensor | L1 | 2 |
| E | 3HAC054989-001 | Pneumatic block | L1 | 1 |

Continues on next page

8 Spare parts

8.2.1 Parts

Continued

| Pos | Article number | Description | Spare part level | Qty |
|-----|----------------|---|------------------|-----|
| F | 3HAC051610-002 | FFC for pneumatic block connector board | L1 | 2 |
| G | 3HAC054988-001 | Servo base | L1 | 1 |
| H | 3HAB3772-173 | O-ring 7x1 | L1 | 1 |
| K | 3HAC054990-001 | Pneumatic block | L1 | 1 |
| J | 3HAC051609-001 | Pneumatic block connector board | L1 | 2 |
| L | 3HAC054987-001 | Shell complete (without camera window) | L1 | 1 |
| M | 3HAC047854-001 | Vacuum filter | L1 | 2 |
| N | 3HAC047927-001 | Vacuum rubber cup | L1 | 2 |

This page is intentionally left blank

Index

A

air consumption, 22
aluminum
 disposal, 151
ambient humidity
 operation, 18
 storage, 18
ambient temperature
 operation, 18
 storage, 18

C

copper
 disposal, 151

E

environmental information, 151

G

g_BlowOff1, 133
g_BlowOff2, 135
g_BlowOn1, 132
g_BlowOn2, 134
g_Calibrate, 129
g_GetErrID, 145
g_GetPos, 141
g_GetPressure1, 147
g_GetPressure2, 148
g_GetSpd, 142
g_GetState, 143
g_GripIn, 123
g_GripOut, 126
g_Init, 117
g_IsCalibrated, 140
g_IsCamOnline, 149
g_JogIn, 119
g_JogOut, 120
g_MoveTo, 121
g_SetMaxSpd, 131
g_Stop, 130
g_VacuumOff1, 137
g_VacuumOff2, 139
g_VacuumOn1, 136

g_VacuumOn2, 138

grease
 disposal, 151

H

hazardous material, 151
humidity
 operation, 18
 storage, 18

M

magnesium
 disposal, 151

O

oil
 disposal, 151

P

plastic
 disposal, 151
pneumatic module
 air consumption, 22
protection classes, 18
protection type, 18

R

RAPID function, 140–143, 145, 147–149
RAPID instruction, 117, 119–121, 123, 126, 129–139
robot
 protection class, 18
 protection types, 18
rubber
 disposal, 151

S

safety
 introduction, 11
steel
 disposal, 151
storage conditions, 18

T

temperatures
 operation, 18
 storage, 18



ABB AB

Robotics & Discrete Automation

S-721 68 VÄSTERÅS, Sweden

Telephone +46 (0) 21 344 400

ABB AS

Robotics & Discrete Automation

Nordlysvegen 7, N-4340 BRYNE, Norway

Box 265, N-4349 BRYNE, Norway

Telephone: +47 22 87 2000

ABB Engineering (Shanghai) Ltd.

Robotics & Discrete Automation

No. 4528 Kangxin Highway

PuDong District

SHANGHAI 201319, China

Telephone: +86 21 6105 6666

ABB Inc.

Robotics & Discrete Automation

1250 Brown Road

Auburn Hills, MI 48326

USA

Telephone: +1 248 391 9000

abb.com/robotics